Bellemave Twin Metal Loft Bed

Bellemave Twin Metal Loft Bed with Desk and Shelve Instruction Manual

Model: Twin Metal Loft Bed

Important Safety Information

- **WARNING:** Top bunk not to be used by children under 6 years of age.
- Ensure all connections are securely fastened before use.
- Regularly inspect the bed for loose parts or damage.
- Do not use substitute parts. Contact Bellemave for replacement parts.
- Follow assembly instructions carefully to prevent injury.
- Maximum weight capacity for the bed: 220 lbs.
- Recommended mattress thickness: 6 inches.

Package Contents

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Metal Bed Frame Components (various beams, rails, legs)
- L-shaped Desk Panels
- Shelf Panel
- 2 Ladders
- Safety Guard Rails
- Hardware Pack (screws, bolts, nuts, Allen wrench)

- Assembly Instructions Manual

Note: Specific quantities of each component may vary. Refer to the detailed parts list included in your physical package.

Assembly Instructions

Assembly is required. It is recommended that two adults assemble this product. Please follow these steps carefully.

Step 1: Unpack and Identify Parts

Carefully unpack all components and lay them out on a clean, soft surface to prevent scratches. Identify each part using the provided hardware list.

Step 2: Assemble the Main Bed Frame

Connect the main vertical and horizontal metal beams to form the base structure of the loft bed. Ensure all bolts are finger-tightened initially.



Image: Illustrates the initial assembly of the main bed frame components.

Step 3: Attach Guard Rails and Ladders

Securely attach the full-length guard rails to the top bunk. Install the two ladders to the designated attachment points on the bed frame. Ensure they are firmly secured for safety.



Image: Shows the loft bed with guard rails and ladders in place.

Step 4: Install Desk and Shelf

Mount the L-shaped desk and the upper shelf to the bed frame according to the instructions. Ensure all connections are tight and stable.



Image: Depicts the loft bed with the L-shaped desk and shelf fully installed.

Step 5: Final Tightening and Inspection

Once all components are in place, go back and fully tighten all bolts and screws using the provided Allen wrench. Do not overtighten. Perform a final inspection to ensure the bed is stable and all safety features are correctly installed.



Image: A complete view of the assembled Bellemave Twin Metal Loft Bed with desk and shelf.

Usage Guidelines

This loft bed is designed for efficient space utilization, providing both a sleeping area and a workstation.

- **Sleeping Area:** The top bunk is suitable for a twin-size mattress with a maximum thickness of 6 inches. Ensure the mattress fits snugly within the guard rails.
- **Workstation:** The L-shaped desk provides a dedicated area for studying, working, or creative activities. The integrated shelf offers additional storage for books or supplies.
- **Ladders:** Use the ladders for safe access to and from the top bunk. Always face the ladder when climbing or descending.
- **Under-bed Space:** The area beneath the bed can be utilized for storage, a seating area, or other personal uses.

Maintenance and Care

- **Cleaning:** Wipe down the metal frame and wooden surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Regular Inspection:** Periodically check all bolts, screws, and connections to ensure they remain tight. Retighten as necessary to maintain stability and safety.
- **Weight Distribution:** Avoid placing excessive weight on any single point of the bed or desk. Distribute weight evenly.
- **Environmental Conditions:** Keep the bed in a dry environment. Avoid prolonged exposure to direct sunlight or extreme temperature changes.

Troubleshooting

Problem	Possible Cause	Solution
Bed feels unstable or wobbly	Loose bolts or uneven assembly.	Ensure all bolts are fully tightened. Check that the bed is on a level surface.
Squeaking noises	Loose connections or friction between metal parts.	Retighten all hardware. Apply a small amount of lubricant (e.g., silicone spray) to connection points if necessary.
Missing or damaged parts	Packaging error or transit damage.	Do not proceed with assembly. Contact Bellemave customer support immediately for replacement parts.

Specifications

Brand: Bellemave

Model: Twin Metal Loft Bed

Material: Heavy Duty Steel, Wood (desk/shelf)

Finish Type: Powder Coated (Black)

Product Dimensions: 78"L x 41.3"W x 70.9"H

Compatible Mattress Size: Twin

Bed Weight Capacity: 220 lbs

Recommended Mattress Thickness: 6 inches

Assembly Required: Yes

UPC: 788634285405

ASIN: B08XZ55JZN




Image: Technical drawing showing the detailed dimensions of the loft bed.

Warranty and Support

For warranty information, replacement parts, or technical assistance, please contact Bellemave customer support.

Please have your model number (Twin Metal Loft Bed) and ASIN (B08XZ55JZN) ready when contacting support.

Visit the official Bellemave store for more information:Bellemave Store