Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

KUCCU B08Y1HX721

KUCCU 6.5-QT Stand Mixer Instruction Manual

Model: B08Y1HX721
Brand: KUCCU

1. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before operating the mixer.
- To protect against risk of electrical shock, do not immerse the mixer base, cord, or plug in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Avoid contact with moving parts. Keep hands, hair, clothing, as well as spatulas and other utensils away from beaters during operation to prevent injury and/or damage to the mixer.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter.
- Do not let cord contact hot surfaces, including the stove.

2. Product Overview

The KUCCU Stand Mixer is a versatile kitchen appliance designed for various mixing tasks, from kneading dough to whipping cream. It features a powerful 660W motor and a large 6.5-quart stainless steel bowl.

Components:

- Mixer Base with Tilt-Head Mechanism
- 6.5-Quart Stainless Steel Mixing Bowl
- Dough Hook
- Flat Beater

- Wire Whisk
- Splash Guard
- Egg White Separator
- Scraper

Key Features:

- **660W High Performance Motor:** Provides ample power for various mixing needs.
- **6-Speed Control:** Offers precise speed adjustments for different ingredients and recipes.
- **Tilt-Head Design:** Allows for easy access to the bowl and attachments.
- **Planetary Mixing Action:** Ensures thorough and even mixing by reaching all areas of the bowl.
- **Anti-Slip Suction Cups:** Keeps the mixer stable during operation.
- **Removable Bowl:** Easy to remove for cleaning and pouring.



Figure 2.1: KUCCU Stand Mixer and its accessories.



Figure 2.2: Labeled components of the KUCCU Stand Mixer.

3. Setup

1. **Unpack and Clean:** Carefully remove all packaging materials. Before first use, wash the mixing bowl, dough hook, flat beater, wire whisk, splash guard, egg white separator, and scraper in warm, soapy water. Rinse thoroughly and dry. Wipe the mixer base with a damp cloth. Do not immerse the mixer base in water.
2. **Placement:** Place the mixer on a clean, dry, and stable surface. Ensure the anti-slip suction cups on the base are securely gripping the countertop.
3. **Attach Mixing Bowl:** Place the stainless steel mixing bowl onto the base, aligning the grooves on the bowl with the locking mechanism on the base. Turn the bowl clockwise until it locks securely into place.
4. **Attach Accessory:**
    - Ensure the mixer is unplugged and the speed control is set to '0'.
    - Press the tilt-head release button and lift the motor head until it locks in the tilted position.
    - Slide the desired attachment (dough hook, flat beater, or wire whisk) onto the attachment shaft, aligning the pin on the shaft with the groove on the attachment. Push upwards and turn counter-clockwise until it clicks into place.
    - Lower the motor head by pressing the tilt-head release button and gently pushing the head down until it locks into the operating position.
5. **Attach Splash Guard:** If desired, place the splash guard over the mixing bowl after the attachment is installed and the head is lowered. The opening in the splash guard allows for easy addition of ingredients during mixing.

4. Operating Instructions

General Operation:

1. Ensure the mixer is properly set up with the bowl and desired attachment.
2. Add your ingredients to the mixing bowl.
3. Plug the mixer into a standard electrical outlet.
4. Turn the speed control knob to the desired speed setting. Start with a lower speed and gradually increase as needed to prevent splashing.
5. When finished mixing, turn the speed control knob back to '0' and unplug the mixer from the outlet.
6. Press the tilt-head release button and lift the motor head to remove the bowl and attachment.

Speed Settings and Attachment Usage:

The mixer features 6 speed settings plus a 'P' (Pulse) function for quick bursts of power.



Figure 4.1: Speed Settings Guide.



Figure 4.2: Attachment Usage Guide.

- **P (Pulse):** Use for short, powerful bursts. Ideal for quick incorporation of ingredients or for starting a mix.
- **Speeds 1-2 (Dough Hook):** Suitable for heavy mixtures such as bread dough, pizza dough, and pasta dough. Begin at speed 1 and gradually increase to speed 2 for kneading.
- **Speeds 3-4 (Flat Beater):** Best for medium-heavy mixtures like batters for cakes, cookies, crepes, and mashed potatoes. Use for combining ingredients and general mixing.
- **Speeds 5-6 (Wire Whisk):** Designed for light mixtures such as whipping cream, egg whites, meringues, and light sauces. Start at speed 5 and increase to speed 6 for maximum aeration.

Using the Egg White Separator:

The included egg white separator can be used to easily separate egg yolks from whites. Simply crack an egg into the separator, and the white will pass through while the yolk remains.

5. Cleaning and Maintenance

Proper cleaning and maintenance will ensure the longevity and optimal performance of your KUCCU Stand Mixer.

1. **Always unplug the mixer** from the power outlet before cleaning.

2. **Mixing Bowl, Dough Hook, Flat Beater, Wire Whisk, Splash Guard, Egg White Separator, and Scraper:** These accessories are made of stainless steel and durable materials. They are generally dishwasher safe for convenient cleaning. For best results and to prolong their lifespan, hand washing with warm, soapy water is recommended, especially for the whisk and beater. Rinse thoroughly and dry immediately.
3. **Mixer Base:** Wipe the exterior of the mixer base with a soft, damp cloth. Do not use abrasive cleaners or scourers. Never immerse the mixer base in water or any other liquid.
4. **Storage:** Store the mixer and its accessories in a clean, dry place when not in use. Ensure all parts are completely dry before storing.



Figure 5.1: Dishwasher Safe Symbol (for applicable parts).

6. Troubleshooting

If you encounter any issues with your KUCCU Stand Mixer, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Mixer does not turn on.	Not plugged in; power outlet malfunction; speed control not at '0'.	Ensure the power cord is securely plugged into a working outlet. Check if the speed control knob is set to '0' before turning on.
Attachments do not reach the bottom of the bowl or scrape the sides.	Attachment not properly installed.	Ensure the attachment is pushed up and twisted counter-clockwise until it clicks securely into place on the shaft.
Excessive noise or vibration during operation.	Overloaded; unstable surface; attachment not properly installed.	Reduce the amount of ingredients. Ensure the mixer is on a flat, stable surface. Verify the attachment is securely installed.
Motor stops during operation.	Overheating due to prolonged use or heavy load.	Turn off the mixer and unplug it. Allow it to cool down for at least 20-30 minutes before resuming use. Reduce load if consistently stopping.

7. Specifications

Feature	Specification

Feature	Specification
Brand	KUCCU
Model	B08Y1HX721
Power/Wattage	660 watts
Capacity	6.5 quarts
Voltage	120 Volts (AC)
Material	Stainless Steel (Bowl, some attachments)
Number of Speeds	6
Product Dimensions	38 x 23.8 x 32.18 cm (14.96 x 9.37 x 12.67 inches)
Item Weight	4.99 kg (11 lbs)



Figure 7.1: Product Dimensions.

8. Warranty and Support

KUCCU offers a full five-year quality guarantee for this electric mixer, demonstrating confidence in its durability and performance. Additionally, friendly lifelong support is provided to assist with any questions or issues you may encounter.

If you received a defective item or have any questions during use, please feel free to contact KUCCU customer support. Refer to your product packaging or purchase documentation for specific contact details, or visit the official KUCCU website for support information.

© 2025 KUCCU. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08Y1HX721

More documents and user manuals: **https://manuals.plus/**