Adesso 1569-12

ADESSO Floor Lamp Instruction Manual

Model: 1569-12 | Brand: Adesso

Introduction

Thank you for purchasing the Adesso Floor Lamp. This modern lamp, Model 1569-12, is designed to enhance your living space with its stylish blend of neutral colors, featuring a warm walnut finish cube-shaped base, a thin black stem, and a tall drum-shaped beige textured fabric shade. It provides soft, diffused light, perfect for bedrooms, living rooms, or any area requiring ambient illumination. Please read this manual carefully before assembly and operation to ensure safe and proper use.



Image: The Adesso Floor Lamp, showcasing its black body, walnut base, and beige fabric lampshade.

Setup and Assembly

Assembly of your Adesso Floor Lamp is straightforward and requires minimal effort. Please follow these steps carefully:

1. **Unpack Components:** Carefully remove all parts from the packaging. Ensure all components are present: lamp base (walnut), lamp pole sections (black), lamp shade (beige fabric), and pull chain.
2. **Assemble the Pole:** Screw the black lamp pole sections together clockwise until securely tightened.
3. **Attach Pole to Base:** Carefully thread the assembled lamp pole into the walnut base. Turn clockwise until it is firmly seated and stable.
4. **Install the Lampshade:** Place the beige fabric lampshade onto the lamp's harp or shade holder. Secure it with the finial (if included) by screwing it onto the top of the harp. *Ensure the shade is oriented correctly and not upside down for proper fit and appearance.*
5. **Insert Light Bulb:** Screw one E26 medium base light bulb (not included) into the lamp socket. Do not exceed 100 watts.
6. **Connect to Power:** Plug the 6-foot brown power cord into a standard 120V AC electrical outlet.






Image: Dimensional view of the Adesso Floor Lamp, showing its 62-inch height and 8.5-inch base dimensions.



Image: A detailed view of the lamp's cube-shaped walnut base, highlighting its finish and connection point.

Operating Instructions

The Adesso Floor Lamp is designed for simple and convenient operation.

- **Power On/Off:** The lamp is operated by a black metal pull chain switch. Pull the chain once to turn the lamp on, and pull it again to turn the lamp off.
- **Bulb Requirements:** This lamp requires one E26 medium base bulb. For optimal performance and safety, use an incandescent bulb up to 100 watts or an equivalent LED bulb. The bulb is not included with the lamp.



Image: The Adesso Floor Lamp positioned in a modern living room, demonstrating its functional illumination.

Maintenance

Proper care and maintenance will ensure the longevity and continued aesthetic appeal of your Adesso Floor Lamp.

- **Cleaning the Shade:** To clean the beige fabric shade, gently dust it with a soft, dry cloth or use a lint roller to remove any debris. For minor spots, dab gently with a slightly damp cloth, avoiding excessive moisture.
- **Cleaning the Base and Stem:** Wipe the walnut base and black metal stem with a soft, dry cloth. Avoid using abrasive cleaners or solvents, as these can damage the finish.

- **Bulb Replacement:** Always ensure the lamp is unplugged from the power outlet before replacing the light bulb. Allow the old bulb to cool completely before removal.
- **General Care:** Do not expose the lamp to excessive moisture or direct sunlight for prolonged periods, as this may cause fading or damage to materials.

Troubleshooting

If you encounter any issues with your Adesso Floor Lamp, please refer to the following common problems and their solutions:

Problem	Solution
Lamp does not turn on.	Ensure the power cord is securely plugged into a working electrical outlet. Check if the light bulb is screwed in tightly and is not burnt out. Verify the pull chain switch is functioning correctly.
Lampshade appears crooked or unstable.	Confirm that the lampshade is properly seated on the harp and secured with the finial. Double-check that the plastic warning sticker (if any) around the lightbulb socket has been removed, as it can interfere with shade alignment. Ensure all pole sections are tightly screwed together.
Lamp is wobbly or unstable.	Ensure the lamp is placed on a flat, level surface. Verify that the lamp pole is securely and fully screwed into the walnut base.

Specifications

Feature	Detail
Model Number	1569-12
Product Dimensions	8.5"D x 8.5"W x 62"H
Item Weight	8.8 Pounds
Lamp Type	Floor Lamp
Base Material	Wood (Walnut finish)
Body Material	Metal (Black finish)
Shade Material	Fabric (Beige textured)
Bulb Base	E26 Medium Base

Feature	Detail
Max Wattage	100 Watts (Incandescent or LED equivalent)
Switch Type	Pull Chain
Power Source	Corded Electric
Cord Length	6 feet (72 inches)
Voltage	120 Volts (AC)
Certifications	UL, ETL
Assembly Required	Yes
UPC	798919156924

Warranty and Support

This Adesso Floor Lamp is covered by a manufacturer's warranty. For specific details regarding the warranty period and coverage, please refer to the documentation included with your purchase or visit the official Adesso website.

For technical support, replacement parts, or any inquiries not covered in this manual, please contact Adesso customer service. Contact information can typically be found on the product packaging or the manufacturer's official website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question