

[manuals.plus](#) /

› [Redmi](#) /

› [Redmi 126 cm \(50 inches\) 4K Ultra HD Android Smart LED TV X50 | L50M6-RA User Manual](#)

Redmi L50M6-RA

Redmi 126 cm (50 inches) 4K Ultra HD Android Smart LED TV X50 | L50M6-RA User Manual

Model: L50M6-RA

1. INTRODUCTION

This manual provides essential instructions for the safe and efficient operation of your Redmi 126 cm (50 inches) 4K Ultra HD Android Smart LED TV X50, model L50M6-RA. Please read this manual thoroughly before using the television and retain it for future reference.



Image: Front view of the Redmi 50-inch 4K Ultra HD Android Smart LED TV X50, showcasing its sleek design and display.

2. SAFETY INFORMATION

To ensure safe operation and prevent damage, observe the following precautions:

- **Power Source:** Connect the TV only to an AC 220V, 50/60Hz power supply.
- **Ventilation:** Ensure adequate ventilation around the TV. Do not block ventilation openings.
- **Water and Moisture:** Do not expose the TV to rain or moisture. Avoid placing objects filled with liquids, such as vases, on the TV.
- **Cleaning:** Unplug the TV before cleaning. Use a soft, dry cloth. Do not use liquid cleaners or aerosol cleaners.
- **Placement:** Place the TV on a stable, level surface. If wall-mounting, ensure the mount is securely installed and can support the TV's weight.
- **Children:** Supervise children to prevent them from climbing on the TV or stand.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- Redmi 50-inch 4K Ultra HD Android Smart LED TV X50
- Remote Control
- Power Cable
- TV Stand (2 pieces)
- Screws for TV Stand
- User Manual (this document)
- AAA Batteries (for remote control)

4. SETUP

4.1 Attaching the TV Stand

1. Carefully place the TV face-down on a soft, flat surface to prevent screen damage.
2. Align the stand bases with the corresponding slots on the bottom of the TV.
3. Secure the stand bases using the provided screws.

4.2 Wall Mounting (Optional)

If you choose to wall-mount your TV, ensure you use a VESA-compatible wall mount kit (not included) that supports the TV's weight and dimensions. Follow the instructions provided with your wall mount kit.

4.3 Connecting Peripherals

The TV features various ports for connecting external devices. Refer to the image below for an overview of the port locations.




Image: Overview of the Redmi TV's rear panel, indicating the general placement of connectivity ports.

Detailed port descriptions:

- **HDMI 2.1 (x3):** For connecting high-definition devices like Blu-ray players, gaming consoles, or set-top boxes. Supports eARC on one port.
- **USB 2.0 (x2):** For connecting USB storage devices to play media or for software updates.
- **Ethernet (LAN):** For a wired internet connection.
- **AV Input:** For connecting older devices using composite video and stereo audio cables.
- **Optical Port:** For digital audio output to a soundbar or home theater system.
- **3.5mm Headphone Jack:** For connecting headphones.

Ports

HDMI 2.1*x3

USB 2.0x2

Ethernet

AV Input

Optical

Headphone Jack



Image: Detailed view of the TV's input and output ports, including HDMI, USB, Ethernet, AV, Optical, and Headphone Jack.

4.4 Power Connection

Connect the power cable to the TV's power input and then to a suitable wall outlet (AC 220V, 50/60Hz).

4.5 Initial Setup Wizard

Upon first power-on, the TV will guide you through the initial setup process, including language selection, network connection (Wi-Fi or Ethernet), Google account sign-in, and channel scanning.

5. OPERATING INSTRUCTIONS

5.1 Remote Control Functions

The included remote control provides access to all TV functions. Insert two AAA batteries (included) into the remote

Sleek Remote



Quick Wake

Turn on the TV
in less than 5s



Quick Mute

Double tap volume
down button to Mute



Quick Settings

Long press the PatchWall button
to enter quick settings menu



Image: The Redmi TV remote control, illustrating buttons for Quick Wake, Quick Mute (double tap volume down), and Quick Settings (long press PatchWall button).

- **Power Button:** Turns the TV on or off.
- **Quick Wake:** Turns on the TV in less than 5 seconds.
- **Volume Buttons:** Adjusts the volume. Double tap volume down for Quick Mute.
- **Navigation Pad:** For menu navigation.
- **OK Button:** Confirms selections.
- **Back Button:** Returns to the previous screen.
- **Home Button:** Accesses the Android TV home screen.
- **PatchWall Button:** Accesses the PatchWall interface. Long press for Quick Settings.
- **App Shortcut Buttons:** Dedicated buttons for popular streaming services like Netflix and Prime Video.

- **Google Assistant Button:** Activates voice commands.

5.2 Android TV 10 Interface

Your Redmi TV runs on Android TV 10, providing access to a wide range of apps and features.




Image: The Android TV 10 interface on the Redmi TV, highlighting Google Play Store, Google Assistant, and built-in Chromecast functionality.

- **Google Play Store:** Download and install various applications, games, and streaming services.
- **Google Assistant:** Use voice commands to search for content, control smart home devices, and get information.
- **Chromecast Built-in:** Cast content directly from your smartphone, tablet, or computer to the TV.

5.3 PatchWall Interface

PatchWall is a content-first interface that aggregates content from various streaming platforms and live TV channels, offering personalized recommendations.

An elevated Content Xperience with PatchWall



Top Features

IMDb Ratings

Universal Search

Kids Mode

300+ Live Channels



Subscription/ charges may be required for certain content

Image: The PatchWall interface on the Redmi TV, showing aggregated content from multiple streaming services and features like IMDb Ratings, Universal Search, Kids Mode, and 300+ Live Channels.

- **Universal Search:** Find content across all integrated platforms.
- **Kids Mode:** Curated content suitable for children.
- **Live Channels:** Access over 300 live channels.

6. MAINTENANCE

- **Screen Cleaning:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, slightly dampen the cloth with water or a specialized screen cleaner (apply to cloth, not directly to screen).
- **Cabinet Cleaning:** Use a soft, dry cloth to clean the TV cabinet.
- **Dusting:** Regularly dust the ventilation openings to prevent overheating.
- **Power Cord:** Periodically check the power cord for any damage.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power cord not connected; power outlet not working.	Ensure power cord is securely connected. Test the outlet with another device.
No picture, but sound is present	Incorrect input source selected; backlight issue.	Press the "Input" button on the remote to select the correct source.
No sound, but picture is present	Volume muted or too low; incorrect audio output settings.	Increase volume. Check audio output settings in the TV menu.
Remote control not working	Batteries depleted or incorrectly inserted; obstruction between remote and TV.	Replace batteries. Ensure clear line of sight to the TV's IR receiver.
Wi-Fi connection issues	Incorrect password; router issues; TV too far from router.	Verify Wi-Fi password. Restart router. Move TV closer to router or use Ethernet.

8. SPECIFICATIONS

Key technical specifications for the Redmi 126 cm (50 inches) 4K Ultra HD Android Smart LED TV X50 | L50M6-RA:

- **Model:** L50M6-RA
- **Screen Size:** 126 cm (50 inches)
- **Resolution:** 3840 x 2160 pixels (4K Ultra HD)
- **Operating System:** Android TV 10
- **Refresh Rate:** 60 Hz
- **Viewing Angle:** 178 Degrees
- **Aspect Ratio:** 16:9
- **Audio Output:** 30 Watts
- **Hardware Interface:** HDMI (x3, HDMI 2.1, one with eARC), USB (x2, USB 2.0), Ethernet, AV Input, Optical Port, 3.5mm Headphone Jack
- **Wireless Connectivity:** Bluetooth 5.0 with BLE, 2X2 Dual Band Wi-Fi
- **Processor:** Quad core processor (A55)
- **Memory:** 2GB RAM, 16GB Storage
- **Voltage:** 220 Volts
- **Power Consumption:** 30 Watts (On-mode)
- **Item Weight:** 14 kg 500 g
- **Package Dimensions:** 112 x 65 x 15 cm
- **Mounting Type:** Wall mount; Table mount





Image: Dimensional diagram of the Redmi TV, indicating overall width (112.27cm / 44.2inch), height (65.29cm / 25.7inch), diagonal (125.7cm / 49.5inch), and side profile depth (8.13cm / 3.2inch).

Seamless Performance



2GB RAM
16GB Storage



Quad core
processor

A55

Image: Performance specifications of the Redmi TV, detailing 2GB RAM, 16GB Storage, Quad-core processor, and A55 chip.

9. WARRANTY AND SUPPORT

Your Redmi TV comes with a standard 1-year warranty. For extended coverage, consider the Mi Extended Warranty program.



Mi EXTENDED WARRANTY



Keep your
Xiaomi products as good
as new with the
Mi Extended Warranty

Here are some Key Benefits



Zero
Documentation



Genuine
Spare Parts



Cashless
Repairs



Authorised
Service Centres



On-site
Support

Image: Information about the Mi Extended Warranty, highlighting benefits such as zero documentation, genuine spare parts, cashless repairs, authorized service centers, and on-site support.

For service requests or technical assistance, Redmi offers dedicated support:

- **Service Request Response:** Expect a call back from the support team within 60 minutes for any service request.
- **On-site Support:** Experts aim to arrive at your home within 24 hours of your service request, 99% of the time.
- **Installation Services:** 99% of new TV installations are completed within 3 hours of your appointment.



Say Goodbye to Waiting

99% of new TV installations are completed within **3 hours** of your appointment.



Need assistance? We're just a call away!

We're just a call away! Enjoy a call back from our team within **60 minutes** for any service request.



Swift solutions at your doorstep!

Our experts arrive at your home within **24 hours** of your service request, **99%** of the time.

Image: Redmi's service commitment, detailing quick installation, prompt call-back for assistance, and swift on-site solutions.







Visit the official Redmi Store for more information: [Redmi Store on Amazon](#)




© 2023 Redmi. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.


Related Documents - L50M6-RA

	<p>Redmi TV Safety Notice and Installation Guide - Setup and Warranty Information</p> <p>Comprehensive guide for Redmi TV installation, safety precautions, remote control usage, specifications, and warranty policy. Includes setup instructions, important usage guidelines, and troubleshooting tips for your Redmi Smart TV.</p>
	<p>Redmi TV L43M6-RA Safety, Installation, and Warranty Guide</p> <p>Comprehensive guide for Redmi TV L43M6-RA, covering safety notices, installation steps, remote control usage, technical specifications, important precautions, and warranty policy. Learn how to set up and safely operate your smart TV.</p>
	<p>Redmi Smart TV L32M6-RA: Safety, Installation, and Warranty Guide</p> <p>Comprehensive guide for the Redmi Smart TV L32M6-RA, covering safety precautions, installation steps (tabletop and wall-mount), TV interface details, remote control functions, technical specifications, important warnings, and the product's warranty policy.</p>
	<p>Redmi TV Safety Notice and Installation Guide - Model L65M6-RA</p> <p>Comprehensive safety notice, installation guide, and warranty policy for the Redmi TV, model L65M6-RA. Learn about setup, usage precautions, and warranty terms from Xiaomi.</p>
	<p>Redmi Note 8 (2021) Краткое руководство пользователя</p> <p>Краткое руководство пользователя для смартфона Redmi Note 8 (2021) от Xiaomi. Информация о настройке, MIUI, SIM-картах, безопасности и соответствии нормам.</p>
	<p>Redmi Note 9S User Guide: Setup, Features, and Safety Information</p> <p>Comprehensive user guide for the Redmi Note 9S smartphone by Xiaomi, detailing setup, MIUI, dual SIM, safety, regulations, and specifications. Available in multiple languages.</p>



[pdf] User Manual Quick Start Guide Instructions Specifications Guide Accessories
L50M6 RA RA4D User Manual Mi India5562e0b0b141bdccb3577326678070ffi02 appmifile 641 update in
04 10 2021 5562e0b0b141bdccb3577326678070ff quot |||

Accessories Note: 1 Accessory Items may vary depending upon model. 2
Specifications may change wi ... : Double tap volume down bu on to mute. Model
Wireless Connectivity Basic Specs Android TV Model: **L50M6-RA** Voltage: 100-240V-
50/60Hz Rated Power: 140W Wi-Fi: 2.4/5GHz Bluetooth: BT5.0 Screen size: ...
lang:en **score:38** filesize: 979.75 K page_count: 1 document date: 2021-08-20



[Redmi TV Safety Notice and Installation Guide - Setup and Warranty Information](#)
Comprehensive guide for Redmi TV installation, safety precautions, remote control
usage, specifications, and warranty policy. Includes setup instructions, important
usage guidelines, and troubleshooting tips for your Redmi Smart TV.
lang:en **score:35** filesize: 979.75 K page_count: 1 document date: 2021-08-20