

[Manuals.plus](#) /

› [Bestier](#) /

› Bestier L Shaped Desk with Storage Shelves (Model D244) - Instruction Manual

Bestier D244

Bestier L Shaped Desk with Storage Shelves

Model: D244

Brand: Bestier

INTRODUCTION

Thank you for choosing the Bestier L Shaped Desk with Storage Shelves. This manual provides essential information for the safe assembly, operation, and maintenance of your new desk. Please read these instructions carefully before beginning assembly and retain them for future reference.



Image: Bestier L Shaped Desk with Storage Shelves in a home office setting, featuring a computer monitor, keyboard, and decorative plant.

SAFETY INFORMATION

- Always assemble the desk on a stable, flat surface.
- Use the provided tools and follow the instructions carefully.
- Be aware of the desk's weight (19.3 kg or 42.5 lbs) and handle it with care to avoid injury.
- Once assembled, ensure the desk is stable and secure before use.
- Do not exceed the maximum weight recommendation of 66 pounds (30 kg) for the desk surface.
- Keep small parts and packaging materials away from children and pets.

PACKAGE CONTENTS

Before assembly, please verify that all parts and hardware are present and undamaged. Refer to the parts list provided in your package. If any components are missing or damaged, please contact Bestier customer

support.



Image: Diagram showing various components of the L shaped desk laid out for assembly, including desk panels, metal frames, and hardware.

SETUP AND ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your Bestier L Shaped Desk. It is recommended to have two people for assembly.

1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out on a clean, soft surface to prevent scratches. Identify each part using the provided parts list.
2. **Assemble the Main Desk Frame:** Attach the metal support frames to the main desk panels using the designated screws and tools. Ensure all connections are secure but do not overtighten until all parts are aligned.
3. **Attach the L-Shaped Extension:** Connect the L-shaped extension panel to the main desk frame. The desk is reversible, allowing you to position the storage shelves on either the left or right side to suit your space.
4. **Install Storage Shelves:** Insert the storage shelves into the designated slots on the L-shaped extension. The shelves are adjustable to accommodate different item heights.
5. **Tighten All Connections:** Once all parts are in place and aligned, fully tighten all screws and bolts.
6. **Final Placement:** Carefully move the assembled desk to its desired location. Ensure it is stable and level.



Image: Bestier L Shaped Desk with storage shelves on the right side, set up in a room with a window.

**Bestier's iron tube provides greater support,
more durable than others.**

Bestier



Others



VS

Image: Comparison image highlighting Bestier's iron tube support with X-bars for enhanced durability and stability.

OPERATING INSTRUCTIONS

Your Bestier L Shaped Desk is designed for versatile use in home offices, study areas, or gaming setups. The integrated storage shelves provide convenient space for books, office supplies, or a computer tower.

- **Shelf Adjustment:** The storage shelves can be adjusted to different heights. To adjust, remove the shelf, reposition the support pins to the desired height, and reinsert the shelf securely.
- **Weight Distribution:** Distribute weight evenly across the desk surface and shelves to maintain stability. Do not place heavy items on the very edge of the desk.



Image: Close-up view of the desk's storage shelves, demonstrating space for a computer tower and books.

MAINTENANCE

To ensure the longevity and appearance of your desk, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the desk surfaces with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the laminated finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the surface.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Heat and Moisture:** Avoid placing hot items directly on the desk surface. Use coasters for drinks to protect against moisture rings.


TROUBLESHOOTING

Problem	Possible Cause	Solution
Desk is wobbly or unstable.	Loose screws or uneven floor.	Ensure all screws are tightened. Adjust the leveling feet (if present) or place shims under the legs to stabilize.
Parts do not align during assembly.	Incorrect orientation of parts or overtightened screws.	Loosen all screws, re-align parts according to the manual, then gradually tighten. Ensure correct part orientation.
Missing hardware or damaged parts.	Shipping damage or packaging error.	Contact Bestier customer support with your model number and a description of the issue for assistance.

SPECIFICATIONS

- **Brand:** Bestier
- **Model:** D244
- **Desk Design:** L-Shaped Computer Desk with Storage Shelves
- **Product Dimensions (D x W x H):** 35.43" x 55.12" x 29.13" (90cm x 140cm x 74cm)
- **Color:** Black Grained
- **Base Material:** Metal
- **Finish Type:** Laminated
- **Item Weight:** 19.3 kg (42.5 lbs)
- **Maximum Weight Recommendation (Desk Surface):** 66 pounds (30 kg)
- **Number of Shelves:** 4 (adjustable)

Product Size



UNIT : INCH/CM

Image: Detailed diagram showing the dimensions of the Bestier L Shaped Desk in inches and centimeters, including the main desk surface and the storage shelf unit.

WARRANTY AND SUPPORT

This Bestier L Shaped Desk comes with a **Lifetime Warranty**, reflecting our commitment to quality and customer satisfaction. For any product issues, missing parts, or assembly questions, please do not hesitate to contact our customer support team.

Contact Information:

Website: [Visit the Bestier Store on Amazon](#)

Email: support@bestier.com (Example)

Phone: 1-800-XXX-XXXX (Example)

Please have your model number (D244) and purchase information ready when contacting support.

