

[Manuals.plus](#) /

› [JEDELEOS](#) /

› JEDELEOS Replacement Flat Non-Stretch Belts for Hoover WindTunnel 3 Pro Pet Upright Vacuum Models UH72625, UH72630, UH72635, UH70930, UH70935, UH70936, UH70937, UH70939 Series

JEDELEOS UH72625, UH72630, UH72635, UH70930, UH70935, UH70936, UH70937, UH70939, UH70900, UH70901, UH70905, UH70909

JEDELEOS Replacement Flat Non-Stretch Belts Instruction Manual

For Hoover WindTunnel 3 Pro Pet Upright Vacuum Models

1. PRODUCT OVERVIEW

This manual provides instructions for the installation and maintenance of JEDELEOS Replacement Flat Non-Stretch Belts, designed for specific Hoover WindTunnel 3 Pro Pet Upright Vacuum models. These belts are crucial components for the proper functioning of your vacuum's brush roll system.



Image 1.1: JEDELEOS Replacement Belts and Compatible Vacuum. This image displays two black replacement belts alongside a red Hoover WindTunnel 3 Pro Pet upright vacuum, illustrating the product and its intended use.

2. COMPATIBILITY

These replacement belts are compatible with the following Hoover WindTunnel 3 Pro Pet Upright Vacuum models:

- UH70930
- UH70935
- UH70936
- UH70937
- UH70939
- UH70900
- UH70901
- UH70905
- UH70909
- UH72625

- UH72630
- UH72635

UNIVERSAL COMPATIBILITY

✓ Fit Hoover WindTunnel 3 Pro Pet UH70930,UH70935,UH70937,UH70939,UH72630 Series



UH70930



UH70935



UH70937



UH70939



UH72630



*The display of the vacuum cleaners is only to illustrate the compatibility of the belts.

Image 2.1: Compatible Vacuum Models. This image illustrates several Hoover WindTunnel 3 Pro Pet vacuum models (UH70930, UH70935, UH70937, UH70939, UH72630) with green checkmarks, confirming their compatibility with the replacement belts. The full list of compatible models is provided above.

3. INSTALLATION INSTRUCTIONS


Follow these steps to replace the drive belt in your Hoover WindTunnel 3 Pro Pet Upright Vacuum:

1. **Safety First:** Always unplug your vacuum cleaner from the power outlet before performing any maintenance or part replacement.
2. **Access the Brush Roll:** Lay the vacuum cleaner on its side or back to access the brush roll area. You may need to remove a cover plate, typically secured by screws, to expose the brush roll and belt.
3. **Remove the Old Belt:** Carefully remove the damaged or worn belt from the brush roll and motor shaft. Note its original position for correct installation of the new belt.
4. **Install the New Belt:** Place the new flat non-stretch belt around the motor shaft and then stretch it over the

brush roll. Ensure the belt is properly seated in the grooves of both the motor shaft and the brush roll.

5. **Test Rotation:** Manually rotate the brush roll a few times to ensure the belt is correctly aligned and moves freely without obstruction.
6. **Reassemble:** Reattach any covers or plates that were removed, securing them with screws.
7. **Final Check:** Plug in the vacuum and briefly turn it on to confirm the brush roll spins correctly.

EASY TO REPLACE



- Simply remove the broken or worn belt in the vacuum.
- Replace the new belt according to the original installation position.

✓ **Let's reactivate your vacuum cleaner!**

*The display of the vacuum cleaners is only to illustrate the compatibility of the belts.

Image 3.1: Belt Replacement Process. This diagram illustrates the two main steps for replacing a vacuum belt: first, removing the old or broken belt, and second, installing the new belt in its correct position on the vacuum's brush roll assembly.

4. OPERATING CONSIDERATIONS

After replacing the belt, ensure the vacuum cleaner operates smoothly. A properly installed belt will allow the brush roll to spin effectively, contributing to optimal cleaning performance. If the brush roll does not spin or makes unusual noises, re-check the installation.

5. MAINTENANCE AND REPLACEMENT SCHEDULE

To maintain optimal performance of your vacuum cleaner, it is recommended to replace the drive belt every 3 to 9 months. Regular replacement prevents loss of suction and ensures the brush roll continues to agitate carpets effectively.



we suggest to replace vacuum belt every 3 to 9 months to ensure optimum performance of your vacuum cleaner.

*The display of the vacuum cleaners is only to illustrate the compatibility of the belts.

Image 5.1: Recommended Belt Replacement. This image shows a vacuum in operation, with an overlay suggesting that the vacuum belt should be replaced every 3 to 9 months to ensure peak performance.

6. TROUBLESHOOTING

- **Brush Roll Not Spinning:**
 - Ensure the vacuum is unplugged. Check if the belt is broken, stretched, or dislodged from the motor shaft or brush roll. Replace if broken or excessively stretched. Re-seat if dislodged.
- **Loss of Suction (Brush Roll Related):**
 - A worn or stretched belt can cause the brush roll to spin slowly or not at all, leading to reduced cleaning effectiveness. Consider replacing the belt if it appears loose or if the brush roll performance is diminished.
- **Unusual Noises from Brush Roll Area:**
 - Unplug the vacuum. Inspect the belt for any damage or fraying. Also, check the brush roll for hair, debris, or other obstructions that might be interfering with its rotation or the belt's movement.

7. SPECIFICATIONS

Product Specifications

Feature	Detail
Brand	JEDELEOS
Material	Rubber
Belt Style	Flat Non-stretch Belt
Color	Black
Package Dimensions	4.45 x 2.91 x 0.51 inches
Item Weight	0.78 ounces



Image 7.1: High-Quality Replacement Belt. This close-up image showcases the texture and material of the flat non-stretch

replacement belt, emphasizing its construction.

8. WHAT'S IN THE BOX

Each package contains:

- 2 x JEDELEOS Replacement Flat Non-Stretch Belts for Hoover WindTunnel 3 Pro Pet Upright Vacuums

PACKAGE LIST



Image 8.1: Package Contents. This image displays two replacement belts, indicating the quantity included in each package.

9. SUPPORT AND WARRANTY

For any questions regarding the installation, compatibility, or performance of your JEDELEOS replacement belts, please refer to the product listing or contact the manufacturer directly through the retailer's platform. Specific warranty information may be available from the seller at the point of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question