

ONOAYO ONO1

ONOAYO 5G WiFi Projector User Manual

Model: ONO1
Brand: ONOAYO

1. INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your ONOAYO 5G WiFi Projector. Designed for both home cinema and gaming, this portable projector delivers a full HD native 1920x1080P resolution with support for 4K content. Its integrated 5G WiFi and Bluetooth capabilities ensure seamless connectivity, while features like digital keystone correction enhance your viewing experience. Please read this manual thoroughly before using the projector to ensure optimal performance and longevity.

2. WHAT'S IN THE BOX

Upon unboxing, please verify that all the following components are included:

- ONOAYO 5G WiFi Projector (Model: ONO1)
- Remote Control
- Power Cable
- HDMI Cable
- AV Cable
- User Manual (this document)

3. SETUP GUIDE

3.1. Placement

Select a flat, stable surface for the projector. Ensure adequate ventilation around the device. For optimal image size and clarity, position the projector at an appropriate distance from your projection surface (wall or screen). The projector supports a visible screen diagonal of up to 300 inches (762 cm).



Figure 1: ONOAYO 5G WiFi Projector and accessories.

3.2. Power Connection

Connect the power cable to the projector's power input and then plug the other end into a standard electrical outlet.

3.3. Initial Power On

Press the power button on the projector or the remote control to turn on the device. The indicator light will illuminate.

4. OPERATING INSTRUCTIONS

4.1. Basic Navigation

Use the navigation buttons on the remote control or the projector's top panel to navigate through the on-screen menus. The "OK" button confirms selections, and the "Return" button goes back to the previous screen.

4.2. Connectivity Options

The ONOAYO projector offers multiple connectivity options:

- **Wi-Fi (5G/2.4G):** Navigate to the Wi-Fi settings menu, select your network, and enter the password. This enables wireless screen mirroring from compatible smartphones and tablets.
- **Bluetooth:** Access the Bluetooth settings to pair with external Bluetooth speakers or headphones for enhanced audio.
- **HDMI:** Connect devices such as laptops, gaming consoles, or Blu-ray players using an HDMI cable.
- **USB:** Insert a USB drive to play media files directly from the storage.
- **AV:** Use the AV port for older devices with composite video output.



Figure 2: Projector demonstrating 5G WiFi wireless connection for lag-free streaming.

4.3. Digital Keystone Correction

If the projected image appears trapezoidal, use the digital keystone correction feature to adjust it to a perfect rectangular shape. This projector supports $\pm 50^\circ$ 4P/4D keystone correction. Access this setting through the projector's menu and follow the on-screen prompts.

4.4. Focus Adjustment

Rotate the focus ring on the projector lens until the image appears sharp and clear on the screen.

5. MAINTENANCE

5.1. Cleaning the Lens

Gently wipe the projector lens with a soft, lint-free cloth specifically designed for optical surfaces. Avoid using abrasive cleaners or excessive force, as this can scratch the lens.

5.2. Cleaning the Exterior

Use a soft, dry cloth to clean the exterior surfaces of the projector. Do not use liquid or aerosol cleaners directly on the unit.

5.3. Ventilation

Ensure that the ventilation vents on the projector are clear of dust and obstructions to prevent overheating. Regular cleaning with a soft brush or compressed air can help maintain proper airflow.

5.4. Storage

When not in use for extended periods, store the projector in a cool, dry place, away from direct sunlight and extreme temperatures. It is recommended to use the original packaging or a protective carrying case to prevent dust accumulation and physical damage.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
No image displayed	Power cable disconnected; incorrect input source selected; lens cap on.	Check power connection; select correct input source (HDMI, USB, AV); remove lens cap.
Image is blurry	Out of focus; incorrect projection distance.	Adjust the focus ring; reposition the projector closer or further from the screen.
Image is trapezoidal	Projector not perpendicular to screen.	Use digital keystone correction to adjust the image.
No sound	Volume too low; external audio device not connected or selected; source device muted.	Increase projector volume; check external audio connections/settings; unmute source device.
Wi-Fi connection issues	Incorrect password; out of range; network interference.	Verify Wi-Fi password; move projector closer to router; try a different Wi-Fi channel.

7. SPECIFICATIONS

Feature	Detail
Brand	ONOAYO
Model Number	ONO1
Native Resolution	1920 x 1080P (Full HD)
Supported Resolution	Up to 4K
Connectivity Technology	Wi-Fi (5G/2.4G), AV, USB, HDMI, IR, Bluetooth
Keystone Correction	Digital ±50° 4P/4D
Speaker Type	Built-In Stereo
Item Weight	5.96 pounds (approx. 2.7 kg)
Product Dimensions	5.51 x 14.17 x 10.24 inches
Recommended Uses	Home Cinema, Gaming

8. WARRANTY AND SUPPORT

The ONOAYO 5G WiFi Projector comes with a standard manufacturer's warranty. For detailed warranty terms and conditions, please refer to the warranty card included in your product packaging or visit the official ONOAYO website. For technical support, troubleshooting assistance, or any product-related inquiries, please contact ONOAYO customer service through the contact information provided on the official website or your purchase platform. Please retain your proof of purchase for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question