

[Manuals.plus](#) /

> [HYUNDAI](#) /

> HYUNDAI 10.1" Android Tablet User Manual

HYUNDAI HT10LC1MSGLTM01


HYUNDAI 10.1" Android Tablet User Manual

Model: HT10LC1MSGLTM01

Brand: HYUNDAI

1. INTRODUCTION

Welcome to the user manual for your new HYUNDAI 10.1" Android Tablet. This guide provides essential information to help you set up, operate, maintain, and troubleshoot your device. Please read this manual thoroughly to ensure optimal performance and longevity of your tablet.






Image: Front view of the HYUNDAI 10.1" Android Tablet, showcasing its display with a vibrant wallpaper.

2. PRODUCT OVERVIEW

2.1 Package Contents

Ensure all items are present in the package:

- HYUNDAI 10.1" Android Tablet
- USB Charging Cable
- Power Adapter
- User Manual (this document)
- (Optional) Screen Protector
- (Optional) Earbuds
- (Optional) Stylus Pen

2.2 Device Layout

Familiarize yourself with the physical components and controls of your tablet.



HYUNDAI™

(((HYTAB)))

**HYTAB PRO
HYUNDAI
10.1 INCHES**



Image: Front and rear views of the tablet, highlighting its sleek design and camera placement.

1. **Front Camera:** For video calls and selfies.
2. **Display:** 10.1" HD IPS touchscreen.
3. **Power Button:** Press and hold to power on/off, short press to sleep/wake.
4. **Volume Buttons:** Adjust audio volume.
5. **USB-C Port:** For charging and data transfer.
6. **Headphone Jack:** 3.5mm audio output.
7. **Speaker:** Audio output.
8. **Rear Camera:** For taking photos and videos (8 MP).
9. **SIM Card Slot:** For LTE data connectivity (data-only).
10. **MicroSD Card Slot:** For expandable storage.

3. SETUP

3.1 Charging the Tablet

Before first use, fully charge the tablet. Connect the USB charging cable to the tablet's USB-C port and the power adapter, then plug the adapter into a wall outlet. The battery indicator will show charging status.

3.2 Powering On/Off

- **To Power On:** Press and hold the Power button until the HYUNDAI logo appears.
- **To Power Off:** Press and hold the Power button until the power options appear, then select "Power off".
- **Sleep/Wake:** Short press the Power button to put the tablet to sleep or wake it up.

3.3 Initial Setup Wizard

Upon first power-on, the Android setup wizard will guide you through:

1. Language selection.
2. Wi-Fi network connection.
3. Google account sign-in or creation.
4. Date and time settings.
5. Security settings (PIN, pattern, password).

3.4 Inserting SIM and MicroSD Cards

The tablet supports a data-only LTE SIM card and a MicroSD card for expanded storage.

1. Locate the SIM/MicroSD card tray on the side of the tablet.
2. Use the provided SIM ejector tool to open the tray.
3. Carefully place the SIM card and/or MicroSD card into their respective slots on the tray, ensuring correct orientation.
4. Gently push the tray back into the tablet until it clicks into place.

4. OPERATING INSTRUCTIONS

4.1 Basic Navigation

- **Touch:** Tap an icon to open an app or select an item.
- **Touch & Hold:** Press and hold an item to access more options or move it.
- **Swipe:** Drag your finger across the screen to scroll or navigate between screens.
- **Pinch-to-Zoom:** Use two fingers to zoom in or out on photos, maps, or web pages.



Image: The tablet's home screen showing various application icons, demonstrating its user interface.

4.2 Connecting to Wi-Fi

1. Go to **Settings > Network & internet > Wi-Fi**.
2. Toggle **Wi-Fi On**.
3. Select your desired network from the list and enter the password if prompted.

4.3 Using LTE Data

If you have inserted a data-only SIM card, ensure mobile data is enabled:

1. Go to **Settings > Network & internet > Mobile network**.
2. Ensure **Mobile data** is toggled **On**.

4.4 Managing Apps

- **Install Apps:** Open the Google Play Store app, search for apps, and tap "Install".
- **Uninstall Apps:** Touch and hold an app icon on the home screen, then drag it to "Uninstall" or go to **Settings > Apps > select app > Uninstall**.
- **Close Apps:** Swipe up from the bottom of the screen and hold to view recent apps, then swipe an app card up to close it.

4.5 Camera Usage

Open the Camera app to take photos or record videos. Tap the shutter button to capture an image or start/stop video recording. Switch between front and rear cameras using the camera switch icon.

5. MAINTENANCE

5.1 Cleaning the Tablet

Use a soft, lint-free cloth to clean the screen and body of the tablet. Do not use abrasive cleaners, alcohol, or solvents, as these can damage the surface. Avoid getting moisture into openings.

5.2 Battery Care

- Avoid extreme temperatures, which can degrade battery life.
- Do not let the battery completely drain frequently.

- Use only the provided charger or a certified compatible charger.

5.3 Software Updates

Periodically check for system updates to ensure your tablet has the latest features and security patches. Go to **Settings > System > System update**.



Image: The tablet securely placed within a protective case, demonstrating proper care and handling.

6. TROUBLESHOOTING

Problem	Possible Solution
Tablet does not turn on.	Ensure the tablet is charged. Connect to the charger and wait a few minutes before attempting to power on again.
Screen is unresponsive.	Restart the tablet by pressing and holding the Power button for about 10-15 seconds until it reboots.
Cannot connect to Wi-Fi.	Check if Wi-Fi is enabled in Settings. Restart your Wi-Fi router. Ensure you are entering the correct password.
Apps are crashing or running slowly.	Close background apps. Clear app cache (Settings > Apps > select app > Storage & cache > Clear cache). Restart the tablet.

Problem	Possible Solution
No mobile data connection.	Ensure SIM card is properly inserted. Check mobile data settings are enabled. Verify your data plan is active with your carrier.

7. SPECIFICATIONS

Key technical specifications for the HYUNDAI 10.1" Android Tablet (Model HT10LC1MSGTLM01):

- **Display:** 10.1" HD IPS (1280 x 800 pixels)
- **Operating System:** Android 13
- **Processor:** MediaTek Chipset
- **RAM:** 4GB
- **Internal Storage:** 64GB (expandable via MicroSD)
- **Cameras:** Rear 8 MP, Front (resolution not specified, but implied from product images)
- **Battery:** 6000mAh Lithium Polymer
- **Connectivity:** LTE (Data-only), Wi-Fi (802.11g), Bluetooth
- **Dimensions:** 5.98 x 0.33 x 9.65 inches
- **Weight:** 3.04 pounds
- **Color:** Space Grey




Image: Visual representation of key features including Android 13, battery life, storage, and accessories.

8. WARRANTY AND SUPPORT

8.1 Warranty Information

Your HYUNDAI 10.1" Android Tablet comes with a limited manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including coverage duration and limitations. Keep your proof of purchase for warranty claims.

8.2 Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact HYUNDAI customer support. You can find contact information on the official HYUNDAI Technology website or through the retailer where you purchased the product.

Visit the official HYUNDAI Technology store for more information and product support:[HYUNDAI Technology Store](#)

© 2024 HYUNDAI. All rights reserved.