Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SanDisk SDSDXDK-064G-GN4IN

SanDisk Extreme PRO SDXC UHS-II Memory Card User Manual

Brand: SanDisk | Model: SDSDXDK-064G-GN4IN

Product Overview

The SanDisk Extreme PRO SDXC UHS-II Memory Card is engineered for professional and advanced photographers and videographers. It provides exceptional speed and reliability for capturing high-resolution photos and cinema-quality 8K, 4K, and Full HD video. This manual provides essential information for setup, operation, maintenance, and troubleshooting of your memory card.



This image displays the SanDisk Extreme PRO SDXC UHS-II Memory Card, highlighting its key specifications and design.

Setup and Compatibility

The SanDisk Extreme PRO SDXC UHS-II Memory Card is designed for use with compatible devices such as digital

cameras, camcorders, and card readers that support SDXC and UHS-II standards. For optimal performance, ensure your device is UHS-II compatible.

Inserting the Memory Card

1. Locate the SD card slot on your device (camera, camcorder, or card reader).
2. Ensure the memory card is oriented correctly, with the gold contacts facing into the slot.
3. Gently insert the card until it clicks into place. Do not force the card.

Formatting the Memory Card

It is recommended to format the memory card within your device before first use and periodically thereafter. Formatting erases all data on the card and prepares it for optimal performance with your specific device.

1. Access the menu settings on your camera or device.
2. Navigate to the 'Format' or 'Initialize' option for the memory card.
3. Confirm the formatting process. All data will be erased.



This image shows the side profile of the SanDisk Extreme PRO SDXC UHS-II Memory Card, including the write-protect lock switch.

Operation

Recording Data (Write Speeds)

This card features super-fast write speeds of up to 260MB/s*, enabling rapid buffer clearing for continuous burst mode shooting and cinema-quality video recording. This is crucial for capturing fast-paced action and high-resolution video without interruption.

- **Continuous Burst Mode:** Ideal for sports, wildlife, and other fast-moving subjects.
- **Video Recording:** Supports sustained V90 video speeds and UHS Speed Class 3 (U3) for 8K, 4K, and Full HD video.

Transferring Data (Read Speeds)

Achieve maximum post-production workflow efficiency with extreme transfer speeds up to 300MB/s*. For best results, use a compatible UHS-II card reader, such as the SanDisk Extreme PRO SD UHS-II USB-C Reader (sold separately).

Video Capabilities

The SanDisk Extreme PRO SDXC UHS-II Memory Card is designed to handle demanding video formats:

- **8K Video:** Capture ultra-high-definition footage with incredible detail.
- **4K Video:** Record professional-grade 4K video smoothly.
- **Full HD Video:** Excellent performance for standard high-definition video.



This image illustrates the card's capability to support professional performance in various shooting conditions, emphasizing its speed for capturing dynamic moments.

Care and Maintenance

The SanDisk Extreme PRO SDXC UHS-II Memory Card is built for durability and designed to withstand challenging environments. To ensure longevity and data integrity, follow these guidelines:

- **Shockproof:** Avoid dropping the card from significant heights.
- **Temperature-Proof:** Operates reliably in extreme temperatures. Store within recommended temperature ranges.
- **Waterproof:** Can withstand immersion in water for a limited time. Ensure the card is dry before inserting into devices.
- **X-ray-Proof:** Safe from airport X-ray scanners.
- **Cleanliness:** Keep the gold contacts clean and free from dust or debris. Use a soft, dry cloth if cleaning is necessary.
- **Write-Protect Switch:** Utilize the write-protect lock switch on the side of the card to prevent accidental data deletion or overwriting. Slide the switch down to lock (read-only) and up to unlock (read/write).

SanDisk

READ	WRITE
UP TO 300 MB/s*	UP TO 260 MB/s*

- WATER PROOF[3]
- TEMPERATURE PROOF[3]
- SHOCK PROOF[3]
- X-RAY PROOF[3]

SanDisk Extreme PRO® | SDXC™ UHS-II Card

English

- Shot speeds up to 260MB/s* and transfer speeds up to 300MB/s*
- UHS Speed Class 3 (U3) allows you to record 4K and Full HD (1080p) video at sustained video capture rate of 30MB/s. Video speed class V90 allows you to record 8K (7680x4320) video at a sustained video capture rate of 90MB/s.[1,2]

* Up to 300MB/s read speed. Write speed up to 260MB/s. Based on internal testing; performance will vary based on host device. Full performance requires SanDisk UHS-II reader. 1MB = 1,000,000 bytes.
** 1GB = 1,000,000,000 bytes. Actual user storage less.
1 Full HD (1920x1080), 4K video (4096x2160) and 8K video (7680x4320) support may vary based upon host device, file attributes and other factors. See www.sandisk.com/HD.
2 UHS Speed Class 3 (U3) and Video Speed Class V90 designate performance options designed to support real-time video recording with UHS-enabled host devices. See www.sdcard.org/consumers/speed for additional details.
3 See www.sandisk.com/proof.

Español

- Velocidad de los disparos de hasta 260MB/s* y velocidad de transferencia de hasta 300MB/s*
- La velocidad UHS clase 3 (U3) le permite grabar videos en 4K y Full HD (1080p) a una tasa de captura de video sostenida de 30 MB/s. La velocidad de video clase V90 le permite grabar videos en 8K (7680x4320) a una tasa de captura de video sostenida de 90 MB/s.[1,2]

* Velocidad de lectura de hasta 300MB/s. Velocidad de escritura de hasta 260MB/s. Según pruebas internas; el rendimiento variará según del dispositivo anfitrión. El rendimiento máximo requiere un lector Sandisk UHS-II. 1MB = 1,000,000 bytes.
** 1GB = 1,000,000,000 bytes. El almacenamiento verdadero que el usuario puede utilizar es menor.
1 El soporte de video Full HD (1920x1080), 4K (4096x2160) y video 8K (7680x4320) puede variar dependiendo del dispositivo anfitrión, los atributos del archivo y otros factores. Visite www.sandisk.com/HD.
2 La velocidad UHS clase 3 (U3) y la velocidad de video clase V90 designan opciones del rendimiento diseñadas para permitir la grabación de video en tiempo real con dispositivos habilitados para UHS. Visite www.sdcard.org/consumers/speed para más detalles.
3 Visite www.sandisk.com/proof.

SanDisk, the SanDisk logo, RescuePRO and SanDisk Extreme PRO are registered trademarks or trademarks of Western Digital Corporation or its affiliates in the US and/or other countries. The SDXC mark and logo are trademarks of SD-3C, LLC. All other marks are the property of their respective owners.

LIFETIME LIMITED WARRANTY

Warranty • Guide | Garantía • Guía
www.sandisk.com/wug

Includes RescuePRO® DELUXE
2-YEAR SOFTWARE DOWNLOAD COUPON
Terms and Conditions apply. See inside for details.

SDSDXDK-064G-ANCIN
6 19659 18659 3
P001-000057-064G

Made in Taiwan
Fabricado en Taiwán

www.sandisk.com

Western Digital Technologies, Inc. • 951 SanDisk Dr., Milpitas, CA 95035, U.S.A.
© 2021 Western Digital Corporation or its affiliates. All rights reserved.

Western Digital Technologies, Inc. is the seller of record and licensee in the Americas of SanDisk® products.

This image from the product packaging highlights the robust durability features of the SanDisk Extreme PRO SDXC UHS-II Memory Card, including its resistance to water, temperature extremes, shock, and X-rays.

Troubleshooting

Card Not Recognized

- Ensure the card is fully inserted into the device slot.
- Check if the write-protect switch is in the unlocked position.
- Try the card in another compatible device or card reader to rule out a device issue.
- If the card was recently formatted, ensure the formatting process completed successfully.

Slow Performance

- Verify that your camera or card reader supports UHS-II speeds. Older devices or UHS-I readers will limit the card's performance.
- Ensure your device's firmware is up to date.
- Avoid filling the card to its absolute maximum capacity, as this can sometimes affect performance.

Data Loss or Corruption

- Immediately stop using the card if you suspect data loss.
- The card includes a download offer for RescuePRO Deluxe software, which can help recover accidentally deleted files. Refer to the packaging or SanDisk website for details.
- If the card is physically damaged or consistently fails, it may need to be replaced under warranty.

Technical Specifications

Feature	Detail
Model Name	SanDisk Extreme PRO SD UHS-II Card
Flash Memory Type	SDXC
Memory Storage Capacity	64 GB
Read Speed	Up to 300 MB/s
Write Speed	Up to 260 MB/s
Video Speed Class	V90
UHS Speed Class	U3
SD Association Speed Class	Class 10
Special Features	Shockproof, Temperature-Proof, Waterproof, X-ray-Proof
Dimensions (LxWxH)	1.26" x 0.94" x 0.09"
Item Weight	0.071 ounces (2 grams)
Manufacturer	Western Digital Technologies, Inc.
UPC	619659186616

Warranty and Support

Warranty Information

The SanDisk Extreme PRO SDXC UHS-II Memory Card comes with a Limited Lifetime Warranty. Please retain your proof of purchase for warranty claims. For full warranty terms and conditions, refer to the official SanDisk website.

Product Support

For additional support, frequently asked questions, and driver downloads, please visit the official SanDisk support page: www.sandisk.com/wug

Data Recovery Software

A download offer for RescuePRO Deluxe data recovery software is included with your purchase. This software can assist in recovering accidentally deleted images and videos. Instructions for download and activation are typically found on the product packaging or via the SanDisk support website.

© 2025 SanDisk. All rights reserved. SanDisk and SanDisk Extreme PRO are trademarks of Western Digital Corporation or its affiliates.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08YFD8QDT

More documents and user manuals: **https://manuals.plus/**