

[Manuals.plus](#) /

› [Falk](#) /

› Falk Country Farmer Pedal Tractor with Trailer - Model 2057L Instruction Manual

Falk 2057L

Falk Country Farmer Pedal Tractor with Trailer - Model 2057L Instruction Manual

1. PRODUCT OVERVIEW

The Falk Country Farmer Pedal Tractor with Trailer, Model 2057L, is designed for young children aged 2 to 5 years. This robust pedal-powered toy encourages outdoor play and helps develop autonomy and imagination. It features a functional trailer for transporting small items, a directional steering wheel with a horn, and a customizable license plate for a personalized touch. Constructed with durability in mind, this tractor is made in France, utilizing at least 50% recycled plastic.



Image 1.1: The Falk Country Farmer Pedal Tractor with Trailer, showcasing its green design and functional components.

2. SAFETY GUIDELINES

To ensure a safe play experience, please adhere to the following guidelines:

- **Adult Supervision Required:** Always ensure an adult supervises children during use.
- **Age Recommendation:** This product is suitable for children aged 2 to 5 years (24 months and up).
- **Weight Limit:** Do not exceed the maximum weight capacity of 35 kilograms (77 pounds).
- **Safe Play Area:** Use the tractor in safe, open areas away from roads, steep inclines, stairs, swimming pools, and other hazards.
- **Footwear:** Children should wear appropriate footwear while operating the tractor.
- **Inspection:** Before each use, check that all parts are securely fastened and in good working condition.

3. INITIAL SETUP

While the Falk Country Farmer Pedal Tractor is largely pre-assembled, some minor setup may be required upon arrival to ensure optimal functionality. Please follow these general steps:

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future reference or disposal.
2. **Steering Wheel Attachment:** If the steering wheel is not already attached, align it with the steering column and secure it according to the specific instructions provided in the product's packaging. Ensure it is firmly in place and turns freely.
3. **Trailer Connection:** Attach the trailer to the rear hitch of the tractor. Verify that the connection is secure and the trailer can pivot freely.
4. **Final Check:** Before first use, inspect all bolts, nuts, and connections to ensure they are tight and secure. Confirm that the pedals, steering, and wheels operate smoothly.



Image 3.1: The pedal tractor positioned in a grassy area, ready for use after initial setup.

4. OPERATING YOUR PEDAL TRACTOR

Operating the Falk Country Farmer Pedal Tractor is intuitive for young children:

- **Getting Started:** Help the child sit comfortably on the seat, ensuring their feet can reach the pedals.
- **Pedaling:** Instruct the child to push the pedals in a circular motion to move the tractor forward. The pedal mechanism is designed for easy use by small children.
- **Steering:** The steering wheel controls the front wheels. Guide the child to turn the wheel left or right to change direction.
- **Using the Horn:** The steering wheel is equipped with a horn. Children can press it to make a sound.
- **Trailer Use:** The attached trailer can be used to carry lightweight items such as toys, sand, or leaves. Ensure the load is not too heavy or unbalanced to prevent tipping.



Image 4.1: Children demonstrating the use of pedal tractors, highlighting the ease of operation.

5. CARE AND MAINTENANCE

Proper care and maintenance will extend the life of your Falk Country Farmer Pedal Tractor:

- **Cleaning:** Clean the tractor and trailer regularly with a damp cloth and mild soap. Avoid harsh chemicals or abrasive cleaners. Rinse thoroughly and dry.
- **Storage:** Store the tractor in a dry, sheltered area when not in use to protect it from extreme weather conditions, which can prolong its lifespan and maintain its appearance.
- **Inspection:** Periodically check all moving parts, such as wheels, pedals, and steering components, for wear or damage. Ensure all fasteners remain tight.

- **Lubrication:** If any moving parts become stiff, a small amount of silicone-based lubricant can be applied, avoiding contact with plastic surfaces that could be damaged.

6. TROUBLESHOOTING

Here are some common issues and basic troubleshooting steps:

- **Pedals Not Turning:**
 - Check for any obstructions around the pedals or chain mechanism.
 - Ensure the pedals are securely attached to the axle.
- **Steering Difficulty:**
 - Verify that the steering wheel is firmly attached and not loose.
 - Inspect the front axle and steering linkage for any damage or obstructions.
- **Trailer Detaches Easily:**
 - Ensure the trailer hitch is correctly engaged with the tractor's attachment point.
 - Check for any damage to the hitch mechanism on both the tractor and trailer.

If issues persist after attempting these steps, please contact customer support.

7. PRODUCT SPECIFICATIONS

Feature	Specification
Model Number	2057L
Brand	Falk
Recommended Age	24 months and up (2 to 5 years)
Maximum Weight Capacity	35 kg (77 lbs)
Product Dimensions (L x W x H)	123 x 42 x 53 cm (48.4 x 16.5 x 20.9 inches)
Product Weight	5.9 kg (13 lbs)
Material	Plastic (at least 50% recycled)
Color	Green
Features	Directional steering wheel, horn, detachable trailer, customizable license plate

8. WARRANTY AND CUSTOMER SUPPORT

For information regarding product warranty, spare parts, or any other customer support inquiries, please refer to the contact details provided with your purchase documentation or visit the official Falk website. Please have your product model number (2057L) and purchase date available when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question