

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Hover-1](#) /

> [Hover-1 Nano Kick Scooter Instruction Manual](#)

## Hover-1 Nano- Folding Kick Scooter

# Hover-1 Nano Kick Scooter Instruction Manual

Model: Nano- Folding Kick Scooter

### IMPORTANT SAFETY INFORMATION

---

Before operating the Hover-1 Nano Kick Scooter, please read and understand all safety instructions. Failure to follow these instructions may result in serious injury.

- **Age and Weight Limit:** This scooter is designed for children aged 5 years and older, with a maximum weight limit of 110 lbs (50 kg).
- **Wear Safety Gear:** Always wear appropriate safety gear, including a helmet, knee pads, and elbow pads, when riding the scooter.
- **Supervision:** Children should always be supervised by an adult while riding.
- **Riding Conditions:** Ride on smooth, paved surfaces away from traffic. Avoid riding on uneven terrain, loose gravel, or wet surfaces.
- **Visibility:** The scooter features multi-color LED lights on the wheels, stem, and deck to enhance visibility, especially in low-light conditions. However, always be aware of your surroundings.
- **Braking:** The scooter is equipped with a rear braking system. Practice braking in a safe area before riding at higher speeds.
- **Avoid Stunts:** Do not attempt stunts, jumps, or aggressive riding, as this can lead to loss of control and injury.



Image: A child safely riding the Hover-1 Nano Kick Scooter, demonstrating the importance of safety gear.

## PRODUCT OVERVIEW AND COMPONENTS

---

The Hover-1 Nano Kick Scooter is designed for a fun and safe riding experience. Familiarize yourself with its main components:

- **Adjustable Handlebar:** Allows for height customization to suit different riders.
- **Soft Grip Handles:** Provide comfort and secure grip during use.
- **Lean-to-Steer Axle:** Enables intuitive steering by leaning.
- **Solid PU Tires:** Durable and provide a smooth ride.
- **Multi-Color LED Lights:** Integrated into the wheels, stem, and deck for enhanced visibility and style.
- **Folding Design:** For easy storage and portability.
- **Rear Brake:** For controlled stopping.

Please Contact  
Hover-1 for  
Troubleshooting



# ADJUSTABLE

## Handles

**PERFECT FOR GROWING CHILDREN**

Adjustable for riders of any age.

Image: Detail of the scooter's soft, comfortable handles for improved grip.

STAY SAFE  
& PAIR YOUR NEW  
E-SCOOTER WITH A  
*HOVER-1* HELMET.



MORE ACCESSORIES ON SALE:



Image: The scooter showcasing its multi-colored LED lights on the wheels, stem, and deck.

## SETUP AND ASSEMBLY

The Hover-1 Nano Kick Scooter requires minimal assembly. Follow these steps to prepare your scooter for use:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Handlebar Installation:** Insert the handlebar stem into the main scooter body until it clicks securely into place. Ensure it is fully engaged.
3. **Adjust Handlebar Height:**
  - Locate the clamp on the stem of the scooter.
  - Open the clamp and adjust the handlebar to the desired height, ensuring it is comfortable for the rider.
  - Close the clamp firmly to secure the handlebar in position. Ensure the handlebar is stable and does not wobble.
4. **Battery Installation (for LED lights):**
  - The scooter's LED lights require 3 AA batteries (not included).

- Locate the battery compartment, typically on the underside of the deck or within the stem.
- Open the compartment, insert the batteries according to the polarity indicators (+/-), and securely close the cover.



Image: The adjustable handlebar mechanism, allowing customization for rider height.

## OPERATING INSTRUCTIONS

---

Operating the Hover-1 Nano Kick Scooter is straightforward. Follow these guidelines for a safe and enjoyable ride:

1. **Starting:** Place one foot firmly on the scooter deck. Use the other foot to push off the ground to gain momentum.
2. **Steering (Lean-to-Steer):** The scooter uses a lean-to-steer mechanism. To turn, gently lean your body in the desired direction. The front wheels will pivot accordingly.
3. **Braking:** To slow down or stop, apply pressure to the rear brake located above the rear wheel with your foot. Apply gradual pressure for smooth stops.
4. **Folding for Storage:**
  - Locate the folding mechanism near the base of the handlebar stem.

- Follow the instructions on the scooter to release the locking mechanism and fold the handlebar down towards the deck.
- Ensure the scooter is securely folded before carrying or storing.



Image: The scooter in its compact, folded design, highlighting its portability and ease of storage.

## MAINTENANCE

---

Regular maintenance ensures the longevity and safe operation of your Hover-1 Nano Kick Scooter:

- **Cleaning:** Wipe the scooter with a damp cloth after use. Avoid using harsh chemicals or abrasive cleaners. Do not hose down the scooter.
- **Wheel Inspection:** Periodically check the solid PU tires for wear and tear. Ensure they are free from debris.
- **Handlebar and Connections:** Regularly check that the handlebar is securely fastened and that all clamps and bolts are tight.
- **Battery Replacement:** When the LED lights dim or stop working, replace the 3 AA batteries in the designated compartment. Ensure correct polarity.
- **Storage:** Store the scooter in a dry, cool place away from direct sunlight and moisture. Use the folding feature for compact storage.

## TROUBLESHOOTING

---

If you encounter issues with your Hover-1 Nano Kick Scooter, refer to the following common solutions:

- **LED Lights Not Working:**
  - Check if the 3 AA batteries are correctly installed with the proper polarity.
  - Replace old or depleted batteries with new ones.
- **Handlebar Wobbles:**
  - Ensure the handlebar stem is fully inserted and the clamp is securely tightened.
  - Inspect for any loose screws or connections in the handlebar assembly.
- **Scooter Not Rolling Smoothly:**
  - Check wheels for debris or obstructions.
  - Ensure wheel axles are not overly tight or loose.

For further assistance, please contact Hover-1 customer support.

## SPECIFICATIONS

---

<b>Brand</b>	Hover-1
<b>Model Name</b>	Nano- Folding Kick Scooter
<b>Age Range (Description)</b>	Youth (5+ Years Old)
<b>Weight Limit</b>	110 Pounds (50 kg)
<b>Item Weight</b>	3.1 Pounds (1.4 kg)
<b>Number of Wheels</b>	2
<b>Wheel Material</b>	Polyurethane (Solid PU)
<b>Frame Material</b>	Aluminum, Plastic
<b>Handlebar Type</b>	Adjustable
<b>Wheel Size</b>	3 Inches
<b>Brake Style</b>	Rear Braking
<b>Special Feature</b>	Lightweight, LED Lights
<b>UPC</b>	888255211835

## WARRANTY AND SUPPORT

---

**Warranty:** The Hover-1 Nano Kick Scooter comes with a 90-day warranty from the date of purchase. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for

warranty claims.

**Customer Support:** For product support, troubleshooting assistance, or warranty inquiries, please visit the official Hover-1 Brand Store or contact their customer service department. You can find more information and contact details on the [Hover-1 Brand Store on Amazon](#).