

[Manuals.plus](#) /

> [FASDUNT](#) /

> Handheld Vacuum, 8000Pa Wet Dry Hand Vac with LCD Display & Charging Dock, Lightweight Portable Hand Vacuum Cordless Rechargeable, for Home, Office and Car Cleaning

FASDUNT HV1

FASDUNT Handheld Vacuum User Manual

Model: HV1

Brand: FASDUNT

1. INTRODUCTION

Thank you for choosing the FASDUNT Handheld Vacuum. This powerful and versatile cordless vacuum is designed to provide efficient cleaning for your home, office, and car. Featuring an 8000Pa ultra-strong suction, wet and dry capabilities, a 3-layer filtration system with HEPA filters, rapid charging, and an innovative LCD display, it offers a smarter and more convenient cleaning experience.

2. PACKAGE CONTENTS

Please ensure all items are present in your package:

- 1 × Handheld Vacuum Cordless
- 1 × Crevice Tool
- 1 × Brush Tool
- 1 × Liquid Nozzle
- 2 × HEPA Filters (one pre-installed, one extra)
- 1 × Charging Base
- 1 × Tool Storage Stand
- 1 × Cleaning Brush
- 1 × User Manual

Brush Nozzle

Clean the pet hair from sofa or carpet



Liquid Nozzle

Suck the spilled liquid



Crevice Nozzle

Clean the debris from any corners



Figure 1: All components included in the FASDUNT Handheld Vacuum package.

3. PRODUCT FEATURES

3.1. 8000Pa Ultra-Strong Suction

Equipped with a 100W power motor, the FASDUNT handheld vacuum delivers over 8000Pa of suction, effectively picking up dirt, crumbs, and pet hair from various surfaces. It features both ECO and MAX modes to adapt to different

Powerful Suction with 2 Modes for Deeper Clean



Figure 2: The vacuum in action, showcasing its powerful suction in both ECO and MAX modes.

3.2. 3-layer Filtration with 2 HEPA Filters

The vacuum utilizes an advanced 3-layer filtration system, including an air outlet sponge, filter holder, and a washable HEPA filter. This system captures 99.99% of microparticles, protecting the motor and preventing secondary air pollution. An additional HEPA filter is provided for convenience.


High Effective Filtration System



Figure 3: Exploded view of the vacuum's multi-layer filtration system, highlighting the HEPA filters.

3.3. Portable Wet Dry Handheld Vacuum

Designed for both wet and dry use, this vacuum comes with three different nozzles (crevice, brush, and liquid) to effectively clean dust, pet hair, and spilled liquids. Note: The liquid capacity of the dust cup should not exceed 100ml.

FASDUNT**Others****VS**

Why Choose FASDUNT?

8kPa with 2 modes	Suction	5kPa with single mode
2-3H	Charging time	5-6H
LCD screen	Battery reminder	No display
Storage stand	Accessories Storage	Messy
20-30min	Running time	20min

Figure 4: The three specialized nozzles for versatile cleaning tasks.

3.4. 2-3h Super Rapid Charging

The vacuum is equipped with a 4 x 2200mAh rechargeable and detachable battery pack, utilizing fast-charge technology to achieve a full charge in just 2-3 hours. This provides 20-30 minutes of continuous running time, and the battery pack can be charged independently.



Smart Large LCD Display

Figure 5: The vacuum charging on its base, highlighting the rapid charging feature.

3.5. Innovative Smart LCD Display

A thoughtful LCD display shows the battery power and selected mode (ECO/MAX) in real-time during use or charging, offering a smarter and more convenient cleaning experience. The included 2-in-1 storage and charging stand helps keep your device organized.

2-3H Portable Fast Charge



Figure 6: The LCD display providing real-time information on battery and mode settings.

Your browser does not support the video tag.

Video 1: Official product video demonstrating the FASDUNT Handheld Vacuum with LCD Display and its features.

4. SETUP AND CHARGING

4.1. Initial Charge

Before first use, fully charge the vacuum. Place the handheld vacuum onto the charging base. The LCD display will show the battery percentage increasing as it charges. A full charge typically takes 2-3 hours.



Figure 7: Place the vacuum on the charging base for initial charging.

4.2. Attaching Nozzles

Select the appropriate nozzle for your cleaning task. Align the nozzle with the vacuum's suction port and push firmly until it clicks into place. To remove, pull the nozzle straight off.

- **Crevice Tool:** Ideal for narrow gaps and corners (e.g., car seats, window sills).

- **Brush Tool:** Best for upholstered surfaces, carpets, and pet hair.
- **Liquid Nozzle:** For vacuuming small liquid spills (ensure liquid does not exceed 100ml).

5. OPERATING INSTRUCTIONS

5.1. Power On/Off and Mode Selection

Press the power button on the handle to turn the vacuum on. The LCD display will illuminate, showing the current battery level and suction mode. Press the mode button to switch between ECO (6000Pa for general cleaning) and MAX (8000Pa for deeper cleaning) modes. Press the power button again to turn the vacuum off.

2-3H Portable Fast Charge



Figure 8: Power button and mode selection on the vacuum's handle.

5.2. General Cleaning

Use the appropriate nozzle for the surface you are cleaning. Move the vacuum slowly over the area to allow for effective suction. For dry debris, the crevice or brush tool can be used. For liquid spills, attach the liquid nozzle and ensure the dust cup does not exceed its 100ml liquid capacity.

FASDUNT

Cordless Handheld Vacuum

for A Smarter Clean and Healthier Life



Figure 9: The versatile handheld vacuum used for cleaning in different environments.

Your browser does not support the video tag.

Video 2: Demonstrates the vacuum's usage for various cleaning tasks, including dry and wet spills.

6. MAINTENANCE

6.1. Emptying the Dust Cup

To empty the dust cup, press the release button located near the dust cup. Detach the dust cup from the main unit. Hold the dust cup over a trash bin and open its lid to dispose of collected debris. For wet messes, carefully pour out the liquid.



Figure 10: Steps for detaching and emptying the dust cup.

6.2. Cleaning the Filters

Regularly clean the HEPA filter and filter holder to maintain optimal suction performance and prevent secondary pollution. Remove the filter from the dust cup. You can use the provided cleaning brush to remove dust from the HEPA filter. Both the HEPA filter and the dust cup can be rinsed under running water. Ensure all parts are completely dry before reassembling to prevent mold or damage.



Figure 11: Detailed steps for cleaning the HEPA filter and dust cup.

Your browser does not support the video tag.

Video 3: Demonstrates how to clean the FASDUNT Handheld Vacuum's filter and dust cup.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No suction or weak suction	Dust cup is full; Filter is clogged; Nozzle is blocked.	Empty the dust cup. Clean or replace the HEPA filter. Check and clear any blockages in the nozzle or suction path.
Vacuum does not turn on	Battery is low or depleted; Power button not pressed correctly.	Charge the vacuum fully. Ensure the power button is pressed firmly.
Short running time	Battery not fully charged; Battery life degraded.	Ensure the vacuum is fully charged before use. If battery life is consistently short after full charge, contact customer support.
Liquid leaks from dust cup	Dust cup overfilled with liquid; Dust cup not properly sealed.	Do not exceed the 100ml liquid max line. Ensure the dust cup is securely attached and sealed.

8. SPECIFICATIONS

Feature	Detail
Brand	FASDUNT

Feature	Detail
Model Number	HV1
Special Features	Portable, LCD Display, Cordless, Bagless, Wet/Dry, Lightweight, HEPA
Filter Type	HEPA Filter
Suction Power	8000Pa (MAX mode)
Battery Type	Lithium-Ion (4 x 2200mAh)
Charging Time	2-3 Hours
Runtime	20-30 minutes
Capacity	0.1 Liters (liquid max)
Item Weight	2.38 pounds
Product Dimensions	16.14"L x 5.12"W x 4.25"H

9. WARRANTY AND SUPPORT

FASDUNT products come with a standard manufacturer's warranty. For detailed warranty information, product support, or to purchase replacement parts, please refer to the contact information provided in your product packaging or visit the official FASDUNT website. Our customer service team is available to assist you with any questions or concerns.

Visit the FASDUNT Store: [FASDUNT Store on Amazon](#)