

vidaXL 313998

vidaXL Antique Brown Iron Garden Pergola (Model 313998) - User Manual

INTRODUCTION

Thank you for choosing the vidaXL Antique Brown Iron Garden Pergola. This manual provides essential information for the safe assembly, operation, and maintenance of your new pergola. Please read these instructions carefully before beginning assembly and retain them for future reference.

This garden pergola is designed to enhance your outdoor space, providing a decorative structure for climbing plants and a shaded area for relaxation. Its antique brown finish and wrought iron construction offer both aesthetic appeal and durability.

SAFETY INFORMATION

General Safety Precautions:

- Read all instructions before assembly and use.
- Ensure all components are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Assemble the pergola on a flat, stable surface.
- Always use appropriate tools and wear protective gear (gloves, safety glasses) during assembly.
- Securely anchor the pergola to the ground to prevent tipping, especially in windy conditions. Consider local weather conditions and soil type when choosing anchoring methods.
- Do not climb on or hang from the pergola.
- Keep children and pets away from the assembly area.
- Regularly inspect the structure for stability and signs of wear or damage.
- This pergola is designed for decorative and plant support purposes. It is not intended to support heavy loads or provide shelter from extreme weather conditions.

PACKAGE CONTENTS

Before assembly, verify that all parts are included and in good condition. If any parts are missing or damaged,

please contact vidaXL customer support.

Typical components include:

- Main frame sections (vertical posts, horizontal beams)
- Decorative elements (scrolls, lattice sections)
- Assembly hardware (bolts, nuts, washers, screws)
- Ground stakes or mounting plates (for securing the base)
- Instruction manual




Image: An illustration showing the various components of the pergola, including posts, beams, and decorative elements, laid out for assembly.

SETUP AND ASSEMBLY INSTRUCTIONS

Assembly of the vidaXL Garden Pergola requires two people and approximately 1-2 hours. Please follow these steps carefully:

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a clean, soft surface to prevent scratches. Refer to the parts list (if provided with the physical product) to identify each piece.
2. **Assemble Vertical Posts:** Connect the sections of the vertical posts if they are not single pieces. Ensure all connections are secure.
3. **Attach Base Plates:** Secure the base plates to the bottom of each vertical post using the provided hardware.



Image: A close-up view of the base of a pergola post, showing the circular plate with three holes for anchoring. The antique brown finish with gold accents is visible.

4. **Connect Horizontal Beams:** Attach the horizontal beams to the top of the vertical posts. Ensure the decorative

elements are correctly oriented.

5. **Secure Top Grid (if applicable):** If your model includes a top grid for climbing plants, attach it to the horizontal beams.




Image: A full view of the assembled pergola frame, showcasing its antique brown wrought iron structure and decorative top scrolls, ready for installation.

6. **Position the Pergola:** Carefully move the assembled pergola to its desired location. Ensure the ground is level and stable.
7. **Anchor the Pergola:** Securely anchor the pergola to the ground using appropriate methods for your surface (e.g., concrete anchors for patio, ground stakes for soil). This step is crucial for stability and safety.
8. **Final Check:** Verify that all bolts and connections are tightened. Ensure the structure is plumb and level.




Image: A diagram illustrating the dimensions of the pergola, showing a width of 400 cm (157.4 inches), a depth of 300 cm (118.1 inches), and varying heights of 230 cm (90.5 inches) and 250 cm (98.4 inches).

OPERATING INSTRUCTIONS

Your vidaXL Garden Pergola is designed to be a versatile addition to your outdoor living space:

- **For Climbing Plants:** Guide climbing plants such as roses, ivy, clematis, wisteria, or grapevines up the posts and across the top grid. The structure provides excellent support for their growth.
- **Shade Provision:** As plants grow and cover the top of the pergola, it will naturally create a shaded area, perfect for relaxing during warm summer days.
- **Decorative Feature:** The antique design and wrought iron construction make it a beautiful focal point in your garden, patio, or terrace, even without extensive plant coverage.



Image: A beautiful garden pergola, fully covered with lush green climbing plants, creating a natural canopy over a small patio area with a table and chairs.

MAINTENANCE

To ensure the longevity and appearance of your vidaXL Garden Pergola, follow these maintenance guidelines:

- **Regular Cleaning:** Clean the iron frame periodically with a soft cloth and mild soap solution. Rinse thoroughly with water and dry to prevent water spots.
- **Rust Prevention:** The pergola is made of iron. While it has an antique finish, inspect for any signs of rust, especially in areas where the finish might be chipped or scratched. Touch up any affected areas with rust-inhibiting paint suitable for outdoor metal.



Image: A detailed close-up of the antique brown finish on a metal component of the pergola, showing its textured appearance.

- **Structural Inspection:** Annually, or more frequently if exposed to harsh weather, check all bolts, nuts, and connections to ensure they are tight. Re-tighten if necessary.
- **Anchoring Check:** Verify that the ground anchors remain secure. Re-secure or reinforce if any loosening is observed.
- **Winter Care:** In regions with heavy snow or ice, consider removing climbing plants or providing additional support to the pergola to prevent damage from excessive weight.

TROUBLESHOOTING

If you encounter issues with your pergola, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Pergola feels unstable or wobbly.	Loose connections; inadequate anchoring; uneven ground.	Ensure all bolts are tightened. Verify ground anchors are secure and appropriate for the surface. Relocate to a more level surface or use shims to level.
Difficulty during assembly (parts not fitting).	Incorrect orientation of parts; manufacturing tolerance issues.	Double-check the assembly diagram for correct part orientation. If parts still do not fit, contact customer support.
Rust spots appearing on the frame.	Exposure to moisture; chipped paint.	Clean the rust, sand lightly, and apply rust-inhibiting paint suitable for outdoor metal. Ensure regular drying after rain.
Pergola deforms under weight of plants.	Excessive plant growth; structural weakness.	Trim plants to reduce weight. Ensure the pergola is properly assembled and anchored. This pergola is designed for light to moderate climbing plants.

SPECIFICATIONS

Model Number: 313998
Brand: vidaXL
Material: Wrought Iron
Color: Antique Brown
Dimensions (L x W x H): 4 x 3 x 2.2/2.5 m (157.4 x 118.1 x 86.6/98.4 inches)
Item Weight: 14.4 Kilograms
Assembly Required: Yes
Country of Origin: China

WARRANTY AND SUPPORT

Warranty Information:

vidaXL offers a 30-day return policy and legal guarantees. For specific warranty details, please refer to the documentation included with your purchase or visit the official vidaXL website.

Customer Support:

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact vidaXL customer support. You can find contact information on the vidaXL website or through your purchase platform.

For more information, visit the official vidaXL store:[vidaXL Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question