

Manuals.plus /

› USARMT /

› USARMT Universal Remote Control User Manual

USARMT B08YP1KYQF

USARMT Universal Remote Control User Manual

Compatible with Pioneer, Daewoo, Hitachi, JVC, HKPro, Atvio Smart TVs

1. INTRODUCTION

This manual provides comprehensive instructions for the USARMT Universal Remote Control, designed for seamless compatibility with various Smart TV brands including Pioneer, Daewoo, Hitachi, JVC, HKPro, and Atvio. This remote offers direct functionality without complex programming, serving as an ideal replacement or secondary control unit.





Figure 1.1: Front view of the USARMT Universal Remote Control. This image displays the full layout of the remote, including all buttons for power, channel, volume, navigation, and dedicated app buttons like Netflix and YouTube.

2. COMPATIBILITY

The USARMT Universal Remote Control is designed for direct compatibility with a range of popular Smart TV brands. No prior programming or code entry is required for these models. Simply insert batteries and begin use.

- **Pioneer** Smart TVs
- **Daewoo** Smart TVs
- **Hitachi** Smart TVs
- **JVC** Smart TVs
- **HKPro** Smart TVs
- **Atvio** Smart TVs

COMPATIBLE CON ESTOS MODELOS



HITACHI



DAEWOO



HKPRO



JVC



PIONEER

Figure 2.1: Visual representation of compatible TV brands. This image shows five different remote controls, each labeled with a compatible brand: Hitachi, Daewoo, HKPro, JVC, and Pioneer, indicating the remote's broad compatibility.

3. SETUP

Setting up your USARMT Universal Remote Control is a simple process that primarily involves battery installation.

3.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or outwards to open it.
3. Insert two AAA batteries (not included) into the compartment, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.





Figure 3.1: Rear view of the remote control, highlighting the battery compartment. This image clearly shows the removable cover for battery insertion.

Once batteries are installed, the remote is ready for immediate use with compatible TV models. No pairing or programming is typically required.

4. OPERATING INSTRUCTIONS

The USARMT Universal Remote Control features a standard layout for intuitive operation of your television. Below is a guide to the main functions and buttons.

4.1 Button Functions Overview






Figure 4.1: Close-up of the upper section of the remote control. This view details the power button, TV/Source input selectors, numerical keypad (0-9), and dedicated app buttons for Netflix and YouTube.





Figure 4.2: Close-up of the lower section of the remote control. This image shows the navigation pad (up, down, left, right, OK), back button, exit, info, USB, menu, sleep, guide, favorite, channel list, picture, sound, CC (closed caption), and media playback controls (play, pause, stop, rewind, fast forward, skip).

- **Power (●):** Turns the TV on or off.
- **TV / SOURCE:** Selects the input source (HDMI, AV, etc.).
- **Number Buttons (0-9):** Directly enter channel numbers.
- **VOL +/-:** Adjusts the volume level.
- **CH ^ / v:** Changes channels up or down.
- **Netflix / YouTube:** Direct access buttons for these streaming services.
- **Navigation Pad (Up, Down, Left, Right, OK):** Navigates menus and confirms selections.
- **Back (↶):** Returns to the previous screen or menu.
- **EXIT:** Exits the current menu or application.
- **INFO:** Displays information about the current program or input.
- **USB:** Selects USB input.
- **Menu (≡):** Opens the main menu.
- **SLEEP:** Sets a sleep timer for the TV.
- **GUIDE:** Accesses the electronic program guide.
- **FAV:** Accesses favorite channels list.
- **CH LIST:** Displays the channel list.
- **PICTURE / SOUND / CC:** Accesses picture settings, sound settings, and closed captions.
- **Media Controls (Play, Pause, Stop, Rewind, Fast Forward, Skip):** Controls media playback.
- **MTS:** Multi-channel Television Sound selection.



Figure 4.3: A hand holding the USARMT remote control, pointing towards a television screen. This illustrates the typical usage scenario of the remote.

5. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your remote control.

- **Cleaning:** Use a soft, dry cloth to clean the remote. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops:** Protect the remote from physical impact, as this can damage internal components.

6. TROUBLESHOOTING

If you encounter issues with your USARMT Universal Remote Control, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Remote not responding.	Dead or incorrectly inserted batteries.	Replace batteries with new ones, ensuring correct polarity (+/-).
Remote works intermittently.	Low battery power; Obstruction between remote and TV sensor.	Replace batteries. Ensure a clear line of sight to the TV's IR sensor.
Specific buttons not working.	Dirt or debris under the button; Internal malfunction.	Clean the remote surface. If problem persists, the remote may be faulty.
Remote does not control TV.	TV model not compatible; Remote malfunction.	Verify your TV model is listed as compatible. If it is, and batteries are new, the remote may be defective.

7. SPECIFICATIONS

- **Brand:** USARMT
- **Compatible Devices:** Television (Pioneer, Daewoo, Hitachi, JVC, HKPro, Atvio Smart TVs)
- **Connectivity Technology:** Infrared (IR)
- **Controller Type:** Tactile Control
- **Maximum Number of Compatible Devices:** 1 (per remote)
- **Dimensions:** Approximately 28.2 x 5.8 x 3 cm (11.1 x 2.3 x 1.2 inches)
- **Weight:** Approximately 100 g (3.5 ounces)
- **ASIN:** B08YP1KYQF

8. WARRANTY AND SUPPORT

Specific warranty details and direct support contact information are not provided in this manual. For warranty claims or technical assistance, please refer to the retailer or platform where the product was purchased, or visit the official USARMT website if available.