

Z-Lite 6015-6MB

Z-Lite 6 Light Chandelier 6015-6MB Instruction Manual

Model: 6015-6MB

1. INTRODUCTION

This instruction manual provides comprehensive guidance for the safe installation, operation, and maintenance of your Z-Lite 6 Light Chandelier, model 6015-6MB. Please read this manual thoroughly before beginning installation and retain it for future reference. Proper installation and adherence to these instructions will ensure optimal performance and safety.

The Z-Lite 6015-6MB is a 6-light chandelier featuring a matte black iron finish and a tiered geometric design, suitable for indoor use in living rooms and other general purpose areas. It is designed for semi-flush mount installation.

2. SAFETY INFORMATION

WARNING: RISK OF ELECTRIC SHOCK. Disconnect power at the circuit breaker or fuse box before installation or servicing. Improper installation can result in serious injury or death.

- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC). Consult a qualified electrician if you are unfamiliar with proper electrical wiring connections.
- This fixture is intended for indoor use only. Do not expose to water or moisture.
- Ensure the mounting surface can support the weight of the fixture.
- Use only the specified bulb type and wattage (E12 base, 360 watts total maximum).
- Do not connect this fixture to an ungrounded electrical system.
- **Proposition 65 Warning:** This product may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

3. PACKAGE CONTENTS

Carefully unpack the fixture and check that all parts are present. Refer to the diagram below for identification of components. If any parts are missing or damaged, do not attempt to assemble or install the fixture. Contact customer support for assistance.

- Chandelier Fixture Body (1)
- Mounting Canopy (1)
- Downrod/Stem (1)
- Mounting Plate/Crossbar (1)
- Mounting Screws and Wire Nuts (Set)
- Instruction Manual (1)





Image: Front view of the Z-Lite 6 Light Chandelier 6015-6MB, showcasing its matte black finish and tiered wire design.

4. SETUP AND INSTALLATION

Professional installation by a qualified electrician is recommended.

Tools Required (Not Included):

- Phillips Head Screwdriver
- Flathead Screwdriver
- Wire Strippers
- Electrical Tape
- Ladder

Installation Steps:

1. **Turn Off Power:** Before starting, ensure the power to the junction box is turned off at the circuit breaker or fuse box.
2. **Prepare Mounting Plate:** Attach the mounting plate/crossbar to the junction box using the provided mounting screws. Ensure it is securely fastened.
3. **Assemble Downrod:** Thread the downrod onto the fixture body. Ensure all connections are tight.
4. **Wire Connections:**
 - Connect the bare copper ground wire from the fixture to the ground wire from the junction box (usually green or bare copper) using a wire nut.
 - Connect the white wire from the fixture to the white (neutral) wire from the junction box using a wire nut.
 - Connect the black wire from the fixture to the black (hot) wire from the junction box using a wire nut.
 - Wrap all wire connections with electrical tape for added security.
5. **Mount Canopy:** Carefully push the wires into the junction box. Align the canopy with the mounting plate and secure it with the canopy screws.
6. **Install Bulbs:** Screw in six (6) E12 base bulbs (not included) into the sockets. Do not exceed the maximum wattage of 60 watts per bulb or 360 watts total.
7. **Restore Power:** Once installation is complete, restore power at the circuit breaker.







Image: Angled view of the Z-Lite 6 Light Chandelier 6015-6MB, showing the internal bulb sockets and wire cage design.

5. OPERATING INSTRUCTIONS

Once properly installed and wired, the Z-Lite 6 Light Chandelier operates like any standard ceiling light fixture. It is designed to be controlled by a wall switch.

- **Turning On/Off:** Use the wall switch connected to the fixture to turn the chandelier on or off.
- **Dimming Functionality:** This fixture is compatible with standard dimmer switches. If a dimmer switch is installed, you can adjust the light output by manipulating the dimmer control. Ensure that the bulbs used are also dimmable.

6. MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your chandelier.

- **Cleaning:** Always disconnect power before cleaning. Wipe the fixture with a soft, dry cloth. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish.
- **Bulb Replacement:** Ensure power is off before replacing bulbs. Allow bulbs to cool completely before touching. Unscrew old bulbs and replace with new E12 base bulbs, not exceeding 60 watts per bulb.
- **Inspection:** Periodically check all electrical connections and mounting hardware for tightness.

7. TROUBLESHOOTING

If you experience issues with your chandelier, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	Power is off at the circuit breaker. Loose wire connections. Faulty bulb(s). Faulty wall switch.	Check circuit breaker and ensure power is on. Turn off power, check all wire connections. Replace bulb(s). Test wall switch or consult an electrician.
Lights flicker.	Loose bulb. Incompatible dimmer switch or bulbs. Loose wire connection.	Tighten bulb(s). Ensure dimmer and bulbs are compatible. Turn off power, check wire connections.
Fixture hums.	Incompatible dimmer switch.	Replace dimmer switch with a high-quality, compatible LED dimmer if using LED bulbs.

8. SPECIFICATIONS




Image: Dimensional drawing of the Z-Lite 6 Light Chandelier 6015-6MB, showing key measurements including 25" width, 25" length, and 22" height.

Model Number:	6015-6MB
Brand:	Z-Lite
Material:	Iron
Finish Type:	Matte Black
Dimensions (L x W x H):	25"L x 25"W x 22"H

Item Weight:	16 Pounds
Number of Light Sources:	6
Bulb Base:	E12
Max Wattage (per bulb):	60 watts (360 watts total)
Voltage:	120 Volts
Installation Type:	Semi Flush Mount, Ceiling Mount
Indoor/Outdoor Usage:	Indoor
Control Method:	Wall Switch (Dimmer compatible)
Certification:	UL Listed (CUL/cETLu)

9. WARRANTY AND SUPPORT

Warranty: This Z-Lite product is covered by a manufacturer's warranty. Please refer to the original purchase documentation or contact Z-Lite customer service for specific warranty terms and conditions.

Customer Support: For technical assistance, missing parts, or warranty inquiries, please contact Z-Lite customer support. Contact information can typically be found on the manufacturer's website or your purchase receipt.

Please retain your proof of purchase for warranty claims.