

## Hover-1 Vivid Folding Kick Scooter

# Hover-1 Vivid Folding Kick Scooter User Manual

Model: Vivid Folding Kick Scooter

## 1. SAFETY GUIDELINES

Before operating the Hover-1 Vivid Folding Kick Scooter, please read and understand all safety instructions. Failure to follow these guidelines may result in injury or damage.

- **Age Recommendation:** This scooter is designed for children 5 years and older.
- **Weight Limit:** Do not exceed the maximum load capacity of 110 lbs (50 kg).
- **Protective Gear:** Always wear a helmet, knee pads, and elbow pads while riding.
- **Supervision:** Adult supervision is recommended, especially for younger riders.
- **Riding Surface:** Ride on smooth, paved surfaces away from traffic. Avoid uneven terrain, loose debris, and wet conditions.
- **Braking:** Familiarize yourself with the rear foot brake before riding at speed.
- **Visibility:** The multi-color LED wheels enhance visibility in low-light conditions, but always be aware of your surroundings.

## 2. SETUP AND ASSEMBLY

The Hover-1 Vivid Folding Kick Scooter comes largely pre-assembled. Follow these steps to prepare it for use:

### 1. Unfolding the Scooter:

- Locate the folding mechanism at the base of the handlebar stem.
- Release the locking mechanism (refer to image for location).
- Carefully pull the handlebar stem upwards until it locks into place with an audible click. Ensure it is securely locked before use.

### 2. Adjusting Handlebar Height:

- Loosen the clamp on the handlebar stem.
- Press the adjustment button and slide the handlebar to the desired height. Ensure the button snaps

into one of the adjustment holes.

- Tighten the clamp firmly to secure the handlebar in position. The cushioned handles should provide maximum grip and comfort.

### 3. Battery Installation (for LED wheels):

- The scooter requires 6 AAA batteries (not included) for the LED wheels.
- Locate the battery compartment, typically on the underside of the deck or near the wheels.
- Open the compartment, insert the batteries with correct polarity, and securely close the cover.



Image: Key features of the Hover-1 Vivid Kick Scooter, including the rear foot brake, adjustable handlebar height, and LED light-up wheels.

## 3. OPERATING INSTRUCTIONS

The Hover-1 Vivid Folding Kick Scooter is designed for intuitive and safe operation.

### 1. Starting:

- Place one foot firmly on the scooter deck.
- Use your other foot to push off the ground, generating momentum.

- Once moving, place both feet on the deck.

## 2. Steering (Lean-to-Turn Axle):

- The scooter uses a lean-to-steer mechanism. To turn, gently lean your body in the desired direction.
- The front wheels will respond to your lean, providing a smooth and stable turn.

## 3. Braking:

- To slow down or stop, press down firmly on the rear foot brake located above the back wheel.
- Apply gradual pressure to avoid sudden stops.



Image: Demonstrates the ease of learning and riding the Hover-1 Vivid Kick Scooter, suitable for young users.

## 4. MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your scooter.

- **Cleaning:** Wipe the scooter with a damp cloth after use. Avoid harsh chemicals or abrasive cleaners.

- **Wheel Inspection:** Regularly check the solid PU tires for wear and tear. Ensure they are free from debris.
- **Fasteners:** Periodically check all screws and bolts to ensure they are tight. Do not overtighten.
- **Battery Replacement:** Replace the 6 AAA batteries for the LED wheels when they dim or stop working.
- **Storage:** Store the scooter in a dry, cool place away from direct sunlight and moisture. The one-step folding system allows for compact storage.

## 5. TROUBLESHOOTING

If you encounter any issues with your Hover-1 Vivid Folding Kick Scooter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
LED wheels not lighting up	Dead or incorrectly installed batteries.	Replace the 6 AAA batteries, ensuring correct polarity.
Handlebar is loose or wobbly	Clamp not tightened or adjustment button not fully engaged.	Ensure the adjustment button is fully engaged in a height hole and tighten the clamp firmly.
Scooter not steering smoothly	Debris in the steering mechanism or worn wheels.	Inspect the lean-to-turn axle for obstructions. Clean if necessary. Check wheels for excessive wear.
Brake not effective	Worn brake pad or debris.	Inspect the rear foot brake for wear. Clean any debris that may be interfering with its function.

## 6. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Hover-1
Model Name	Vivid- Folding Kick Scooter
Color	black
Age Range (Description)	Kid (5+ Year Old)
Weight Limit	110 Pounds
Product Dimensions (LxWxH)	23"L x 12.5"W x 32.7"H
Number of Wheels	2
Wheel Material	Polyurethane
Frame Material	Aluminum
Item Weight	4.1 Pounds



Feature	Detail
Handlebar Type	Adjustable
Handle Height	32.7 Inches
Wheel Size	3 Inches
Wheel Type	Solid
Brake Style	Rear Braking
UPC	888255217349



**110 lbs**  
MAX WEIGHT



**4.6/3.5 inch**  
FRONT/REAR SOLID TIRES



**Lean Turn**  
AXLE



**HOVER-1**  
VIVID SPECS

Image: Visual representation of key specifications for the Hover-1 Vivid Kick Scooter.





7. WARRANTY AND SUPPORT

The Hover-1 Vivid Folding Kick Scooter comes with a limited warranty.

- **Warranty Period:** 90 days from the date of purchase.
- **Warranty Coverage:** This warranty covers manufacturing defects in materials and workmanship. It does not cover damage caused by misuse, neglect, accidents, or normal wear and tear.
- **Claiming Warranty:** For warranty claims or technical support, please contact the manufacturer, DGL Group, or your retailer with your proof of purchase.

© 2025 Hover-1. All rights reserved.


Related Documents - Vivid Folding Kick Scooter

	<p><a href="#">Hover-1 Vivid Scooter Quick Start Guide</a></p> <p>A quick start guide for the Hover-1 Vivid scooter, covering parts identification, safety warnings for pinch points, folding and unfolding instructions, and handlebar height adjustment.</p>
	<p><a href="#">Hover-1 Helios Electric Folding Scooter Operation Manual</a></p> <p>Comprehensive operation manual for the Hover-1 Helios electric folding scooter (Model H1-HLOS), covering safety guidelines, operating instructions, maintenance, specifications, and troubleshooting.</p>
	<p><a href="#">HOVER-1 HIGHLANDER Electric Folding Scooter: Important Information and Setup Guide</a></p> <p>Essential information for your HOVER-1 HIGHLANDER electric folding scooter, including charging instructions, serial number location, and support contact details. Keep this card for your records.</p>
	<p><a href="#">Hover-1 Gambit Electric Folding Scooter Operation Manual H1-GAM</a></p> <p>Comprehensive operation manual for the Hover-1 Gambit Electric Folding Scooter (H1-GAM), covering safety precautions, assembly, charging, riding instructions, maintenance, and specifications. Learn how to safely operate and maintain your electric scooter.</p>



[Hover-1 Journey Max Electric Folding Scooter Operation Manual](#)

This operation manual provides comprehensive instructions and safety precautions for the Hover-1 Journey Max electric folding scooter. Learn about assembly, operation, maintenance, battery care, and troubleshooting.



[Hover-1 Comet Electric Folding Scooter Operation Manual & Safety Guide](#)

Comprehensive operation manual and safety guide for the Hover-1 Comet electric folding scooter. Learn about assembly, riding, maintenance, specifications, and safety precautions.