

**Manuals+**

[Q & A](#) | [Deep Search](#) | [Upload](#)

**Manuals.plus /**

› **Vezzio /**

› Vezzio 9.5-Quart 10-Speed Tilt-Head Stand Mixer (Model SM-1553N) User Manual

**Vezzio SM-1553N**

# Vezzio 9.5-Quart 10-Speed Tilt-Head Stand Mixer (Model SM-1553N) User Manual

Your comprehensive guide to operating and maintaining your Vezzio Stand Mixer.

## 1. INTRODUCTION

---

Thank you for choosing the Vezzio 9.5-Quart 10-Speed Tilt-Head Stand Mixer. This appliance is designed to simplify your baking and cooking tasks with its powerful motor, large capacity, and versatile attachments. Please read this manual thoroughly before first use to ensure safe and efficient operation.

# 9.5 QT

## Larger Capacity



Tow-handed handle



304 Stainless Bowl



Dishwasher-Safe



Image 1: Vezzio 9.5-Quart Stand Mixer showcasing its large capacity bowl.

## 2. IMPORTANT SAFETY INSTRUCTIONS

---

To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions when using electrical appliances:

- Read all instructions before operating the mixer.
- Do not immerse the motor base in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Avoid contact with moving parts. Keep hands, hair, and clothing, as well as spatulas and other utensils, away from beaters during operation to reduce the risk of injury to persons and/or damage to the mixer.
- Do not use attachments not recommended or sold by the manufacturer.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter.

- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- Always ensure the mixer head is securely locked down before operation.

### **3. PACKAGE CONTENTS**

---

Your Vezzio Stand Mixer package includes the following items:

- Vezzio Stand Mixer Motor Base
- 9.5-Quart Stainless Steel Mixing Bowl with 2 Handles
- Dough Hook
- Whisk Attachment
- Beater Attachment
- Splash Guard with Pour Spout
- Egg White Separator
- Spatula

# OVERVIEW OF THE COMPONENTS



Image 2: Overview of the Vezzio Stand Mixer components and accessories.

## 4. SETUP

### 4.1 Attaching and Detaching Accessories

To attach an accessory (dough hook, whisk, or beater), ensure the mixer is unplugged and the head is tilted up. Align the accessory shaft with the output shaft, push it up, and twist clockwise until it locks into place. To detach, push up and twist counter-clockwise, then pull down.

### 4.2 Attaching and Detaching Mixing Bowl

To attach the stainless steel mixing bowl, place it onto the base, aligning the guides, and twist clockwise until it locks securely. To detach, twist counter-clockwise and lift the bowl off the base.

Video 1: Demonstration of attaching and detaching mixer attachments and the mixing bowl.

### 4.3 Attaching the Splash Guard

The transparent splash guard helps prevent ingredients from splattering during mixing. It easily attaches to the mixer

head once an accessory is installed and the head is lowered. The pour spout allows for adding ingredients while the mixer is running.



Image 3: The tilt-head design and splash guard for easy access and clean operation.

## 5. OPERATING INSTRUCTIONS

### 5.1 Speed Control

The Vezzio Stand Mixer features 10 optimized speeds and a pulse function. Use the rotary control knob to select the desired speed:

- **Speeds 1-4 (Dough Hook):** Ideal for heavy mixtures like bread dough, pizza dough, and short pastry.
- **Speeds 2-6 (Beater):** Suitable for medium-heavy mixtures such as cake batters, cookies, and mashed potatoes.
- **Speeds 8-10 (Whisk):** Best for light mixtures like meringues, whipping cream, and egg whites.
- **Pulse (P):** Provides a quick burst of power for rapid incorporation or quick mixing.

# 10 Speed Options & Pulse Function



**1-4 Dough Hook**

(e.g bread or short pastry)



**2-6 Beater**

Medium-Heavy Mixtures  
(e.g crepes or sponge mixture)



**8-10 Whisk**

Light Mixtures  
(e.g cream, sauces  
egg white,)



**Pulse**

when require a quick burst of  
power or for quick incorporations

Image 4: Speed options and recommended attachment usage.



## Dough Hook

1-4 Speed

Heavy Mixtures-Bread,  
Pizza, Spaghetti



## Beater

2-6 Speed

Medium-heavy mixtures  
Salad, Cookie, crepes



## Whisk

8-10 Speed/Pulse Mode

Light mixtures-Cream,  
Egg White, Cake, Sauces



*Image 5: Visual guide for attachment and speed selection based on food type.*

*Video 2: The 9.5-Quart Stand Mixer in operation, demonstrating various mixing tasks.*

*Video 3: Stand mixer demonstrating dough kneading.*

*Video 4: Stand mixer demonstrating whipping action.*

## 6. MAINTENANCE AND CLEANING

---

Proper cleaning ensures the longevity and hygiene of your mixer:

- Always unplug the mixer before cleaning.
- The stainless steel mixing bowl, dough hook, whisk, and beater attachments are dishwasher-safe.
- Wipe the motor base with a damp cloth. Do not immerse the motor base in water.
- Ensure all parts are completely dry before reassembling or storing.

## 7. TROUBLESHOOTING

---

If you encounter any issues with your Vezzio Stand Mixer, please refer to the following common solutions:

- **Mixer does not turn on:** Ensure the power cord is securely plugged into a working outlet and the speed control knob is not in the 'OFF' position. Check if the mixer head is properly locked down.
- **Attachments not reaching ingredients:** Ensure the mixing bowl is correctly seated and locked onto the base.
- **Excessive noise or vibration:** Verify that the mixer is placed on a flat, stable surface. The anti-slip suction cups on the base are designed to minimize movement and noise during operation.
- **Ingredients splattering:** Ensure the splash guard is properly installed. Reduce the speed setting if necessary.

For further assistance, please contact Vezzio customer support.

## 8. SPECIFICATIONS

---

Feature	Specification
Brand	Vezzio
Model Name	SM-1553N
Capacity	9.5 Quarts
Number of Speeds	10
Wattage	660 Watts
Voltage	120 Volts
Material	Stainless Steel (Bowl, Blade)
Product Dimensions (D x W x H)	42.5D x 27W x 36H Centimetres
Item Weight	5.8 Kilograms
Special Features	Adjustable Speed Control, Dishwasher Safe Jars, Tilt Head
Noise Level	<76dB

**≤60dB**

Low operation noise,  
68-75dB within 1M

10-20dB Leaves Fall	30dB Whisper	40-50 dB Alarm Clock	60dB Quite Operation	90 dB Little Noisy	70-80 dB Normal Chat
------------------------	-----------------	-------------------------	----------------------	-----------------------	-------------------------

Image 6: Vezzio Stand Mixer with key dimensions.

## 9. WARRANTY AND SUPPORT

Vezzio offers a full five-year quality guarantee for your stand mixer, along with friendly lifelong support. If you have any questions or require assistance, please do not hesitate to contact us.

**Manufacturer Contact Information:** [dewudq1226@outlook.com](mailto:dewudq1226@outlook.com)