

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Kenmore](#) /

› [Kenmore Elite Ovation 5 Qt Stand Mixer Instruction Manual \(Model KKEOVSMG_AZ\)](#)

Kenmore KKEOVSMG_AZ

Kenmore Elite Ovation 5 Qt Stand Mixer Instruction Manual

Model: KKEOVSMG_AZ | Brand: Kenmore

INTRODUCTION

This manual provides essential information for the safe and efficient operation, maintenance, and care of your Kenmore Elite Ovation 5 Qt Stand Mixer. Please read all instructions carefully before first use and retain this manual for future reference.

PRODUCT FEATURES

- **500 Watt Motor:** Provides robust power for various mixing tasks, from whipping cream to kneading dense doughs.
- **Revolutionary Pour-In Top:** Allows for easy addition of ingredients during mixing without stopping or splattering.
- **360-Degree Splash Guard:** Keeps ingredients contained within the bowl, minimizing countertop mess.
- **Tilt-Head Design:** Facilitates easy access to the mixing bowl and attachments.
- **5 Qt Glass Bowl:** High-capacity bowl suitable for large or small batches, with a convenient handle and storage lid.
- **LED Bowl Light:** Illuminates the mixing bowl for enhanced visibility of ingredients and mixing progress.
- **10 Speed Options:** Offers precise control for various baking tasks.
- **Slow-Start Feature:** Provides gentle mixing initiation to prevent splattering.
- **Safety Start:** Mixer will not operate unless the speed is set to zero, ensuring safe operation.
- **Stable Operation:** Heavy-duty construction ensures stability even with stiff doughs.
- **Versatile Attachment Hub:** Compatible with widely available attachments (sold separately) like vegetable spiralizers, meat grinders, and pasta makers.

WHAT'S INCLUDED

Your Kenmore Elite Ovation Stand Mixer comes with the following components and accessories:

- Mixer base with Pour-In Top
- 5 Qt Glass Bowl with Handle
- Snap-on Bowl Lid

- 360-Degree Splash Guard
- Flat Beater
- Wire Whisk
- Dough Hook
- Easy-Pour Funnel
- Pour-In Egg Separator
- Ingredient Grater/Zester



Figure 1: All included accessories for the Kenmore Elite Ovation Stand Mixer.

The image above displays the Kenmore Elite Ovation Stand Mixer along with its complete set of included accessories, such as the glass bowl, various beaters, and specialized pour-in tools.

SETUP

1. **Unpack Components:** Carefully remove all parts from the packaging.
2. **Clean Before First Use:** Wash the glass bowl, splash guard, and all attachments (flat beater, whisk, dough hook, funnel, egg separator, grater/zester) in warm, soapy water or in the dishwasher. Wipe the mixer base with a damp cloth. Ensure all parts are completely dry before assembly.
3. **Place Mixer Base:** Position the mixer base on a clean, dry, and stable countertop. The suction cups on the base will help secure it during operation.
4. **Attach Mixing Bowl:** Place the 5 Qt glass bowl onto the mixer base. Turn the bowl clockwise until it locks securely into place.
5. **Install Attachment:** Lift the tilt-head by pushing the release lever. Select the desired attachment (flat beater, whisk, or dough hook) and insert it into the attachment shaft. Twist to secure. Lower the tilt-head until it locks.
6. **Attach Splash Guard:** Place the 360-degree splash guard over the mixing bowl. Ensure it is properly seated.

OPERATING INSTRUCTIONS

1. **Add Ingredients:** Place your ingredients into the mixing bowl. For liquids or smaller ingredients, utilize the revolutionary pour-in top or the easy-pour funnel.
2. **Select Speed:** Turn the speed control knob to the desired setting (1-10). The mixer features a slow-start function to prevent sudden splattering.
3. **Monitor Mixing:** The built-in LED light illuminates the bowl, allowing you to monitor the consistency and progress of your ingredients.
4. **Add Additional Ingredients:** Use the pour-in top or funnel to add more ingredients while the mixer is operating, without stopping the machine.
5. **Stop Mixer:** To stop the mixer, turn the speed control knob to '0'.
6. **Remove Bowl and Attachment:** Lift the tilt-head. Twist and remove the attachment. Unlock and remove the mixing bowl.



Figure 2: The speed control dial offers 10 settings for precise mixing.

The speed control dial allows you to select from 10 different speeds, providing versatility for various recipes. The mixer is designed with a safety feature that requires the speed to be set to zero before starting.



Figure 3: The integrated LED light provides clear visibility into the mixing bowl.

The LED light feature ensures that you have a clear view of your ingredients as they mix, helping to prevent over or under-mixing.

ATTACHMENTS AND ACCESSORIES

The Kenmore Elite Ovation Stand Mixer comes with several essential attachments and exclusive accessories:

- **Flat Beater:** Ideal for creaming butter and sugar, mixing cake batters, and combining ingredients for cookies.
- **Wire Whisk:** Perfect for whipping eggs, cream, and light batters to achieve airy textures.
- **Dough Hook:** Designed for kneading yeast doughs for bread, pizza, and pasta.
- **Easy-Pour Funnel:** Assists in adding ingredients precisely through the pour-in top.

- **Pour-In Egg Separator:** Conveniently separates egg yolks from whites directly into the bowl.
- **Ingredient Grater/Zester:** Allows for grating or zesting ingredients directly into the mixture.



Figure 4: The versatile attachment hub allows for expansion with optional accessories.

The attachment hub expands the mixer's capabilities, allowing you to connect various optional accessories (sold separately) such as vegetable spiralizers, meat grinders, and pasta makers.

MAINTENANCE AND CLEANING

- **Unplug Before Cleaning:** Always ensure the mixer is unplugged from the power outlet before cleaning.
- **Exterior Cleaning:** Wipe the mixer base with a damp cloth. Do not immerse the base in water.
- **Bowl and Attachments:** The glass bowl, splash guard, and all interchangeable tools (flat beater, whisk, dough hook, funnel, egg separator, grater/zester) are dishwasher safe. Hand wash promptly after use to prevent food residue from drying. Avoid abrasive cleansers.
- **Drying:** Ensure all parts are completely dry before reassembling or storing.

SAFETY INFORMATION

- **Stable Placement:** Always operate the mixer on a stable, flat, and dry surface. The mixer's weight and suction cups help maintain stability.
- **Safety Start Feature:** The mixer is designed to only start when the speed control knob is set to '0'. This prevents accidental starts.
- **Overheating Protection:** The mixer features a work light that illuminates during operation and also alerts you to operational errors or motor overheating. If the motor stops due to overheating, turn the speed switch to zero and allow it to cool for 10-15 minutes before restarting.
- **Glass Bowl Usage:** The glass mixer bowl is designed for mixing purposes only. Do not use it for cooking or heating, as extreme temperatures may cause breakage or shattering.
- **Children and Pets:** Keep hands, hair, clothing, and utensils away from moving parts during operation. Supervise children closely if they are near the appliance.

TROUBLESHOOTING

- **Mixer Not Starting:** Ensure the speed control knob is set to '0' before attempting to start. Check if the power cord is securely plugged into a working outlet.
- **Motor Overheating:** If the mixer stops during extended use or when handling heavy doughs, the motor's overheating protection may have activated. Turn the speed switch to zero and allow the unit to cool for 10-15 minutes before restarting.
- **Dough Riding Up Attachments:** For very small batches of dough, the dough may occasionally ride up the dough hook. This is less common with larger batches.

- **Noise Level:** The mixer operates quietly, ranging from 60 dB at speed 1 to 70 dB at speed 10, comparable to normal household sounds.

SPECIFICATIONS

Specification	Detail
Brand	Kenmore
Model Name	Kenmore Ovation Stand Mixer 5 Quart
Item Model Number	KKEOVSMG_AZ
Capacity	5 Quarts
Wattage	500 watts
Voltage	120.0
Material	Stainless Steel
Color	Grey
Product Dimensions	14.75"D x 9.5"W x 13"H
Item Weight	30 pounds
Controls Type	Knob
Dishwasher Safe Parts	Yes (non-electrical parts)

WARRANTY AND SUPPORT

The Kenmore Elite Ovation Stand Mixer comes with a **5-year warranty**, providing assurance of its durability and quality.

For any questions, replacement parts, or support, please contact Koolatron or visit their website to reach the support team.

PRODUCT VIDEOS

Kenmore 500W Ovation Stand Mixer Overview

Your browser does not support the video tag.

This video provides a comprehensive overview of the Kenmore Elite Ovation Stand Mixer, highlighting its key features and benefits for home baking.