faleemi FSC776A, FSC768

Faleemi Indoor/Outdoor Home WiFi Security Camera User Manual

Models: FSC776A (Indoor), FSC768 (Outdoor)

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Faleemi Indoor/Outdoor Home WiFi Security Camera. This product line includes both indoor (FSC776A) and outdoor (FSC768) models, designed to provide reliable surveillance with features such as 1080P Full HD video, night vision, two-way audio, and motion detection. Please read this manual thoroughly before using your camera to ensure proper installation and functionality.

Figure 1: Faleemi Indoor (dome) and Outdoor (bullet) Security Cameras. This image displays both the indoor dome-style camera and the outdoor bullet-style camera, highlighting the dual-purpose nature of the product line.

2. PRODUCT OVERVIEW

2.1 Key Features

- **1080P Full HD Video:** Captures clear and crisp video footage.

- **Easy Setup:** QR code-based setup via the Faleemi Cloud App.

- **Two-Way Audio:** Built-in microphone and speaker for real-time communication.

- **Night Vision:** Provides clear monitoring in low-light or complete darkness.

- **Motion Detection:** Sends instant alerts with 10-second video clips to your smartphone.

- **Local & Cloud Storage:** Supports Micro SD card (up to 128GB, not included) and offers optional cloud storage.

- **Weatherproof (FSC768 Outdoor Model):** IP66 rated aluminum alloy construction for outdoor use.

- **Pan & Tilt (FSC776A Indoor Model):** 340° horizontal and 120° vertical rotation for wider coverage.

2.2 Camera Components

Figure 2: Faleemi Indoor Dome Camera (FSC776A). This image shows the compact, white dome-style indoor camera with its lens and Faleemi branding.

Figure 3: Faleemi Outdoor Bullet Camera (FSC768). This image displays the robust, white bullet-style outdoor camera with its antenna and mounting bracket.

3. SETUP GUIDE

3.1 Download the Faleemi Cloud App

1. Search for "Faleemi Cloud" in your smartphone's app store (App Store for iOS or Google Play Store for Android).
2. Download and install the application.
3. Register for a new account or log in if you already have one.

3.2 Power On the Camera

- Connect the camera to a power outlet using the provided power adapter.

- Wait for the camera to power on. You may hear a startup chime or see an indicator light.

3.3 Connect to Wi-Fi (QR Code Setup)

1. Open the Faleemi Cloud App and tap the "+" icon to add a new device.

2. Select your camera model or choose the option for QR code setup.

3. Enter your Wi-Fi network name (SSID) and password when prompted. Ensure your phone is connected to a 2.4GHz Wi-Fi network, as the camera may not support 5GHz.

4. The app will generate a QR code. Hold your smartphone with the QR code approximately 4-8 inches (10-20 cm) in front of the camera lens.

5. The camera will scan the QR code and confirm successful connection. Follow any further on-screen instructions in the app to complete the setup.

3.4 Mounting the Camera

- **Indoor Camera (FSC776A):** Place the camera on a flat surface or use the included mounting bracket to attach it to a wall or ceiling. Ensure it has a clear line of sight to the area you wish to monitor.

- **Outdoor Camera (FSC768):** Use the provided mounting hardware to securely attach the camera to a wall or eave. Position it to cover the desired outdoor area, ensuring the power cable is protected from the elements. The camera is rated IP66 for weather resistance.

4. OPERATING INSTRUCTIONS

4.1 Live View and Remote Control

- Open the Faleemi Cloud App. Your connected camera(s) will appear on the main screen.

- Tap on a camera to view its live feed.

- For the indoor camera (FSC776A), use the on-screen controls to pan (left/right) and tilt (up/down) the camera lens to adjust the viewing angle.

4.2 Two-Way Audio

Both camera models feature a built-in microphone and speaker, enabling two-way communication through the app.

1. While in live view, tap the microphone icon in the app to speak. Your voice will be transmitted through the camera's speaker.

2. Tap the speaker icon to listen to audio from the camera's location.

Figure 4: Indoor Camera Two-Way Audio Demonstration. This image illustrates the two-way audio feature, showing a baby being monitored by the indoor camera and a phone displaying the live feed with a speech bubble indicating communication.

Figure 5: Outdoor Camera Two-Way Audio with Delivery. This image depicts the outdoor camera's two-way audio capability, showing a delivery person and a phone displaying the live feed with a message for the delivery person.

4.3 Night Vision

The cameras automatically switch to night vision mode in low-light conditions, providing clear black-and-white video. The night vision range is effective for monitoring in complete darkness.

4.4 Motion Detection and Alerts

The cameras are equipped with motion detection capabilities. When motion is detected, the camera will:

- Send an instant push notification to your smartphone.
- Record a 10-second video clip, accessible within the Faleemi Cloud App.

You can adjust the motion detection sensitivity and set detection zones within the app settings.

Figure 6: Motion Alarm in Real Time. This image demonstrates the motion detection feature, showing an intruder being captured by the indoor camera and a corresponding motion alarm notification on a smartphone.

4.5 Recording and Storage

- **Micro SD Card:** Insert a Micro SD card (up to 128GB, Class 10 recommended) into the camera's SD card slot for continuous recording or event-triggered recordings. The camera will automatically overwrite older footage when the card is full.

- **Cloud Storage:** Faleemi offers an optional cloud storage service, typically with a free trial period. This provides an off-site backup of your recordings, ensuring data security even if the camera is compromised.

5. MAINTENANCE

- **Cleaning:** Gently wipe the camera lens and body with a soft, dry cloth. Avoid using harsh chemicals or abrasive cleaners.

- **Firmware Updates:** Periodically check the Faleemi Cloud App for available firmware updates. Keeping your camera's firmware up-to-date ensures optimal performance, security, and access to new features.

- **Outdoor Camera (FSC768):** Regularly inspect the mounting and power cable for any signs of wear or

damage, especially after severe weather conditions.

Figure 7: Outdoor Camera Weatherproof Feature. This image highlights the IP66 weatherproof rating of the outdoor camera, showing it functioning reliably in rainy conditions.

6. TROUBLESHOOTING

- **Camera Offline:**
  - Check if the camera is powered on and the power adapter is securely connected.
  - Ensure your Wi-Fi router is working and the camera is within Wi-Fi range.
  - Restart the camera and your Wi-Fi router.
  - If the issue persists, try re-pairing the camera with the app.

- **Poor Video Quality:**
  - Check your Wi-Fi signal strength. A weak signal can affect video streaming quality.
  - Ensure the camera lens is clean and free from dust or smudges.
  - Verify that the camera is set to 1080P resolution in the app settings.

- **Motion Alerts Not Received:**
    - Ensure motion detection is enabled in the app settings for the specific camera.
    - Check your phone's notification settings to ensure the Faleemi Cloud App is allowed to send notifications.
    - Adjust motion detection sensitivity if necessary.
- **Two-Way Audio Issues:**
    - Ensure your phone's microphone and speaker are working correctly.
    - Check the volume settings in the app and on your phone.
    - Minimize background noise for clearer communication.

7. SPECIFICATIONS

Feature	Specification
Video Capture Resolution	1080p Full HD
Connectivity Technology	Wireless (Wi-Fi)
Wi-Fi Frequency	2.4GHz (5GHz not supported)
Indoor/Outdoor Usage	Indoor (FSC776A), Outdoor (FSC768)
Weatherproof Rating (FSC768)	IP66
Motion Detection	Yes, with instant alerts
Night Vision	Yes
Two-Way Audio	Yes (Built-in microphone and speaker)
Storage Options	Micro SD Card (up to 128GB), Cloud Storage (optional)
Pan & Tilt (FSC776A)	340° Horizontal, 120° Vertical
Material (FSC768)	Aluminum Alloy
Compatible Devices	Smartphone (Android, iOS)
Mounting Type	Wall Mount

8. WARRANTY AND SUPPORT

Faleemi products are designed for reliability and performance. For specific warranty information, please refer to the warranty card included with your product packaging or visit the official Faleemi website. If you encounter any issues or require technical assistance, please contact Faleemi customer support through the contact information provided on their website or within the Faleemi Cloud App.