

Manuals.plus /

› Carrera /

› Carrera RC Nintendo Mario Kart Gold Mario Mini RC Car Instruction Manual

Carrera 370430001

Carrera RC Nintendo Mario Kart Gold Mario Mini RC Car Instruction Manual

Model: 370430001

1. INTRODUCTION

This manual provides essential information for the safe and optimal operation of your Carrera RC Nintendo Mario Kart 2.4 GHz Mini Collectible Radio Remote Control Toy Car Vehicle - Gold Mario Edition. Please read these instructions carefully before first use and keep them for future reference.

The Carrera RC Mario Kart Mini RC Car is an officially licensed Nintendo product, designed for fun and collecting. It features 2.4 GHz radio control technology for interference-free operation and comes ready to run with all necessary batteries included.

2. WHAT'S IN THE BOX

Your package should contain the following items:

- Mini Collectible RC Car (Gold Mario)
- Remote Controller
- Charging Cable
- 1 Lithium Polymer Battery (pre-installed in car)
- Jewel Display Case



Image: The Carrera RC Mario Kart Gold Mario Mini RC Car, remote controller, and clear jewel display case as packaged.

3. SETUP

3.1. Battery Installation (Remote Controller)

The remote controller requires batteries (included). Locate the battery compartment on the back of the remote controller. Use a small Phillips screwdriver to open the compartment. Insert the batteries, ensuring correct polarity (+/-). Close the compartment and secure it with the screw.

3.2. Charging the RC Car

The RC car contains a rechargeable Lithium Polymer battery. Connect the provided charging cable to the car's charging port and to a USB power source (e.g., computer USB port, USB wall adapter). The indicator light on the charging cable will show the charging status. A full charge typically takes approximately 30 minutes and provides up to 7 minutes of playtime.



Image: The remote controller with the mini RC car securely stored in its transparent top compartment.

4. OPERATING INSTRUCTIONS

4.1. Powering On/Off

- To turn on the RC car, locate the ON/OFF switch on the underside of the car and slide it to the 'ON' position.
- To turn on the remote controller, slide the ON/OFF switch on the controller to the 'ON' position. An indicator light on the controller will illuminate.
- To turn off, slide both switches to the 'OFF' position.

4.2. Controls

The remote controller features two joysticks for movement:

- **Left Joystick:** Controls forward and backward movement. Push forward to accelerate, pull back to reverse.
- **Right Joystick:** Controls steering. Push left to turn left, push right to turn right.

For optimal performance, operate the RC car on smooth, flat surfaces. Avoid carpets or rough terrain that may impede movement.

5. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the car and controller. Do not use water or chemical cleaners. Regularly check the wheels for any accumulated dust or hair, as this can affect performance.
- **Storage:** When not in use, store the RC car in its clear jewel display case or within the remote

controller's storage compartment to protect it from dust and damage. Store in a cool, dry place away from direct sunlight.

- **Battery Care:** Always turn off the car and controller when not in use. For long-term storage, it is recommended to fully charge the car's battery and remove batteries from the remote controller.



Image: The remote controller with the mini RC car stored, highlighting the convenient belt clip for portability.

6. TROUBLESHOOTING

- **Car not responding:** Ensure both the car and controller are switched ON. Check that the car's battery is charged and the controller's batteries are correctly installed and not depleted. Ensure you are within the operating range (2.4 GHz technology allows for a good range, but extreme distances or interference can affect connection).
- **Poor performance/slow movement:** Recharge the car's battery. Clean any debris from the wheels and axles. Ensure the car is being operated on a suitable surface.
- **Interference:** The 2.4 GHz technology minimizes interference, but if issues occur, try operating in a different location away from other electronic devices.

7. SPECIFICATIONS

- **Product Dimensions:** 2.5 x 1.5 x 1.75 inches
- **Item Weight:** 15.8 ounces
- **Model Number:** 370430001
- **Manufacturer Recommended Age:** 6 years and up
- **Batteries:** 1 Lithium Polymer battery required (included)
- **Radio Control Frequency:** 2.4 GHz
- **Scale:** 1:50



Image: A top-down perspective of the Gold Mario mini RC car, showcasing its detailed design and compact form factor.

8. SAFETY INFORMATION

WARNING: CHOKING HAZARD - Small Parts. Not for children under 3 years.

Always supervise children during play. Do not operate the RC car near stairs, roads, or other hazardous areas. Avoid contact with water. Do not attempt to modify or disassemble the product, as this may cause damage or injury and will void the warranty.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included in your product packaging or visit the official Carrera website. Keep your proof of purchase for any warranty claims.