



[Manuals.plus](#) /

> [Home Aesthetics](#) /

> Home Aesthetics Rolling Kitchen Island Cart Instruction Manual - Model B08YS7CBSH

Home Aesthetics B08YS7CBSH

Home Aesthetics Rolling Kitchen Island Cart Instruction Manual

Model: B08YS7CBSH

Brand: Home Aesthetics

INTRODUCTION

Thank you for purchasing the Home Aesthetics Rolling Kitchen Island Cart. This manual provides detailed instructions for assembly, operation, and maintenance to ensure safe and efficient use of your new kitchen cart. Please read all instructions carefully before assembly and retain this manual for future reference.

SAFETY INFORMATION

- Always assemble the unit on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Do not overtighten to avoid damaging the bamboo.
- Do not exceed the maximum weight capacity of 110 lbs.
- Keep small parts away from children during assembly.
- Use the locking casters to stabilize the cart when it is in a stationary position.
- This product is intended for indoor use only.

PACKAGE CONTENTS

Please verify that all parts listed below are present before beginning assembly:

- Top Panel (1)
- Side Panels (2)
- Slatted Shelves (2)
- Drawers (2)

- Towel Rack (1)
- Locking Casters (2)
- Non-Locking Casters (2)
- Assembly Hardware (Screws, Allen Wrench)

ASSEMBLY INSTRUCTIONS

Follow these steps carefully for proper assembly. An assembly video is provided for visual guidance.

Your browser does not support the video tag.

Official assembly video for the Home Aesthetics 503307 Bamboo Kitchen Cart. This video demonstrates the step-by-step process of putting together the kitchen island cart, including drawer and shelf installation.

1. Step 1: Assemble the Drawers

Begin by assembling the two drawers. Ensure the grooves for the drawer bottom are facing inwards and downwards. Secure the sides using the provided screws. Attach the handles to the front panels of the drawers.



Image showing the fully assembled kitchen cart, highlighting the drawers and overall structure.

2. Step 2: Attach Casters to Base

Carefully attach the four casters to the bottom of the main frame. It is recommended to place the two locking casters on one side (e.g., the front) for easier access when locking/unlocking. Use the provided screws and Allen wrench to secure them firmly.



Close-up view of one of the locking caster wheels attached to the bamboo leg, showing the 'ON' and 'OFF' positions for the lock.

3. Step 3: Assemble Side Panels and Shelves

Connect the side panels to the slatted shelves. Ensure the shelves are oriented correctly, with the wider support bars facing upwards. Secure with screws.



Side view of the kitchen cart, showcasing the two slatted shelves and the overall bamboo construction.

4. Step 4: Attach Towel Rack

Attach the towel rack to one of the side panels using the designated holes and screws. Ensure it is securely fastened.



Detailed image of the towel rack attached to the side of the kitchen cart, providing a convenient hanging spot.

5. **Step 5: Install Drawers and Top Panel**

Slide the assembled drawers into their respective slots. Finally, place the butcher block top panel onto the assembled frame and secure it with the remaining screws from underneath.



Front view of the kitchen cart with key dimensions labeled, including overall height, width, and depth, as well as drawer size.

OPERATING INSTRUCTIONS

- **Mobility:** To move the cart, unlock the casters by flipping the levers to the 'OFF' position.
- **Stability:** To keep the cart stationary, lock the casters by flipping the levers to the 'ON' position.
- **Storage:** Utilize the drawers for small kitchen essentials and the open shelves for larger items or appliances. The towel rack is ideal for dishcloths or aprons.
- **Work Surface:** The bamboo top can be used as an additional work surface for food preparation or serving.

MAINTENANCE

- **Cleaning:** Wipe the bamboo surfaces with a damp cloth and mild soap. Dry immediately. Do not use abrasive cleaners.
- **Wood Care:** Periodically apply food-grade mineral oil to the bamboo top to maintain its luster and prevent drying.
- **Avoid Moisture:** Do not allow water to stand on the bamboo surfaces for extended periods.
- **Inspection:** Regularly check all screws and fasteners to ensure they remain tight. Retighten if necessary.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Cart is wobbly	Loose screws or uneven casters.	Check and tighten all assembly screws. Ensure casters are fully inserted and locked if stationary.
Drawers stick or don't slide smoothly	Misalignment during assembly or debris in grooves.	Recheck drawer assembly. Clean drawer grooves of any obstructions. Apply a small amount of wax to the runners if needed.
Casters not locking/rolling	Locking mechanism engaged/disengaged incorrectly.	Ensure the caster levers are fully flipped to the desired 'ON' or 'OFF' position. Clean any debris from the wheels.

SPECIFICATIONS

- **Product Dimensions:** 29"D x 21.5"W x 35"H
- **Material:** Bamboo
- **Item Weight:** 44 Pounds
- **Maximum Weight Recommendation:** 110 Pounds
- **Number of Shelves:** 2
- **Furniture Finish:** Varnished Bamboo
- **Color:** Natural

WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the product packaging or contact Home Aesthetics customer service directly. Specific warranty details are not provided in this manual.