

- Manuals.plus /
- › Sleepbox /
- › Sleepbox Sound White Noise Machine User Manual

Sleepbox B08YYMQ23J

Sleepbox Sound White Noise Machine User Manual

Model: B08YYMQ23J

- Overview
- Setup
- Introduction
- Operation
- Safety Information
- Maintenance
- Package Contents
- Troubleshooting
- Product
- Specifications
- Warranty & Support

1. INTRODUCTION

The Sleepbox Sound White Noise Machine is designed to create a calming environment for improved sleep and relaxation. It features a selection of soothing sounds, a multi-color night light, adjustable brightness and volume levels, and convenient timer functions. Its compact design makes it suitable for use at home or while traveling.



Figure 1: The Sleepbox Sound White Noise Machine is versatile for various environments, including travel, work, sleep, and relaxation.

2. SAFETY INFORMATION

Please read and understand all safety instructions before using this product. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- This product is not a toy and should be kept out of reach of children.
- Use only the recommended power source and voltage specified for this device.
- To prevent electric shock, do not expose the device to water or moisture.
- Do not disassemble, repair, or modify the device yourself. Contact qualified service personnel for assistance.
- Ensure proper ventilation around the device; do not cover it during operation.
- Set the volume to an appropriate level to avoid hearing damage.
- Handle with care to avoid physical damage to the unit.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- Sleepbox Sound White Noise Machine
- USB Power Cable
- Power Adapter
- User Manual (this document)



Figure 2: The Sleepbox Sound White Noise Machine, USB power cable, and power adapter included in the box.

4. PRODUCT OVERVIEW

Familiarize yourself with the device's components and controls.



Figure 3: Top view of the Sleepbox Sound White Noise Machine, highlighting the control buttons and the night light ring.

Control Buttons:

- **Power Button (⏻):** Turns the device On/Off.
- **Light Button (☀️):** Cycles through night light colors and adjusts brightness.
- **Timer Button (⌚):** Sets the auto-off timer (1H, 2H, 3H, 4H, Continuous).
- **Volume Down Button (-):** Decreases the sound volume.
- **Volume Up Button (+):** Increases the sound volume.
- **Previous Sound Button (⏮):** Selects the previous sound.
- **Next Sound Button (⏭):** Selects the next sound.

5. SETUP

5.1 Power Connection

1. Connect the small end of the USB power cable to the power input port on the Sleepbox Sound White Noise Machine.
2. Connect the large end of the USB power cable to the provided power adapter.
3. Plug the power adapter into a standard electrical outlet.
4. The device is now ready for use.

6. OPERATION

6.1 Power On/Off

- Press the **Power Button** () to turn the device on.
- Press the **Power Button** () again to turn the device off.

6.2 Sound Selection

The device offers 25 non-looping soothing sounds.

- Press the **Next Sound Button** () to cycle through the available sounds.
- Press the **Previous Sound Button** () to go back to the previous sound.
- Available sounds include: White Noise, Pink Noise, Brown Noise, Blue Noise, Fans, Rain, Brook, Sea Wave, Bird, Campfire, Train, Piano, and more.



Figure 4: Visual representation of the 25 soothing sounds available on the device.

6.3 Volume Adjustment

The device has 32 adjustable volume levels.

- Press the **Volume Up Button (+)** to increase the volume.
- Press the **Volume Down Button (-)** to decrease the volume.

6.4 Night Light Function

The device features a night light with 10 colors and 4 brightness levels.

- Press the **Light Button (*)** to turn on the night light and cycle through the 10 available colors.
- To adjust brightness, press and hold the **Light Button (*)**. The brightness will cycle through 4 levels. Release the button at the desired brightness.
- Press the **Light Button (*)** repeatedly to turn off the light after cycling through all colors.

10 Colors Night Light




Figure 5: The device's night light feature showcasing 10 distinct colors.

4

Adjustable Brightness Levels



Figure 6: The four adjustable brightness levels of the night light.

6.5 Timer Function

The auto-off timer can be set for 1, 2, 3, or 4 hours, or for continuous play.

- Press the **Timer Button** () repeatedly to cycle through the timer options: 1H, 2H, 3H, 4H, and Continuous (indicated by an infinity symbol ∞).
- The device will automatically turn off after the selected time period, or play continuously if ∞ is selected.

6.6 Memory Function

The device remembers your last used volume, sound, and timer settings.

- When the Sleepbox Sound White Noise Machine is restarted, it will automatically resume with the settings that were active before it was turned off.

5 Timers & Memory Function

1H 2Hs 3Hs 4Hs Cont.



Figure 7: The timer and memory functions provide convenience for consistent sleep environments.

7. MAINTENANCE

7.1 Cleaning

- Ensure the device is unplugged before cleaning.
- Wipe the exterior of the device with a soft, dry cloth.
- Do not use abrasive cleaners, waxes, or solvents as they may damage the finish.
- Avoid getting moisture into any openings.

7.2 Storage

- Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- Keep the device away from dust and dirt when not in use for extended periods.

8. TROUBLESHOOTING

If you encounter issues with your Sleepbox Sound White Noise Machine, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device does not turn on.	No power connection.	Ensure the power cable is securely connected to the device and the power adapter is plugged into a working electrical outlet.
No sound.	Volume is too low or muted.	Press the Volume Up Button (+) to increase the volume.
Night light not working.	Light function is off.	Press the Light Button (*) to turn on and cycle through light options.
Device turns off unexpectedly.	Timer function is active.	Check the timer setting. If continuous play is desired, set the timer to ∞ .

9. SPECIFICATIONS

- **Model:** B08YYMQ23J
- **Product Dimensions:** 4.13 x 4.13 x 2.6 inches
- **Item Weight:** 10.93 ounces (0.31 Kilograms)
- **Sound Options:** 25 non-looping soothing sounds
- **Volume Levels:** 32 adjustable levels
- **Night Light Colors:** 10 colors
- **Night Light Brightness:** 4 adjustable levels
- **Timer Settings:** 1H, 2H, 3H, 4H, Continuous
- **Material:** Plastic or Stainless Steel
- **Manufacturer:** Sleepbox

10. WARRANTY & SUPPORT

Sleepbox provides professional after-sales service. If you have any questions or require support regarding your Sleepbox Sound White Noise Machine, please do not hesitate to contact us. Refer to your purchase documentation or the Sleepbox official website for specific warranty details and contact information.

Legal Disclaimer: Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition. This product is not a medical device.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08YYMQ23J>

More documents and user manuals: **<https://manuals.plus/>**