

- Manuals.plus /
- > Craftmade /
 - > Craftmade 52" Pro Plus P101-52 Indoor Ceiling Fan User Manual

Craftmade P101-52

Craftmade 52" Pro Plus P101-52 Indoor Ceiling Fan User Manual

Model: P101SB5-52BWNFB

- Overview
- Safety
- Contents
- Setup
- Operation
- Maintenance
- Troubleshooting
- Specifications
- Warranty
- Support

1. PRODUCT OVERVIEW

The Craftmade 52" Pro Plus P101SB5-52BWNFB Indoor Ceiling Fan is designed to provide efficient air circulation and illumination for various indoor spaces. This model features a satin brass finish with reversible blades (black walnut/flat black), an optional clear bowl light kit, and a 3-speed reversible motor. It is suitable for dual mount installations on flat or angled ceilings.



Image 1.1: The Craftmade 52-inch Pro Plus Indoor Ceiling Fan, showcasing its satin brass finish, clear bowl light kit, and reversible blades.

2. IMPORTANT SAFETY INFORMATION

Read all instructions carefully before installation and use. Failure to follow these instructions may result in electric shock, fire, or personal injury.

- **Electrical Safety:** Ensure power is disconnected at the circuit breaker before installation or servicing. All wiring must be in accordance with national and local electrical codes.
- **Mounting:** The fan must be mounted to a structurally sound ceiling joist or outlet box capable of supporting the fan's weight (19.7 lbs).
- **Blade Clearance:** Maintain a minimum clearance of 7 feet from the floor to the bottom of the fan blades.
- **Light Kit:** Use only the specified bulb type and wattage (2 x 7W Non-Dimmable LED Bulbs).
- **Professional Installation:** If you are unsure about wiring or installation, consult a qualified electrician.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- Motor Assembly
- Blades (5)
- Light Kit (Clear Bowl, 2 x 7W Non-Dimmable LED Bulbs)
- 4" Downrod
- Instruction Manual
- Parts Assembly (Hardware)

4. SETUP AND INSTALLATION

This section provides a general overview. For detailed, step-by-step instructions, please refer to the comprehensive Installation Manual PDF available for download from the product page or manufacturer's website.

4.1 Mounting Options

The fan supports dual mount installation, allowing it to be installed on either a flat ceiling or an angled ceiling. The included 4-inch downrod is required for installation.

4.2 Wiring and Assembly

Carefully follow the wiring diagrams provided in the full manual. Ensure all electrical connections are secure and properly insulated. When connecting wires within the canopy, manage excess wire length to prevent crowding and facilitate secure attachment of the canopy to the mounting bracket. This step requires careful attention to detail.



Image 4.1: Side view of the Craftmade 52-inch Pro Plus Ceiling Fan, illustrating the downrod and blade attachment points.

4.3 Blade Attachment

Attach the five blades to the motor assembly. The blades are reversible, offering a choice between black walnut and flat black finishes. Select your desired finish before securing the blades.

4.4 Light Kit Installation

Install the clear glass bowl light kit and the two 7W non-dimmable LED bulbs according to the manual's instructions. Ensure the glass bowl is securely fastened.

5. OPERATING INSTRUCTIONS

The Craftmade Pro Plus ceiling fan offers convenient control over fan speed and lighting.

5.1 Fan Speed Control

The fan features a standard 3-speed reversible motor. You can adjust the fan speed using the pull chain control or an optional remote control (if installed). Pull the chain repeatedly to cycle through high, medium, low, and off settings.

5.2 Light Operation

The clear bowl light kit is operated by a separate pull chain or the optional remote control. Pull the chain to turn the light on or off.

5.3 Reversible Motor Function

A slide switch on the fan's motor housing controls the blade direction. In warm weather, set the switch to circulate air downwards, creating a cooling effect. In cool weather, set the switch to circulate air upwards, helping to distribute warm air evenly without creating a direct draft. Always turn off the fan and wait for the blades to stop completely before changing the direction of rotation.

6. MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your ceiling fan.

- **Cleaning:** To clean the fan, wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these may damage the

finish or electrical components.

- **Glass Bowl Cleaning:** The clear glass bowl may show dirt easily. For best results, carefully remove the glass bowl and wash it with mild soap and water. Dry thoroughly before reattaching. Avoid harsh chemicals that could streak or etch the glass.
- **Blade Cleaning:** Dust the fan blades regularly with a soft cloth or duster.
- **Tighten Fasteners:** Periodically check and tighten all screws and fasteners on the fan housing and blade attachments to prevent wobbling and noise.

7. TROUBLESHOOTING

Before attempting any repairs, ensure power is disconnected at the circuit breaker.

Problem	Possible Cause	Solution
Fan does not start	No power to fan; Loose wire connections; Motor switch off	Check circuit breaker; Verify all wire connections are secure; Ensure pull chain is set to an ON position.
Light does not work	Bulbs loose or burned out; Loose wire connections	Tighten or replace bulbs; Check light kit wiring.
Fan wobbles	Loose blade screws; Unbalanced blades; Loose mounting bracket	Tighten all blade screws; Check blade balance (use a balancing kit if necessary); Ensure mounting bracket is securely fastened to the ceiling.
Noisy operation	Loose screws; Motor housing rubbing; Incorrect installation	Check and tighten all screws; Ensure no parts are rubbing; Re-check installation steps.

8. PRODUCT SPECIFICATIONS

Brand	Craftmade
Model Number	P101SB5-52BWNFB
Size	52 inches
Color	Satin Brass
Blade Material	MDF (Reversible Black Walnut/Flat Black)
Number of Blades	5
Motor	Standard, 3-Speed Reversible
Light Kit	Clear Bowl, 2 x 7W Non-Dimmable LED Bulbs
Control Type	Pull Chain Control, Remote Control (optional)
Mounting Type	Dual Mount (Flat or Angled Ceiling)
Downrod Included	4 inches
Voltage	120 volts
Item Weight	19.7 pounds
Product Dimensions (D x W x H)	52"D x 52"W x 17.69"H
Indoor/Outdoor Usage	Indoor

9. WARRANTY INFORMATION

All products purchased have a 30-day replacement parts policy to ensure a fully working item. All products are covered under a 1-year warranty when purchased on Amazon. The warranty period begins on the day the product is originally shipped. The warranty covers all items and conditions identified in the original manufacturer's warranty.

Items specifically **not covered** by the warranty include loss and theft, water damage, customer abuse, and finish deterioration due to UV or coastal exposure.

10. CUSTOMER SUPPORT

For technical assistance, warranty claims, or any questions regarding your Craftmade 52" Pro Plus Indoor Ceiling Fan, please contact customer support:

Phone: (800) 486-4892

Please have your model number (P101SB5-52BWNFB) and purchase date available when contacting support.

© 2023 Craftmade. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08YZ675XP>

More documents and user manuals: <https://manuals.plus/>