

[Manuals.plus](#) /

› [Craftmade](#) /

› Craftmade CPT52FB5 Captivate Modern 52" Indoor/Outdoor Damp Location Ceiling Fan Instruction Manual

Craftmade CPT52FB5

Craftmade CPT52FB5 Captivate Modern 52" Indoor/Outdoor Damp Location Ceiling Fan Instruction Manual

Model: CPT52FB5

1. INTRODUCTION

This manual provides comprehensive instructions for the safe installation, operation, and maintenance of your Craftmade CPT52FB5 Captivate Modern 52-inch Indoor/Outdoor Damp Location Ceiling Fan. Please read all instructions carefully before beginning installation and retain this manual for future reference.

The Craftmade Captivate ceiling fan features a 52-inch span, 5 solid wood blades, and an energy-saving, six-speed reversible DC motor, suitable for both indoor and damp outdoor locations.

2. SAFETY INFORMATION

WARNING: To reduce the risk of fire, electric shock, or personal injury, always follow these essential safety guidelines:

- Before installation, disconnect power at the main circuit breaker or fuse box to prevent electrical shock.
- All wiring must be in accordance with national and local electrical codes. If you are unfamiliar with wiring, consult a qualified electrician.
- The fan must be mounted to a structurally sound outlet box marked "Acceptable for Fan Support of 35 lbs (15.9 kg) or less" and supported directly from the building structure.
- Ensure the installation site allows for a minimum 7 feet (2.1 meters) clearance from the floor to the blade trailing edge.
- Do not operate the fan with damaged blades or housing.
- Avoid placing objects in the path of the fan blades.
- This fan is rated for damp locations. Do not expose to direct water spray.
- Proposition 65 Warning: This product may expose you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, go to www.P65Warnings.ca.gov.

3. PACKAGE CONTENTS

Verify that all components listed below are included in your package. If any parts are missing or damaged, contact Craftmade customer support.

- Motor Housing Assembly
- 5 Solid Wood Blades
- Downrod (6-inch)
- Canopy
- Mounting Bracket
- Remote Control with Wall Mount
- Installation Hardware (screws, washers, wire nuts)
- Installation Guide



Image 1: Craftmade CPT52FB5 Captivate Modern 52" Ceiling Fan in Flat Black finish. This image displays the complete fan assembly, including the motor housing, five blades, downrod, and canopy, providing a visual reference for the product.

4. SETUP AND INSTALLATION

This section outlines the general steps for installing your ceiling fan. Refer to the included detailed installation guide for specific diagrams and safety precautions.

1. **Prepare for Installation:** Ensure power is OFF at the circuit breaker. Clear the work area.
2. **Mounting Bracket Installation:** Secure the mounting bracket to the ceiling outlet box. The outlet box must be rated for fan support (35 lbs or 15.9 kg).
3. **Downrod Assembly:** Insert the downrod through the canopy and connect it to the motor housing. Feed electrical wires through the downrod.
4. **Hang the Fan:** Carefully lift the fan assembly and hang it from the mounting bracket.
5. **Electrical Connections:** Connect the fan's electrical wires to the household wiring according to the wiring diagram in the detailed installation guide. Ensure all connections are secure with wire nuts.
6. **Canopy Installation:** Secure the canopy to the mounting bracket, covering the electrical connections.
7. **Blade Attachment:** Attach the five solid wood blades to the motor housing using the provided screws. Ensure all blades are securely fastened.
8. **Final Checks:** Double-check all connections and ensure no wires are pinched. Restore power at the circuit breaker.

5. OPERATING INSTRUCTIONS

Your Craftmade Captivate ceiling fan is operated using the included remote control.

5.1 Remote Control Functions

- **Power Button:** Turns the fan ON or OFF.
- **Fan Speed Buttons:** Adjusts the fan speed through 6 available levels. Press to cycle through speeds or select a specific speed.
- **Reverse Function Button:** Changes the direction of blade rotation.
 - **Downward Airflow (Summer Mode):** Blades rotate counter-clockwise, creating a cooling breeze.
 - **Upward Airflow (Winter Mode):** Blades rotate clockwise, circulating warm air trapped near the ceiling.

5.2 Battery Installation

The remote control requires batteries (Alkaline type, included). Open the battery compartment on the back of the remote and insert the batteries, observing correct polarity.

6. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your ceiling fan.

- **Cleaning:** Use a soft, damp cloth to clean the fan. Do not use abrasive cleaners or solvents, as these can damage the finish or blades.
- **Blade Inspection:** Periodically check the blade screws for tightness. Loose screws can cause wobbling and noise.
- **Motor:** The fan's DC motor is permanently lubricated and requires no additional oiling.
- **Damp Location Care:** For outdoor or damp location use, ensure the fan is kept clean and dry as much as possible to prevent corrosion.

7. TROUBLESHOOTING

If you experience issues with your fan, consult the following troubleshooting guide before contacting customer support.

Problem	Possible Cause	Solution
Fan does not start	No power to the fan. Loose wire connections. Remote control batteries are dead or incorrectly installed.	Check circuit breaker/fuse. Verify all wire connections are secure (ensure power is off first). Replace remote batteries; check polarity.
Fan wobbles	Loose blade screws. Fan not securely mounted to the outlet box. Blades are unbalanced.	Tighten all blade screws. Ensure mounting bracket and fan are securely attached. Use a blade balancing kit (not included) if necessary.
Remote control not working	Dead or incorrectly installed batteries. Interference from other devices.	Replace batteries, check polarity. Ensure no obstructions between remote and fan receiver.

8. SPECIFICATIONS

Model Name	Captivate
Model Number	CPT52FB5
Brand	Craftmade
Dimensions (D x W x H)	52"D x 52"W x 12.76"H
Blade Length	52 Inches
Number of Blades	5
Air Flow Capacity	5431 Cubic Feet Per Minute (CFM)
Power Source	AC (120 Volts)
Wattage	24 Watts
Control Method	Remote Control (6 Power Levels, Reverse Function)
Indoor/Outdoor Usage	Outdoor (Damp Location ETL Approved)
Item Weight	12.28 Pounds
Batteries Required	Yes (Alkaline, included)
UPC	647881221553

9. WARRANTY AND SUPPORT

9.1 Warranty Information

All products purchased have a 30-day replacement parts policy to ensure a fully working item. All products are covered under a 1-Year warranty when purchased on Amazon. The warranty period begins on the day the product is originally shipped. The warranty covers all items and conditions identified in the original manufacturer's warranty. Items specifically not covered by the warranty include loss and theft, water damage, customer abuse, and finish deterioration due to UV or coastal exposure.

9.2 Customer Support

For technical assistance, warranty claims, or missing parts, please contact Craftmade Customer Support:

Phone: [\(800\) 486-4892](tel:8004864892)

Online: Visit the [Craftmade Store on Amazon](#) for more information and support resources.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08YZ78N2J>

More documents and user manuals: **<https://manuals.plus/>**