

Consfly B08Z3BFN8J

Consfly Automatic Soybean Milk Maker

Model: B08Z3BFN8J

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using the appliance. Retain this manual for future reference.

- Always ensure the appliance is connected to a 110V power supply.
- Do not immerse the main engine unit in water or other liquids.
- Keep hands and utensils out of the blender jar while blending to prevent injury.
- Ensure the lid is securely closed before operation. The appliance features a safety micro switch that prevents operation if the lid is open.
- Do not lift the cup during operation. A micro switch in the cup holder will automatically stop the machine if the cup is lifted.
- The motor is equipped with over-voltage protection and will automatically stop if overheating occurs. Allow the unit to cool down before resuming use.
- Exercise caution when handling hot liquids or steam.
- This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

TRIPLE SAFETY PROTECTION



Shutdown when opening the lid:
a micro switch is provided at the top of the handle,
and the machine will shut down when the lid is opened.



Shutdown when lifting the cup:
The cup holder is equipped with a micro switch,
and the cup is automatically stopped when the cup is lifted.



Overheating shutdown:
The motor is equipped with overvoltage protection,
and the motor will automatically stop if it is overheated.



Image: Triple Safety Protection features, including lid open shutdown, cup lift shutdown, and overheating protection.

2. PRODUCT OVERVIEW AND COMPONENTS

The Consfly Automatic Soybean Milk Maker is a versatile appliance designed for preparing various beverages and pastes. Familiarize yourself with its components for proper use.

PRODUCT STRUCTURE



Image: Labeled diagram of the product components.

Components:

- **Small Cover:** Used to cover the filling port and release steam.
- **Bowl Cover:** Must be tightly closed to activate electromagnetic induction for heating.
- **Cup Lid Sealing Ring:** Ensures a tight seal to prevent overflow.
- **Glass Cup Body:** Made of high borosilicate glass with built-in graduation lines for measurement.
- **Cup Base:** Contains the heating plate and the blending blade.
- **Lower Coupler:** Connects the cup to the main engine.
- **Operation Panel:** Touch-sensitive interface for selecting functions.
- **Main Engine:** Houses the motor and electronic controls.



3-layer 6-leaf stainless steel blade

Food grade material + reasonable blade angle to ensure a delicate taste, healthy and delicious

Image: Detail of the 3-layer, 6-leaf stainless steel blending blade.

The appliance features a 3-layer, 6-leaf stainless steel blending blade designed for efficient and smooth processing of ingredients.

3. SPECIFICATIONS

Technical details of the Consfly Automatic Soybean Milk Maker.



Image: Product specifications and dimensions.

Feature	Detail
Model	B08Z3BFN8J
Brand	Consfly
Voltage	110V
Stirring Power	300W
Heating Power	600W
Operating Mode	Touch Control
Capacity (Cold Drink)	0.8 Liters (27 oz)
Capacity (Hot Drink)	0.7 Liters
Material	Stainless Steel (Blade), High Borosilicate Glass (Cup Body)
Special Feature	Portable
Item Weight	1.98 Kilograms
Dishwasher Safe	Yes (Cup Body)

4. SETUP AND ASSEMBLY

Follow these steps to correctly assemble your soybean milk maker before first use.

Cup Lid Installation Steps:

1. Pick up the lid of the cup in the direction shown in the diagram.
2. Align the cup buckle and press it firmly. Ensure the cup cover protruding edge and the handle buckle are in the same direction.
3. Rotate the lid so that the protruding edge of the lid overlaps the handle. A mechanical sound will indicate it is locked.
4. When the cup body is placed on the main unit and the power is turned on, you will hear a beep when you close the lid correctly.

Cup Body Installation Steps:

1. Before installing the cup, ensure the lower coupler of the host and the upper coupler of the cup are dry and free from water.
2. Align the lower coupler of the host with the upper coupler of the cup body as shown in the figure, and gently press down to secure.

CUP LID INSTALLATION STEPS



1. Pick up the lid of the cup in the direction shown.



2. Align the cup buckle and press it firmly, the cup cover protruding edge and the handle buckle are in the same direction (as shown in the picture).



3. Rotate the lid so that the protruding edge of the lid overlaps the handle. When overlapped, a mechanical sound of "di" will be heard.



4. When the cup body is on the main unit and the power is turned on, you will hear a beep when you close the lid.

CUP BODY INSTALLATION STEPS



1. Before installing the cup, make sure that the lower coupler of the host and the upper coupler of the cup are dry and free from water.



2. Align the lower coupler of the host with the upper coupler of the cup body as shown in the figure.

Image: Detailed steps for cup lid and cup body installation.

5. OPERATING INSTRUCTIONS

This appliance offers 16 major function menus for various preparations. Ensure the unit is properly assembled and plugged into a 110V outlet before operation.

Basic Operation:

1. Add desired ingredients to the glass cup body, observing the maximum fill lines.
2. Securely install the cup lid and place the cup body onto the main engine. Ensure you hear a beep indicating proper connection.
3. Plug the appliance into a power outlet. The display will illuminate.

4. Use the touch control operation panel to select your desired function from the 16 available menus (e.g., Soybean Milk, Corn Juice, Rice Paste, Fish Soup, etc.).
5. Press the 'Start' button to begin the selected program. The smart chip will accurately control temperature and blending cycles.
6. Once the program is complete, the appliance will signal. Carefully remove the cup and pour out the contents.

Intelligent Appointment Function:

The 12-hour intelligent appointment feature allows you to set a delayed start time for your preparations.

1. Prepare your ingredients and load them into the cup as usual.
2. Select your desired function.
3. Press the 'Preset' or 'Appointment' button (refer to the control panel diagram for exact labeling) and set the desired delay time using the adjustment buttons.
4. Confirm the setting. The appliance will start automatically after the set delay, allowing you to have fresh preparations ready at your convenience.



Image: Illustration of the 12-hour intelligent appointment function.

Versatile Use:

This appliance is capable of making a variety of items, including:

- Soybean Milk
- Corn Juice
- Rice Paste
- Fish Soup
- Complementary Food
- And more, depending on the 16 available functions.



Image: Examples of various preparations possible with the appliance.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the lifespan of your appliance.

Cleaning the Cup Body and Lid:

- After each use, unplug the appliance and allow it to cool down.
- Remove the cup body and lid. The glass cup body and lid are dishwasher safe.
- Alternatively, wash them by hand using warm, soapy water and a non-abrasive sponge. Rinse thoroughly and dry completely.
- Be careful when cleaning around the blade area.

Cleaning the Main Engine Unit:

- Wipe the exterior of the main engine unit with a damp cloth. Do not use abrasive cleaners or immerse the unit in

water.

- Ensure the lower coupler area is clean and dry before reassembling the cup.

7. TROUBLESHOOTING

If you encounter issues with your appliance, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Appliance does not start.	1. Power cord not securely plugged in. 2. Cup lid not properly closed. 3. Cup body not correctly seated on the main engine. 4. Overheating protection activated.	1. Check power connection. 2. Ensure lid is securely closed and you hear a beep. 3. Realign and firmly place the cup body on the main engine. 4. Unplug and allow the unit to cool down for at least 30 minutes before restarting.
Machine stops during operation.	1. Cup was lifted during operation. 2. Overheating protection activated.	1. Do not lift the cup during operation. Re-seat the cup firmly. 2. Unplug and allow the unit to cool down for at least 30 minutes before restarting.
Ingredients are not blended smoothly.	1. Too many ingredients. 2. Insufficient liquid. 3. Ingredients are too hard or large.	1. Reduce the amount of ingredients. 2. Add more liquid as per recipe. 3. Cut hard ingredients into smaller pieces.
Leakage from the lid.	1. Lid not properly sealed. 2. Overfilling the cup.	1. Ensure the lid is securely closed and the sealing ring is correctly in place. 2. Do not exceed the maximum fill line indicated on the cup.

8. WARRANTY AND SUPPORT

Consfly products are manufactured to high-quality standards. For warranty information, technical support, or service inquiries, please refer to the contact information provided at the point of purchase or visit the official Consfly website. Please retain your proof of purchase for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question