Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MEMBER´S MARK KB0773000

Members Mark Elegant Family Pool Instruction Manual

Model: KB0773000 | Brand: MEMBER´S MARK

1. Safety Information

WARNING: This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, go to www.P65Warnings.ca.gov.

Always ensure adult supervision when children are in or around the pool. This pool is designed for family use, including children, but requires constant adult oversight to prevent drowning or injury.

- Do not leave children unattended in or near the pool.
- Ensure the pool is placed on a level, stable surface free of sharp objects.
- Do not dive or jump into the pool.
- Maximum weight recommendation for the pool is 300 pounds.
- Empty the pool completely after each use if not equipped with a filtration system, or if it will be left unattended for an extended period.

2. Product Overview

Product Description

The Members Mark Elegant Family Pool is a spacious inflatable pool designed for family enjoyment. It features two air-cushioned backrests and comfortable seats for enhanced relaxation. Constructed from durable and puncture-resistant PVC material, this pool is built for longevity. It includes a convenient 2-in-1 valve for easy inflation and deflation, and a drain plug for simple water removal.

Key Features

- Two air-cushioned backrests and comfortable seats for extra comfort.
- 2-in-1 valve for easy inflation and deflation.
- Made with durable and puncture-resistant materials.
- Includes a drain plug for easy drainage of water.
- Includes a repair patch for minor punctures.

Package Contents

- 1 x Members Mark Elegant Family Pool
- 1 x Repair Patch



Image 1: Top-down view of the Members Mark Elegant Family Pool, showcasing its rectangular shape with rounded corners and integrated seating areas.



Image 2: Angled view of the Members Mark Elegant Family Pool, highlighting its blue and white design and the two inflatable backrests.



Image 3: Close-up view of one of the inflatable seats and backrests within the pool, showing the mosaic tile pattern on the interior.



Image 4: The retail packaging for the Members Mark Elegant Family Pool, displaying key features and dimensions.



Image 5: A family enjoying the Members Mark Elegant Family Pool in a backyard setting, demonstrating its capacity for multiple users.

3. Setup

Site Selection

1. Choose a flat, level area in your backyard or garden. The surface must be free of rocks, sharp objects, or debris that could puncture the pool.
2. Ensure the chosen area is large enough to accommodate the inflated pool dimensions (120"L x 110"W x 26"H) with additional space around it for safe access.
3. Avoid setting up the pool under trees that may drop leaves or debris into the water, or near electrical outlets.

Inflation

1. Unfold the pool and lay it flat on the prepared surface.
2. Locate the 2-in-1 inflation/deflation valves on each chamber of the pool.

3. Open the valve cap and insert an air pump nozzle (not included) into the larger opening of the valve.
4. Inflate each chamber until it is firm to the touch but not overinflated. Overinflation can cause damage.
5. Close the valve cap securely after inflation to prevent air leakage.
6. Inflate the two air-cushioned backrests similarly until they are firm and supportive.

Filling the Pool

1. Once all chambers are inflated, begin filling the pool with water using a garden hose.
2. Fill the pool to the recommended water level, typically indicated by a fill line on the inside of the pool, or until the water level is comfortable for use, ensuring it does not overflow. The pool has a capacity of approximately 3200 liters.
3. Monitor the water level and the stability of the pool during filling.

4. Operation

Usage Guidelines

- Always ensure adult supervision, especially when children are using the pool.
- Do not allow sharp objects, toys, or pets into the pool to prevent punctures.
- Avoid rough play or jumping, which could damage the pool structure or cause injury.
- Keep the area around the pool clear to prevent slips and falls.

Draining the Pool

1. Locate the drain plug at the bottom of the pool.
2. Remove the drain plug cap. The water will begin to drain.
3. Direct the draining water to a suitable area, such as a garden or storm drain, ensuring it does not cause flooding or damage.
4. Once the pool is empty, wipe down the interior to remove any remaining debris or moisture.

5. Maintenance

Cleaning

- Regularly remove debris such as leaves, insects, and dirt from the pool water using a net.
- Clean the interior surfaces of the pool with a soft cloth and mild soap or a non-abrasive pool cleaner. Rinse thoroughly with clean water.
- For prolonged use, consider using pool chemicals suitable for inflatable pools to maintain water quality, following the chemical manufacturer's instructions carefully.

Storage

1. After draining and cleaning, ensure the pool is completely dry before deflating. This prevents mold and mildew growth.
2. Open all 2-in-1 valves and allow the air to escape. You can gently press on the pool to help expel air.
3. Once deflated, fold the pool neatly.
4. Store the pool in a cool, dry place, away from direct sunlight and extreme temperatures, to prolong its lifespan.

6. Troubleshooting

Problem	Possible Cause	Solution
Pool not holding air	Valve not properly sealed or a puncture.	Ensure all valve caps are securely closed. Check for small holes or tears. Use the included repair patch to fix punctures.
Water not draining completely	Drain plug obstructed or pool not on a level surface.	Ensure the drain plug is fully open and clear of debris. Slightly lift the side opposite the drain plug to facilitate complete drainage.
Pool unstable or leaning	Uneven ground or insufficient inflation.	Ensure the pool is placed on a completely flat and level surface. Re-inflate chambers to recommended firmness.
Water appears cloudy or dirty	Lack of cleaning or chemical imbalance.	Regularly remove debris. Clean pool surfaces. Consider using appropriate pool chemicals and a small filter pump if desired.

7. Specifications

Attribute	Detail
Brand	MEMBER´S MARK
Model Number	KB0773000
Color	Blue
Product Dimensions (Inflated)	120"L x 110"W x 26"H
Shape	Rectangular
Material	Polyvinyl Chloride (PVC)
Water Capacity	3200 Liters
Occupancy	Up to 5 People
Special Features	Inflatable, Portable, Lightweight, Foldable, Drain Hole
Approximate Assembly Time	30 minutes
Item Weight	17.1 Pounds
Maximum Weight Recommendation	300 Pounds

8. Warranty and Support

Specific warranty information for the Members Mark Elegant Family Pool is not provided in the product details. Please refer to the product packaging or contact the retailer/manufacturer directly for warranty terms and conditions.

For product support or inquiries, please contact Members Mark customer service through their official website or the contact information provided on the product packaging.

© 2025 MEMBER´S MARK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08Z3YRNNH

More documents and user manuals: **https://manuals.plus/**