

[manuals.plus](#) /› [Joyroom](#) /› [Joyroom JR-TL6 Bluetooth Wireless Earbuds User Manual](#)

Joyroom JR-TL6

Joyroom JR-TL6 Bluetooth Wireless Earbuds User Manual

Model: JR-TL6

1. INTRODUCTION

Thank you for choosing the Joyroom JR-TL6 Bluetooth Wireless Earbuds. This manual provides essential information for setting up, operating, and maintaining your earbuds. Please read it carefully before use to ensure optimal performance and longevity of your device.

2. PACKAGE CONTENTS

Verify that all items are present in your package:

- Joyroom JR-TL6 Bluetooth Wireless Earbuds (Left and Right)
- Charging Case
- USB Type-C Charging Cable
- User Manual

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your Joyroom JR-TL6 earbuds and charging case.



Image 3.1: Joyroom JR-TL6 Bluetooth Wireless Earbuds and Charging Case. This image displays the black earbuds nestled within their compact charging case, illustrating their design and portability.

Earbud Components:

- **Touch Control Area:** For managing playback, calls, and voice assistant.
- **Microphone:** For calls and voice commands.
- **Charging Contacts:** For charging inside the case.
- **LED Indicator:** Displays status (pairing, charging, low battery).

Charging Case Components:

- **Earbud Charging Slots:** Securely holds and charges the earbuds.
- **USB Type-C Charging Port:** For charging the case.
- **LED Power Display:** Shows real-time battery level of the charging case.

4. SETUP

4.1. Charging the Earbuds and Case

Before first use, fully charge both the earbuds and the charging case.

1. Place the earbuds into the charging case. Ensure they are correctly seated in their respective slots.
2. Connect the USB Type-C charging cable to the charging port on the case and the other end to a 5V/1A power adapter (not included).
3. The LED power display on the case will show the charging status. The earbuds' LED indicators will light up during charging and turn off when fully charged.
4. Charging time for the case is approximately 1.5 hours. Earbuds charge automatically when placed in a charged case.

4.2. Pairing with a Bluetooth Device

The earbuds support Bluetooth 5.0 for a stable connection.

1. Ensure the charging case is charged and open the lid. The earbuds will automatically power on and enter pairing mode. The LED indicator on one earbud will flash white/blue, indicating it is ready to pair.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for available Bluetooth devices and select "JR-TL6" from the list.
4. Once connected, the earbud LED indicators will turn off or show a steady light, and you will hear a confirmation tone.
5. The earbuds will automatically reconnect to the last paired device when taken out of the case, if Bluetooth is enabled on the device.

Note: If pairing fails, turn off the earbuds, disable Bluetooth on your device, and repeat the pairing process. If issues persist, refer to the Troubleshooting section.

5. OPERATING INSTRUCTIONS

The Joyroom JR-TL6 earbuds feature touch controls for easy management of audio and calls.

5.1. Power On/Off

- **Power On:** Open the charging case lid, or long-press the touch control area for 3 seconds if earbuds are out of the case.
- **Power Off:** Place the earbuds back into the charging case and close the lid, or long-press the touch control area for 5 seconds.

5.2. Music Playback

Action	Control
Play/Pause	Single tap on either earbud
Next Track	Double tap on the right earbud
Previous Track	Double tap on the left earbud
Volume Up	Triple tap on the right earbud
Volume Down	Triple tap on the left earbud

5.3. Phone Calls

Action	Control
Answer/End Call	Single tap on either earbud

Action	Control
Reject Call	Long press on either earbud for 2 seconds

5.4. Voice Assistant

- **Activate Voice Assistant:** Long press on either earbud for 2 seconds (when not on a call).

6. MAINTENANCE

Proper maintenance ensures the longevity and performance of your earbuds.

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Charging Contacts:** Ensure the charging contacts on both the earbuds and the case are clean and free of debris to maintain proper charging.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place away from extreme temperatures.
- **Water Exposure:** The earbuds are not waterproof. Avoid exposure to water, moisture, or sweat.

7. TROUBLESHOOTING

If you encounter issues with your Joyroom JR-TL6 earbuds, try the following solutions:

- **Earbuds not pairing:**
 - Ensure both earbuds are charged.
 - Turn off Bluetooth on your device, then turn it back on.
 - Forget "JR-TL6" from your device's Bluetooth list and try pairing again.
 - Place earbuds back in the case, close the lid, wait 5 seconds, then open the lid to reset.
- **Only one earbud working:**
 - Ensure both earbuds are charged.
 - Place both earbuds back into the charging case, close the lid, and then open it again. This should re-sync them.
 - If the issue persists, try resetting the earbuds as described in the pairing section.
- **Earbuds not charging:**
 - Ensure the charging case itself is charged.
 - Check that the charging contacts on the earbuds and inside the case are clean and free of obstructions.
 - Verify the charging cable and power adapter are working correctly.
- **Low volume or poor sound quality:**
 - Adjust the volume on both your device and the earbuds.
 - Ensure the earbuds are properly seated in your ears.
 - Clean any earwax or debris from the earbud mesh.

8. SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Brand	Joyroom
Model Number	JR-TL6
Color	Black
Connectivity Technology	Wireless (Bluetooth 5.0)
Bluetooth Audio Decoding	AAC/SBC
Earbud Battery Capacity	40 mAh
Music Playback Time	Up to 3.5 hours
Talk Time	Up to 3.5 hours
Standby Time	Approximately 120 hours
Charging Input (Case)	Type-C, 5V-1A
Charging Time (Case)	Approximately 1.5 hours
Charging Case Dimensions	60.48 × 49.13 × 28.86 mm
Product Net Weight	37.7 grams
Control Method	Touch
Headphones Form Factor	In-Ear
Material	Silicone
Compatible Devices	Multi-device

9. SAFETY INFORMATION

Please observe the following safety guidelines:

- Do not disassemble, repair, or modify the product.
- Keep the product away from extreme temperatures, direct sunlight, and open flames.
- Avoid exposing the product to water or other liquids.
- Do not use the product at high volume for extended periods to prevent hearing damage.
- Keep out of reach of children and pets.

10. WARRANTY AND SUPPORT

Joyroom products are designed for reliability and performance. For warranty information or technical support, please refer to the warranty card included in your package or visit the official Joyroom website. Please retain your proof of purchase for any warranty claims.