



[Manuals.plus](#) /

> [JLeisure](#) /

> JLeisure Avenli 17807 Inflatable Swimming Pool User Manual

## JLeisure JL-17808

# JLeisure Avenli 17807 Inflatable Swimming Pool User Manual

Model: JL-17808

## INTRODUCTION

---

Thank you for choosing the JLeisure Avenli 17807 Inflatable Swimming Pool. This manual provides essential information for the safe and efficient setup, operation, and maintenance of your new pool. Please read all instructions carefully before use and retain this manual for future reference.

This JLeisure Prompt Set Above Ground Pool measures 10 feet in diameter and 30 inches in height, designed for ages 6 and up. It features super tough sidewalls constructed with three separate layers of puncture-resistant material for enhanced durability. The pool includes a convenient drain plug that accepts a garden hose, allowing for easy water drainage away from the pool area. Designed for quick setup, it can be ready for water in approximately 10 minutes without the need for special tools. Proper storage during the off-season will significantly extend the product's lifespan.

## SAFETY INFORMATION

---

**WARNING:** Failure to follow these instructions can result in serious injury or death.

- Adult supervision is required at all times when children are in or near the pool.
- Do not dive or jump into the pool. The water depth is not sufficient for diving.
- Ensure the pool is set up on a level, stable surface free of sharp objects.
- Keep children away from the drain plug and any electrical components if a pump is used (pump sold separately).
- Empty the pool completely when not in use or when storing for the off-season.
- Check with your local Homeowners Association (HOA) rules and restrictions regarding above-ground pools before purchasing and setting up. Not all housing agencies permit private above-ground pools.
- This pool is designed for outdoor use only.

## SETUP INSTRUCTIONS

---

Setting up your JLeisure Avenli pool is quick and easy. No tools are required for assembly.

1. **Site Preparation:** Choose a flat, level area in your backyard, free from rocks, sharp objects, or debris. Ensure the ground is firm and can support the weight of the filled pool.



Image: The JLeisure Avenli pool positioned on a level, grassy area, demonstrating proper site selection.

2. **Unfold the Pool:** Carefully unfold the pool liner and spread it out evenly on the prepared ground. Ensure the drain plug is positioned where it can be easily accessed for drainage.
3. **Inflate the Top Ring:** Locate the inflation valve on the top ring of the pool. Use an air pump (not included) to inflate the top ring until it is firm to the touch but not over-inflated.



Image: A user inflating the top ring of the pool with a manual air pump, illustrating the inflation process.

- 4. Fill with Water:** Begin filling the pool with water using a garden hose. As the pool fills, the sidewalls will rise. Smooth out any wrinkles in the bottom of the pool as it fills. Stop filling when the water level reaches the fill line indicated on the pool, or approximately 80% full (956 gallons capacity).



Image: A person filling the inflatable pool with water from a garden hose, showing the pool expanding as it fills.



Image: The JLeisure Avenli inflatable pool, fully set up and filled with water, showcasing its round shape and blue color.

5. **Pump Connection (Optional):** If using a pool pump (JLeisure 29P414US 300Gal/H Cartridge Pump recommended, sold separately), connect it according to the pump's instructions.

## OPERATING THE POOL

---

Once set up, your JLeisure Avenli pool is ready for enjoyment.

- **Supervision:** Always ensure adequate adult supervision, especially when children are present.
- **Entry and Exit:** Use appropriate steps or ladders if needed (not included with pool only model) to safely enter and exit the pool.
- **Water Quality:** Maintain proper water chemistry and filtration (if using a pump) to ensure clean and safe swimming conditions.
- **Capacity:** The pool is designed for 2-3 people. Do not exceed this capacity to prevent damage or injury.



Image: A family of five, including adults and children, enjoying the JLeisure Avenli inflatable pool, demonstrating its capacity for recreational use.

## MAINTENANCE

---

Regular maintenance will prolong the life of your pool and ensure a clean swimming environment.

- **Cleaning:** Regularly remove debris from the water surface and bottom. Use a soft brush or pool vacuum designed for inflatable pools.
- **Water Treatment:** Use appropriate pool chemicals (chlorine, algaecide, etc.) to keep the water sanitized and balanced. Follow chemical manufacturer's instructions carefully.
- **Filter Pump Maintenance (if applicable):** If using a filter pump, clean or replace the filter cartridge regularly as per the pump's instructions.
- **Air Ring Pressure:** Periodically check the air pressure in the top ring and re-inflate if necessary to maintain firmness.
- **Draining:** To drain the pool, connect a garden hose to the drain plug and open the valve. Direct the water to a suitable drainage area away from the pool.
- **Storage:** For off-season storage, completely drain and clean the pool. Allow it to dry thoroughly to prevent mold and mildew. Deflate the top ring and fold the pool neatly. Store in a cool, dry place, protected from direct sunlight and extreme temperatures.

## TROUBLESHOOTING

---

| Problem | Possible Cause | Solution |
|---------|----------------|----------|
|---------|----------------|----------|

| Problem                         | Possible Cause                                       | Solution   |
|---------------------------------|--|--|
| Pool losing air from top ring.  | Puncture or loose valve cap.                         | Locate the leak using soapy water. Patch small holes with the included repair kit. Ensure valve cap is tightly secured.                            |
| Water level decreasing rapidly. | Leak in the pool liner.                              | Inspect the pool liner for punctures or tears. Use the repair kit to patch any damage.   |
| Water is cloudy or green.       | Improper water chemistry or insufficient filtration. | Test water chemistry and adjust chemicals as needed. Clean or replace filter cartridge if using a pump. Shock treat the water if algae is present. |
| Pool is lopsided after filling. | Uneven ground or insufficient inflation of top ring. | Drain the pool, re-level the ground, and re-inflate the top ring firmly before refilling.  |

## SPECIFICATIONS

---

**Brand:** JLeisure

**Model:** JL-17808

**Product Dimensions:** 120 inches (10 feet) Diameter x 30 inches Height

**Shape:** Round

**Color:** Blue

**Material:** Polyvinyl Chloride (PVC)

**Capacity:** 956 Gallons (at 80% full)

**Recommended Age:** 6 years and up

**Item Weight:** 17.84 Pounds

**Indoor/Outdoor Usage:** Outdoor

**Included Components:** Pool liner (Filter Pump, CleanPlus 300 GPH pool pump sold separately)



Image: A diagram illustrating the 10-foot diameter and 30-inch height of the JLeisure Avenli inflatable pool.

## WARRANTY AND SUPPORT

---

This JLeisure product comes with a **6-month manufacturer warranty**. Please retain your proof of purchase for warranty claims.

For technical support, replacement parts, or warranty inquiries, please contact JLeisure customer service.

**JLeisure Customer Service:** Refer to the contact information provided on the product packaging or visit the official JLeisure website for support details.

You can also visit the [JLeisure Store on Amazon](#) for more information and products.

---

© 2024 JLeisure. All rights reserved.

This manual is for informational purposes only. Product specifications are subject to change without notice.