

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Naturehike](#) /

› [Naturehike Folding Moon Chair YL06 Instruction Manual](#)

## Naturehike YL06

# Naturehike Folding Moon Chair YL06 Instruction Manual

Model: NH18Y060-Z

## 1. INTRODUCTION

Thank you for choosing the Naturehike Folding Moon Chair YL06. This lightweight and durable chair is designed for comfort and portability, making it ideal for camping, hiking, and other outdoor activities. This manual provides essential information for the safe and proper assembly, use, and maintenance of your chair.

## 2. SAFETY INFORMATION

- Read all instructions before assembly and use.
- Ensure all components are securely connected before sitting.
- Do not exceed the maximum weight capacity of 150 kg (330.7 lbs).
- Keep the chair away from open flames and extreme heat sources.
- Use on a stable, level surface to prevent tipping.
- Supervise children when they are near or using the chair.
- Avoid sharp objects that could puncture or tear the fabric.

## 3. PACKAGE CONTENTS

Verify that all the following items are included in your package:

- 1 x Folding Chair Frame (Aluminum Alloy)
- 1 x Chair Fabric Seat
- 1 x Storage Bag

## 4. SETUP AND ASSEMBLY

Follow these steps to assemble your Naturehike Folding Moon Chair:

1. **Unpack the Components:** Remove the chair frame and fabric seat from the storage bag.
2. **Assemble the Frame:** The aluminum alloy frame uses an elastic cord system, similar to tent poles. Simply

shake the frame pieces, and they will automatically snap into place. Ensure all joints are fully connected and secure.

3. **Attach the Fabric Seat:** Locate the four corners of the fabric seat. There are four pockets on the fabric designed to fit over the four poles of the assembled frame. Start by attaching the two top corners of the fabric to the top poles of the frame. Then, apply slight pressure to stretch the fabric and attach the two bottom corners to the bottom poles.
4. **Verify Stability:** Once the fabric is attached, gently press down on the seat to ensure all connections are firm and the chair is stable before use.



Image: The chair's lightweight aluminum frame and fabric seat, ready for assembly.



Image: The fully assembled Naturehike Folding Moon Chair, demonstrating its compact and comfortable design in an outdoor environment.



Image: A detailed view showing the front and back of the assembled chair, highlighting its ergonomic shape and mesh panels.

### [Assembly Video Guide](#)

Your browser does not support the video tag.

Video: A demonstration of how to quickly and easily assemble the Naturehike Folding Moon Chair, showing the frame setup and fabric attachment.

## 5. OPERATING INSTRUCTIONS

Using your Naturehike Folding Moon Chair is straightforward:

- **Sitting:** Once assembled, sit gently into the chair, distributing your weight evenly. The ergonomic design provides comfortable support.
- **Folding for Storage:** To disassemble, first remove the fabric seat from the frame poles. Then, collapse the frame by pulling apart the connected sections. The elastic cord will guide the pieces to fold compactly. Place both the fabric and frame into the provided storage bag.

## DETAIL 商品詳細



コンパクトに収納可能



背面にブランドロゴ



耐久・耐摩耗性に優れた生地



フレームを差し込むポケット

Image: Close-up details showing the chair's compact storage, discreet brand logo, durable fabric, and how the frame inserts into pockets.

## 6. MAINTENANCE

Proper care will extend the life of your chair:

- **Cleaning:** Wipe the fabric seat with a damp cloth and mild soap if necessary. Rinse thoroughly and allow to air dry completely before storing. Do not machine wash or tumble dry.
- **Frame Care:** Wipe the aluminum frame with a dry cloth. If it gets wet, ensure it is completely dry to prevent corrosion.
- **Storage:** Store the chair in its original storage bag in a cool, dry place, away from direct sunlight and extreme temperatures.

## 7. TROUBLESHOOTING

If you encounter any issues, refer to these common solutions:

- **Difficulty Assembling Frame:** Ensure all elastic cord connections are fully seated. Sometimes a gentle shake or slight manipulation helps the poles align.
- **Difficulty Attaching Fabric:** Start with the top two corners, then use your body weight or leverage to stretch the fabric over the bottom two poles. The fabric is designed to be taut for support.

- **Chair Feels Unstable:** Double-check that all frame poles are fully connected and the fabric is securely attached to all four corners. Ensure the chair is on a flat, stable surface.

## 8. SPECIFICATIONS

Feature	Detail
Model Number	NH18Y060-Z
Brand	Naturehike
Material	Aluminum (Frame)
Product Dimensions (Assembled)	14.17"D x 18.5"W x 38.58"H (36 x 47 x 98 cm)
Storage Size	Approx. 19.7" x 5.1" (50 x 13 cm)
Item Weight	1.3 Kilograms (Approx. 2.87 lbs)
Maximum Weight Recommendation	150 Kilograms (Approx. 330.7 lbs)
Required Assembly	Yes
Is Foldable	Yes
Recommended Uses	Camping, Outdoor Recreation

## SIZE サイズ

耐荷重  
150kg



Image: A diagram illustrating the key dimensions (height, width, depth) and maximum load capacity of the chair.

## 9. WARRANTY AND SUPPORT

Naturehike products are manufactured to high-quality standards. For specific warranty information or if you require technical support, please refer to the official Naturehike website or contact their customer service directly. Keep your purchase receipt as proof of purchase.