

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Honeywell](#) /

› [Honeywell 1114 Waterproof and Fireproof Chest User Manual](#)

Honeywell 1114

Honeywell 1114 Waterproof and Fireproof Chest User Manual

MODEL: 1114

Introduction

The Honeywell 1114 Waterproof and Fireproof Chest is designed to provide secure storage for your valuable documents and digital media. This chest offers robust protection against both fire and water damage, ensuring the safety of your important items.

It features a spacious interior capable of holding letter-size, A4, and legal-size documents flat, along with envelopes, media devices, and digital drives. The chest is engineered to be waterproof for up to 24 hours under a 39-inch water depth and fireproof for 1 hour at 1700 degrees Fahrenheit.



Image: The Honeywell 1114 chest shown open, revealing its interior capacity. Various items such as a passport, documents, and a USB drive are placed inside, demonstrating its ability to store important personal and digital assets securely.

Setup and Initial Use

1. **Unpacking:** Carefully remove the chest from its packaging. Inspect for any visible damage.
2. **Placement:** Position the chest on a flat, stable surface. For optimal performance and to maintain its fire and water resistance ratings, it is crucial that the chest is stored laying flat, not standing upright.
3. **Off-Gassing:** Upon initial opening, a slight odor may be present due to the fire-resistant materials. It is recommended to air out the chest in a well-ventilated area, such as a garage, for a few days before storing sensitive items.
4. **Key Operation:** The chest is secured with a key lock. Insert the key into the lock and turn to open or close the chest. Ensure the key is fully inserted and turned to engage the locking mechanism.



Image: The Honeywell 1114 chest in its closed position, highlighting the front panel with its integrated carry handle and key lock. This view emphasizes the compact and portable design of the unit.

Operating Instructions

- **Opening the Chest:** Insert the provided key into the lock and turn it clockwise (or counter-clockwise, depending on the lock mechanism) until the latch disengages. Lift the lid to open.
- **Storing Items:** Place documents, digital media, and other valuables flat inside the chest. Avoid overfilling to ensure the lid closes properly and the seal remains effective.
- **Closing the Chest:** Lower the lid firmly until it clicks into place. Insert the key and turn it to lock the chest. Remove the key and store it in a secure location away from the chest.
- **Humidity Management:** Due to the fire-resistant insulation, humidity can build up inside the chest. To prevent moisture damage to contents, it is essential to open the chest and air it out weekly for at least 30 minutes.

Maintenance

- **Regular Airing:** As mentioned in the operating instructions, open the chest weekly to allow for air circulation and prevent humidity buildup. This is crucial for protecting sensitive documents and electronics.
- **Cleaning:** Wipe the exterior of the chest with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these may damage the finish. Ensure the chest is completely dry before closing.
- **Seal Inspection:** Periodically inspect the waterproof seal around the lid for any signs of wear, cracks, or damage. A compromised seal can affect the chest's water resistance.

Troubleshooting

- **Difficulty Opening/Closing:**
 - Ensure the key is fully inserted and turned correctly. Do not force the key or the lid.
 - Check if any items inside are obstructing the lid from closing properly.
- **Excessive Humidity Inside:**
 - Increase the frequency or duration of airing out the chest. Ensure it is aired in a dry environment.
 - Consider placing a desiccant packet (e.g., silica gel) inside the chest, away from direct contact with documents, to absorb excess moisture. Replace regularly.

- **Lost or Broken Key:**

- Contact Honeywell customer support for assistance with key replacement. Be prepared to provide proof of ownership and the model number of your chest.

Product Specifications

Manufacturer	Honeywell
Part Number	1114
Item Weight	41.9 pounds
Product Dimensions	17.2 x 20 x 7.3 inches
Item Model Number	1114
Size (Outer Dimensions)	7.3 x 20 x 17.2 in. (H x W x D)
Color	Black
Material	Plastic
Shape	Chest
Fire Protection	1 hour at 1700°F
Water Protection	24 hours under 39-inch water depth

Warranty and Support

The Honeywell 1114 Waterproof and Fireproof Chest comes with a **7-Year Limited Warranty**. This warranty covers defects in materials and workmanship under normal use.

For warranty claims, technical support, or any inquiries regarding your product, please contact Honeywell customer service. Refer to the contact information provided with your purchase documentation or visit the official Honeywell website for the most up-to-date support details.

Please retain your proof of purchase for warranty validation.