

[Manuals.plus](#) /

› [SYNHOPE](#) /

› SYNHOPE 2S/S2 Drawing Pen Replacement Tip User Manual

SYNHOPE 2S/S2

SYNHOPE 2S/S2 Drawing Pen Replacement Tip User Manual

Model: 2S/S2 | Brand: SYNHOPE

INTRODUCTION

This manual provides essential instructions for the proper installation, usage, and maintenance of your SYNHOPE 2S/S2 Drawing Pen Replacement Tips. Please read this guide thoroughly to ensure optimal performance and longevity of your product.

PRODUCT OVERVIEW

The SYNHOPE 2S/S2 Replacement Tips are designed to restore the precision and responsiveness of your compatible drawing pen. Crafted from durable materials, these tips ensure a smooth and consistent writing and drawing experience on your tablet.



Image: Four white replacement tips for the SYNHOPE 2S/S2 drawing pen. Each tip features a smooth, conical writing point and a threaded base for secure attachment to the stylus. These tips are essential for maintaining the pen's

INSTALLATION AND REPLACEMENT

Follow these steps to replace the tip on your SYNHOPE 2S/S2 drawing pen:

- 1. Prepare:** Ensure your drawing pen is powered off or in a safe state before beginning the replacement process.
- 2. Remove Old Tip:** Gently twist the old tip counter-clockwise to unscrew it from the pen body. If the tip is stuck, use a soft cloth for better grip. Avoid excessive force to prevent damage to the pen.
- 3. Inspect:** Check the pen's tip receptacle for any debris or damage. Clean if necessary with a soft, dry cloth.
- 4. Install New Tip:** Take a new SYNHOPE replacement tip. Align the threads of the new tip with the pen's receptacle. Gently twist clockwise until the tip is securely fastened. Do not overtighten.
- 5. Test:** Power on your drawing pen and test its functionality on your compatible tablet to ensure the new tip is working correctly.

USAGE GUIDELINES

The SYNHOPE 2S/S2 replacement tips are designed for use with compatible drawing pens on tablet devices. For optimal performance:

- Use the pen with a light and consistent pressure.
- Avoid dropping the pen or applying excessive force to the tip, as this can cause damage.
- Ensure your tablet screen is clean and free of dust or debris for smooth interaction.
- If using a screen protector, ensure it is compatible with stylus use to prevent premature tip wear.

MAINTENANCE

Proper maintenance can extend the life of your replacement tips:

- **Cleaning:** Periodically wipe the tip with a soft, dry, lint-free cloth to remove any dust or residue. Do not use harsh chemicals or abrasive materials.
- **Storage:** When not in use, store your drawing pen and spare tips in a protective case or a safe place to prevent accidental damage.
- **Inspection:** Regularly inspect the tip for signs of wear, such as flattening, fraying, or cracking. Replace the tip if significant wear is observed to maintain drawing precision and prevent screen damage.

TROUBLESHOOTING

Issue	Possible Cause	Solution
Pen not responding after tip replacement.	Tip not securely installed; pen not powered on; compatibility issue.	Ensure the tip is screwed on tightly. Verify the pen is charged and powered on. Confirm the tip is compatible with your specific pen model (2S/S2).

Issue	Possible Cause	Solution
Inaccurate or inconsistent lines.	Worn tip; screen debris; software glitch.	Replace the tip if worn. Clean your tablet screen. Restart your tablet and drawing application.
Tip feels loose.	Not tightened enough; damaged threads.	Gently tighten the tip clockwise. If threads appear damaged on the tip or pen, replace the tip or contact support.

SPECIFICATIONS

- **Brand:** SYNHOPE
- **Model Compatibility:** 2S/S2 Drawing Pen
- **Material:** Aluminium
- **Compatible Devices:** Tablets
- **UPC:** 762027249717

WARRANTY AND SUPPORT

For information regarding warranty coverage or technical support for your SYNHOPE 2S/S2 Drawing Pen Replacement Tips, please refer to the documentation provided with your original drawing pen or visit the official SYNHOPE website. Keep your purchase receipt as proof of purchase.

For further assistance, you may contact SYNHOPE customer service through their official channels.