

[Manuals.plus](#) /

› [BesLowe](#) /

› BesLowe 3-Light Rustic Farmhouse Convertible Pendant/Semi-Flush Mount Ceiling Light (Model: CD3239-03-WDBK) Instruction Manual

BesLowe CD3239-03-WDBK

BesLowe 3-Light Rustic Farmhouse Convertible Pendant/Semi-Flush Mount Ceiling Light

Model: CD3239-03-WDBK

Brand: BesLowe

PRODUCT OVERVIEW

The BesLowe 3-Light Rustic Farmhouse Convertible Light Fixture (Model: CD3239-03-WDBK) is designed to enhance your interior spaces with its unique blend of farmhouse, rustic, industrial, and vintage aesthetics. This versatile fixture can be installed as either a semi-flush mount ceiling light or a hanging pendant light, offering flexibility for various room types and ceiling heights. Crafted from durable metal with a hand-painted white birch wood finish, it features a central candelabra cluster for three E12 base bulbs (not included).



Image: The BesLowe 3-Light Rustic Farmhouse Convertible Light Fixture in a wooden color finish.

SAFETY INFORMATION

Please read and understand all instructions before beginning installation. Failure to do so may result in electric shock, fire, or other injuries that could be hazardous or fatal. All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC). Consult a qualified electrician if you are unfamiliar with electrical wiring.

- **WARNING:** To avoid electric shock, disconnect power at the main fuse box or circuit breaker before installation.
- **WARNING:** Do not connect this fixture to an ungrounded electrical system.
- **CAUTION:** All wires must be connected properly. Ensure that the electrical connections are secure and correct.
- **CAUTION:** Use only E12 base bulbs with a maximum wattage of 40 watts per bulb.

PACKAGE CONTENTS

Verify that all parts listed below are included in your package. If any parts are missing or damaged, please contact customer service.



Image: A visual representation of all components included in the package, such as ceiling plates, stem, ring frames, lamp base, adjustable chain, arms, spanner, and wire caps.

- Mounting Hardware
- Accessories Kit (Spanner, Wire Caps)
- Ceiling Plate (x2)
- Stem (x1)
- Ring Frame (x2)
- Lamp Base (x1)
- Adjustable Chain (x1)
- Arm (x3)

SETUP & INSTALLATION

This fixture is designed for easy assembly and installation. Follow these steps carefully.

Assembly Instructions

1. **Fixate the 2 rings onto the 3 arms with screws:** Align the pre-drilled holes on the two ring frames with the holes on the three metal arms. Secure them using the provided screws.
2. **Lock the 3 arms onto the ceiling plate with spanner:** Attach the assembled frame (arms and rings) to the ceiling plate. Use the provided spanner to tighten the nuts, ensuring a secure connection.
3. **Run the wire through the stem and then lock it onto the lamp base:** Carefully thread the

electrical wire from the lamp base through the stem. Secure the stem to the lamp base.

4. **Pull the wire through the ceiling plate and screw the stem onto it:** Guide the wire through the center hole of the ceiling plate. Screw the stem onto the ceiling plate, ensuring a tight fit.
5. **If used as a pendant light:** Pull the wire through the other ceiling plate and lock the loops on two ceiling plates with the chain. The length of the chain can be shortened to half by removing links.

Your browser does not support the video tag.

Video: Step-by-step assembly guide for the BesLowe light fixture, demonstrating how to connect the rings, arms, and ceiling plate, and how to prepare it for pendant installation.



Image: This image illustrates the convertible nature of the light fixture, showing it configured as both a semi-flush mount and a pendant light, highlighting its adaptability.



Image: A diagram demonstrating how the light fixture can be mounted on both flat and sloped ceilings, providing installation flexibility.

Electrical Connection

1. Take out the mounting plate and fix it to the junction box with the mounting screws.
2. Connect black fixture wire to black supply wire and white fixture wire to white supply wire using wire caps.
3. Connect ground wire from mounting plate with ground wire from junction box by using a wire cap. If there is no ground wire in your house, attach ground wire to green grounding screw marked G.N.D. Tuck all wires carefully into the J-Box.
4. Install the ceiling plate to the mounting plate by using the screws.
5. Install three E12 bulbs (bulbs not included).

OPERATING INSTRUCTIONS

Once installed, the light fixture is ready for use. Ensure appropriate bulbs are installed for optimal performance.

- **Bulb Requirements:** This fixture requires three E12 base bulbs. Each bulb should not exceed 40 watts. Bulbs are not included with the fixture.
- **Dimmable Functionality:** The fixture is dimmable when used with compatible dimmable E12 bulbs and a suitable dimmer switch (not included).



Image: The light fixture shown with various types of E12 bulbs, emphasizing its compatibility with different bulb styles (bulbs not included).

MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your light fixture.

- **Cleaning:** To clean the fixture, disconnect power and wipe with a soft, dry cloth. Do not use abrasive cleaners or solvents as they may damage the finish.
- **Bulb Replacement:** Ensure power is disconnected before replacing bulbs. Allow bulbs to cool

completely before handling.

TROUBLESHOOTING

If you encounter any issues with your light fixture, refer to the following common problems and solutions:

- **Light does not illuminate:**
 - Check if the power is turned on at the circuit breaker.
 - Ensure bulbs are correctly installed and not faulty.
 - Verify all wire connections are secure.
- **Flickering lights:**
 - Ensure bulbs are fully screwed into their sockets.
 - Check for loose wiring connections.
 - If using a dimmer, ensure bulbs are dimmable and compatible with the dimmer switch.

If problems persist, please contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	BesLowe
Model Number	CD3239-03-WDBK
Color	Wooden Color (White Birch finish)
Material	Metal
Style	Farmhouse, Rustic, Industrial, Vintage, Antique
Light Fixture Form	Chandelier (Convertible to Semi Flush Mount)
Product Dimensions	14.5"L x 14.5"W x 68"H (Max adjustable height)
Item Weight	7.23 Pounds
Power Source	Hard-wired
Bulb Base	E12
Number of Light Sources	3
Maximum Compatible Wattage	40 Watts (per bulb)
Voltage	120 Volts (AC)
Indoor/Outdoor Usage	Indoor use only

Assembly Required	Yes
-------------------	-----

WARRANTY & SUPPORT

For any questions, concerns, or warranty inquiries regarding your BesLowe light fixture, please contact our customer support team. Refer to your purchase documentation for specific warranty terms and contact information.