

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [SANAG](#) /

› [SANAG Bluetooth Portable Speaker User Manual \(Model: B08ZD2S6PQ\)](#)

SANAG B08ZD2S6PQ

SANAG Bluetooth Portable Speaker User Manual

Model: B08ZD2S6PQ

INTRODUCTION

Thank you for purchasing the SANAG Bluetooth Portable Speaker. This manual provides important information regarding the setup, operation, and maintenance of your new speaker. Please read it thoroughly before use to ensure optimal performance and longevity of the product.

SAFETY INFORMATION

- Do not expose the speaker to extreme temperatures or direct sunlight for extended periods.
- Avoid dropping or subjecting the speaker to strong impacts.
- Do not disassemble, repair, or modify the speaker yourself. Contact customer support for assistance.
- Keep the speaker away from water and liquids, despite its waterproof rating, to prevent damage to internal components.
- Use only the specified charging cable and power adapter to charge the device.
- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.

PACKAGE CONTENTS

Please check that all items are present in the package:

- SANAG Bluetooth Portable Speaker
- USB Charging Cable
- AUX Audio Cable
- User Manual (this document)

PRODUCT OVERVIEW

The SANAG Bluetooth Portable Speaker is a compact and versatile audio device designed for various environments. It features Bluetooth 5.0 connectivity, TWS (True Wireless Stereo) support, AUX input, and a MicroSD/TF card slot for multiple playback options. Its waterproof design makes it suitable for outdoor and bathroom use.

SANAG

X6ワイヤレススピーカー



Bluetooth5.0



MicroSD
TFカード



AUXケーブル



TWS対応



Image: Overview of SANAG Bluetooth Portable Speakers in various colors, highlighting key features.



小型&高音質

理想の音を楽しむには高品質の音源をご用意ください



本体で操作可

ボタンが凹凸設計されて
るため暗闇でも操作可能



Image: Detailed view of the speaker's controls and ports.

Component Identification:

- Volume Up / Next Track Button:** Press to increase volume, long press for next track.
- Power ON/OFF / TWS Mode / Menu Button:** Long press to power on/off, short press to switch modes or activate TWS pairing.
- MicroSD Card Slot:** Insert a MicroSD/TF card for direct music playback.
- Play/Pause / Call Button:** Press to play/pause music, answer/end calls.

5. **Volume Down / Previous Track Button:** Press to decrease volume, long press for previous track.
6. **AUX Port:** Connect external audio devices via the 3.5mm AUX cable.
7. **Indicator Light:** Displays power, charging, and connection status.
8. **USB Charging Port:** Connect the USB cable for charging.

SETUP

1. Charging the Speaker

Before first use, fully charge the speaker. Connect the provided USB charging cable to the speaker's USB charging port and the other end to a USB power adapter (not included) or a computer's USB port. The indicator light will show charging status and turn off when fully charged. A full charge provides approximately 18-24 hours of playback.



Image: Speaker in use, highlighting its portability and extended battery life.

2. Powering On/Off

Long press the Power ON/OFF button (2) to turn the speaker on or off. An audible prompt will indicate the power status.

3. Bluetooth Pairing

1. Turn on the speaker. The indicator light (7) will flash, indicating it's in pairing mode.
2. Enable Bluetooth on your device (smartphone, tablet, computer).

18~24 時間



連続再生可能
スピーカーの電池残量は
スマホから確認は可能

3. Search for "SANAG X6" (or similar name) in your device's Bluetooth settings and select it to connect.
4. Once connected, the indicator light will stop flashing and remain solid, and you will hear a confirmation sound.
5. The speaker will automatically reconnect to the last paired device when powered on, if the device's Bluetooth is active and within range.

抜群な安定性

Bluetooth5.0を採用、従来の4.2より伝送能率が2倍、伝送距離が4倍まで向上。

一回接続すると、次回本体を起動する際に自動で接続します (iPhone、iPad、Android対応)



Image: Speaker highlighting Bluetooth 5.0 connectivity and stability.

4. TWS (True Wireless Stereo) Pairing (for two speakers)

To enjoy stereo sound, you can pair two SANAG Bluetooth Portable Speakers:

1. Ensure both speakers are powered on and not connected to any other Bluetooth device.
2. On one speaker (this will be the primary speaker), short press the Power ON/OFF / TWS Mode button (2) twice. The speaker will enter TWS pairing mode.
3. The two speakers will automatically search for and pair with each other. Once paired, you will hear a confirmation sound, and the indicator light on the primary speaker will flash slowly, while the secondary speaker's light will be solid.
4. Now, connect your device to the primary speaker via Bluetooth as described in "Bluetooth Pairing" above.

OPERATING INSTRUCTIONS

1. Music Playback

- **Bluetooth Mode:** After successful Bluetooth pairing, play music from your connected device.
- **MicroSD/TF Card Mode:** Insert a MicroSD/TF card with music files into the MicroSD card slot (3). The speaker will automatically switch to MicroSD mode and begin playback.
- **AUX Mode:** Connect an external audio device (e.g., MP3 player, computer) to the AUX port (6) using the provided 3.5mm AUX cable. The speaker will automatically switch to AUX mode.

2. Button Functions

- **Play/Pause (4):** Short press to play or pause music.
- **Volume Up (1):** Short press to increase volume.
- **Volume Down (5):** Short press to decrease volume.
- **Next Track (1):** Long press to skip to the next track.
- **Previous Track (5):** Long press to go to the previous track.
- **Answer/End Call (4):** Short press to answer an incoming call or end an ongoing call.
- **Reject Call (4):** Long press to reject an incoming call.

MAINTENANCE

- Store the speaker in a cool, dry place when not in use.
- Avoid exposing the speaker to dust, dirt, and sand, which can damage the ports and internal components.
- Regularly charge the speaker if it's not used for a long time to maintain battery health.
- Clean the exterior of the speaker with a soft, slightly damp cloth. Ensure all ports are dry before charging or connecting other devices.

防水仕様



IPX5防水防塵

お風呂/キッチン/海等で
も気軽にご使用頂けます




Image: Red speaker demonstrating its waterproof feature.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not turn on.	Low battery.	Charge the speaker fully.

Problem	Possible Cause	Solution
Cannot pair via Bluetooth.	Speaker is not in pairing mode or already connected to another device. Device Bluetooth is off.	Ensure speaker is in pairing mode (flashing indicator light). Turn off Bluetooth on other devices. Enable Bluetooth on your device and search again.
No sound.	Volume too low. Incorrect mode selected. Device not playing.	Increase speaker and device volume. Check if the correct input mode (Bluetooth, AUX, MicroSD) is active. Ensure music is playing on your device.
Poor sound quality.	Device too far from speaker. Obstructions between devices. Low battery.	Move device closer to the speaker. Remove obstructions. Charge the speaker.
TWS pairing fails.	Speakers are too far apart. One speaker is already paired.	Ensure speakers are close to each other. Disconnect any existing Bluetooth connections before TWS pairing.

SPECIFICATIONS

Model	B08ZD2S6PQ
Brand	SANAG
Connectivity Technology	Bluetooth 5.0, AUX
Special Features	Waterproof (IPX5), Portable, Wireless, TWS Support, MicroSD/TF Card Playback
Control Method	Touch buttons
Power Source	Battery Powered (USB Charging)
Battery Life	Up to 24 hours (depending on usage)
Product Dimensions	7.5 x 7.5 x 8.8 cm (Depth x Width x Height)
Product Weight	0.44 kg

WARRANTY AND SUPPORT

This product comes with a 365-day after-sales service. If you encounter any issues or have questions regarding your SANAG Bluetooth Portable Speaker, please contact our customer support team. Provide your purchase details and model number (B08ZD2S6PQ) for faster assistance.

For support, please refer to the contact information provided with your purchase or visit the official SANAG website.