

[Manuals.plus](#) /

› [Timex](#) /

› Timex Fairfield 41mm Watch TW2U89100VQ Instruction Manual

Timex TW2U89100VQ

Timex Fairfield 41mm Watch Instruction Manual

Model: TW2U89100VQ

INTRODUCTION

Thank you for choosing the Timex Fairfield 41mm Watch. This manual provides essential information for the proper setup, operation, and maintenance of your timepiece. The Fairfield collection is designed with minimalist influences, offering a blend of classic style and modern functionality.



Front view of the Timex Fairfield 41mm Watch with blue dial and black leather strap.

SETUP

Setting the Time

1. **Pull the Crown:** Gently pull the crown (the small knob on the side of the watch case) out to the time-setting position.
2. **Adjust the Time:** Rotate the crown in either direction to move the hour and minute hands to the correct time.
3. **Push the Crown In:** Once the time is set, push the crown back into its original position to start the watch movement.

Adjusting the Strap

Your Timex Fairfield watch features an adjustable genuine leather strap with quick-release spring bars for easy customization. To adjust the fit, locate the buckle and adjust the pin to the desired hole on the strap. The quick-release spring bars allow for easy removal and replacement of the strap without tools.



Side view of the watch, highlighting the crown for time adjustment and the leather strap.

OPERATING FEATURES

Indiglo Night-Light

Your watch is equipped with the Timex Indiglo night-light feature. To illuminate the watch dial in low-light conditions, simply press and hold the crown. The entire dial will light up for easy readability.

Water Resistance

This watch is water resistant to 50 meters (165 feet). This rating means it is suitable for short periods of recreational swimming. It is **not** suitable for diving or snorkeling. To maintain water resistance, do not press any buttons or operate the crown while the watch is wet or submerged.

DEGREE OF WATER RESISTANCE OF TIMEX® WATCHES

	 Rain Resistant	 Light Swimming	 Snorkeling	 Poolside Diving	 Surfing	 Recreational Scuba Diving
30 METERS 98 FEET 60 ATMS						
50 METERS 164 FEET 86 ATMS						
100 METERS 328 FEET 160 ATMS						
200 METERS 656 FEET 284 ATMS						

Watches labeled water-resistant without a depth indicated can withstand splashes and rain, but should not be submerged. To maintain water resistance, do not press any buttons under water unless your watch is indicated as 200 meter water resistant.

TIMEX

This chart illustrates the degree of water resistance for Timex watches. Your 50-meter rated watch is suitable for light swimming but not diving.

MAINTENANCE

Cleaning Your Watch

To clean your watch, wipe the case and crystal with a soft, damp cloth. For the leather strap, use a dry, soft cloth. Avoid using harsh chemicals or abrasive materials, as these can damage the watch's finish or strap.

Battery Replacement

Your watch uses one Lithium Metal battery. When the watch stops running, it indicates that the battery needs replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and maintain water resistance.

Strap Care

The genuine leather strap can be affected by moisture, sweat, and direct sunlight. To prolong its life, avoid prolonged exposure to water and direct sunlight. Clean with a dry, soft cloth and allow it to air dry if it becomes damp.

TROUBLESHOOTING

- **Watch Not Running:** Ensure the crown is fully pushed in. If the watch still does not run, the battery may need

replacement.

- **Indiglo Not Working:** Check if the battery needs replacement. If the battery is new, ensure the crown is being pressed firmly.
- **Water Inside the Watch:** If moisture appears inside the watch, immediately take it to a qualified watch technician. This may indicate a compromised seal. Remember to avoid pressing buttons underwater.

SPECIFICATIONS

Feature	Detail
Model Number	TW2U89100VQ
Case Diameter	41mm
Case Material	Brass
Crystal Material	Mineral Glass
Strap Material	Genuine Leather (20mm)
Water Resistance	50m (165 ft)
Battery Type	1 Lithium Metal (included)
Product Dimensions	8 x 5 x 5 inches
Item Weight	1.76 ounces

WARRANTY AND SUPPORT

Your Timex watch is covered by a limited warranty. For detailed warranty information, service, or support, please refer to the official Timex website or contact Timex customer service directly. Keep your proof of purchase for warranty claims. For further assistance, visit the official [Timex Store on Amazon](#).

© 2024 Timex. All rights reserved.

Timex and Indiglo are registered trademarks of Timex Group USA, Inc.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question