Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Artemide USC-1274018A

Artemide NH LED | Gold - S2 14 SUSP-5W/E12 User Manual

Model: USC-1274018A

Product Overview

The Artemide NH LED Gold S2 14 SUSP-5W/E12 is a contemporary suspension light fixture designed for indoor use. It features a minimalist design with a spherical LED light source and a distinctive gold accent, providing adjustable illumination for various room types, including study rooms. This fixture operates on 120 Volts and uses a 5-watt E12 LED bulb.

Key Features

- **Brand:** Artemide
- **Color:** Gold
- **Material:** Glass, Metal
- **Style:** Contemporary
- **Light Source Type:** LED
- **Wattage:** 5 watts
- **Bulb Base:** E12
- **Special Feature:** Adjustable



This image displays the Artemide NH LED Gold S2 14 SUSP-5W/E12 light fixture. It features a long horizontal black bar with a spherical white LED bulb suspended below it by a gold-colored accent. The fixture is suspended from the ceiling by thin wires and a power cable, showcasing its modern and minimalist design.

Setup and Installation

Safety Precautions

- Always turn off the power at the circuit breaker before beginning installation.
- Consult a qualified electrician if you are unsure about any part of the installation process.
- Wear appropriate safety gear, including gloves and eye protection.
- Ensure the mounting surface can support the weight of the fixture.

Unpacking

- Carefully remove all components from the packaging.

- Inspect all parts for any damage. Do not proceed with installation if any parts are damaged.
- Keep all packaging materials until installation is complete to ensure no small parts are discarded.

Mounting Instructions

1. Identify the desired mounting location on the ceiling.
2. Secure the mounting bracket to the ceiling junction box using appropriate screws.
3. Adjust the suspension cables to the desired length for the fixture's height.
4. Attach the fixture's canopy to the mounting bracket, ensuring a secure fit.

Electrical Connection

1. Connect the fixture's wires to the corresponding household wires (black to black, white to white, ground to ground) using wire nuts.
2. Ensure all connections are tight and secure.
3. Carefully tuck all wires into the junction box.
4. Restore power at the circuit breaker and test the light fixture.

Operation

Turning On/Off

The Artemide NH LED fixture is operated via a standard wall switch connected to the electrical circuit. Simply toggle the switch to turn the light on or off.

Adjusting the Fixture

This fixture features an adjustable design. The position of the spherical light source along the horizontal bar can be adjusted to direct light as needed. Gently slide the light along the bar to achieve the desired illumination angle and coverage.

Maintenance

Cleaning

To maintain the appearance and performance of your Artemide NH LED fixture, clean it regularly. Ensure the power is turned off before cleaning. Use a soft, dry cloth to wipe down the metal and glass surfaces. For stubborn marks, a slightly damp cloth with mild soap can be used, followed by drying with a clean, dry cloth. Avoid abrasive cleaners or solvents.

Bulb Replacement

The fixture uses an E12 base LED bulb with a maximum wattage of 5W. While LED bulbs have a long lifespan, if replacement is necessary:

1. Turn off the power to the fixture at the circuit breaker.

2. Allow the bulb to cool if it has been recently in use.
3. Carefully unscrew the old bulb from its socket.
4. Screw in a new E12 LED bulb (max 5W) until snug. Do not overtighten.
5. Restore power and test the new bulb.

Troubleshooting

Problem	Possible Cause	Solution
Light does not turn on	No power to the fixture; Loose wiring; Faulty bulb; Tripped circuit breaker.	Check circuit breaker; Verify wire connections; Replace bulb; Ensure wall switch is on.
Light flickers	Loose bulb; Incompatible dimmer switch; Loose wiring.	Tighten bulb; Ensure dimmer is LED compatible; Check wire connections.
Humming noise	Incompatible dimmer switch; Loose components.	Replace dimmer with an LED-compatible one; Check for loose parts.

Specifications

Attribute	Value
Brand	Artemide
Model Number	USC-1274018A
Color	Gold
Material	Glass, Metal
Style	Contemporary
Light Fixture Form	Wall (Note: Product description indicates suspension, but specification lists 'Wall'. Refer to product images for actual form.)
Room Type	Study Room
Power Source	Corded Electric
Special Feature	Adjustable
Light Source Type	LED

Attribute	Value
Finish Type	Brushed Brass, Painted, Gold, Glass
Shade Material	Glass
Voltage	120 Volts
Specification Met	E12
Wattage	5 watts
Bulb Base	E12
Unit Count	1 Count
Mounting Type	Wall Mount (Note: Product description indicates suspension, but specification lists 'Wall Mount'. Refer to product images for actual mounting.)
Fixture Type	Non Removable
Date First Available	March 18, 2021

Warranty and Support

Artemide products are manufactured to high standards and are typically covered by a limited warranty against defects in materials and workmanship. Please refer to the warranty card included with your purchase or visit the official Artemide website for specific warranty terms and conditions applicable to your region.
For technical support, replacement parts, or further assistance, please contact Artemide customer service through their official website or authorized distributors. When contacting support, please have your model number (USC-1274018A) and purchase date readily available.

© 2024 Artemide. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08ZDK86K1

More documents and user manuals: **https://manuals.plus/**