

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Outsunny](#) /

› [Outsunny Barbecue Gazebo Instruction Manual \(Model 84C-220\)](#)

Outsunny 84C-220

Outsunny Barbecue Gazebo Instruction Manual

MODEL: 84C-220

Introduction

Thank you for purchasing the Outsunny Barbecue Gazebo, Model 84C-220. This gazebo is designed to provide a sheltered space for your outdoor cooking and dining activities, offering protection from sun and light rain. Constructed with a durable metal frame and a polycarbonate roof, it also features two convenient side shelves for storage. Please read this manual thoroughly before assembly and use to ensure safe operation and proper maintenance.



Image: The Outsunny Barbecue Gazebo providing shelter for a grill in an outdoor setting.

Safety Instructions

- **Read all instructions:** Before assembly and use, carefully read and understand all instructions in this manual.
- **Adult assembly required:** This product requires adult assembly. Ensure all parts are correctly installed before use.
- **Secure installation:** Always anchor the gazebo securely to the ground using the provided fixing bars and expansion bolts to prevent tipping or collapse in windy conditions.
- **Fire safety:** Do not place hot grills or open flames directly against the gazebo frame or roof. Ensure adequate ventilation and clearance around any heat sources.
- **Weather conditions:** While the gazebo offers protection from light rain and sun, it is not designed for heavy rain, strong winds, or snow. Disassemble or secure the gazebo during severe weather to prevent damage or injury.
- **Regular inspection:** Periodically check all bolts and connections to ensure they remain tight and secure.
- **Weight limits:** Do not overload the side shelves. Refer to the specifications for maximum weight capacity.

Package Contents

Verify that all components are present and undamaged before beginning assembly. If any parts are missing or damaged, contact customer support.

- Metal Frame Components (various poles, connectors, and supports)
- Polycarbonate Roof Panels
- 2 Side Shelves
- 8 Fixing Bars
- 8 Expansion Bolts
- Assembly Hardware (screws, nuts, washers, etc.)
- Instruction Manual



Image: The product is typically shipped in two packages.

Assembly Instructions

Assembly requires at least two adults. Follow the illustrated assembly instructions provided with your product for detailed step-by-step guidance. The following provides a general overview of the process.

1. **Unpack and Identify Parts:** Lay out all components and hardware. Compare them with the parts list in your separate assembly guide to ensure everything is present.
2. **Assemble the Main Frame:** Begin by connecting the vertical support poles to the base frames. Use the provided screws and tighten them securely.
3. **Attach Crossbars and Upper Frame:** Connect the horizontal crossbars and the upper frame sections to form the gazebo's basic structure. Ensure all connections are firm.
4. **Install Side Shelves:** Attach the two side shelves to the designated points on the frame. These shelves provide convenient storage space.
5. **Mount the Polycarbonate Roof:** Carefully place and secure the polycarbonate roof panels onto the upper frame. Ensure they are properly aligned and fastened to provide optimal weather protection.
6. **Secure to Ground:** Once the gazebo is fully assembled, use the 8 fixing bars and 8 expansion bolts to

anchor the gazebo securely to a stable surface. This is crucial for stability and safety.

STRUCTURE SOLIDE

Châssis en acier et aluminium
Garantit une structure solide



Barres renforcées
Ils garantissent une solidité maximale

Vis d'expansion et piquets de sol
Ils assurent un
positionnement stable



Image: Details of the solid structure, including chassis, reinforced bars, and ground anchors.



Image: Detailed view of a frame connection, highlighting secure bolting.



Image: Close-up of a side shelf, showing its perforated surface.

Operating Instructions

The Outsunny Barbecue Gazebo is designed for outdoor use as a shelter for barbecues and other outdoor activities.

- **Placement:** Position the gazebo on a flat, stable surface. Ensure there is sufficient clearance around any barbecue grill or heat source to prevent fire hazards.
- **Shelter:** The polycarbonate roof provides protection from direct sunlight and light rain, making it ideal for grilling in various weather conditions.
- **Storage:** Utilize the two side shelves for holding cooking utensils, plates, condiments, or beverages. Do not exceed the recommended weight capacity for each shelf.

ESPACE DE RANGEMENT



2 étagères latérales pour placer
les aliments, les boissons,
les condiments et avoir les ustensiles
nécessaires à portée de main



Image: The two side shelves offer convenient storage for barbecue essentials.



Image: The polycarbonate roof panel provides protection from sun and rain.



Image: Underside view of the polycarbonate roof panels and supporting frame.

Video: This video demonstrates the Outsunny Barbecue Gazebo in an outdoor setting, showcasing its design and functionality as a sheltered area for outdoor cooking and relaxation.

Maintenance

- **Cleaning:** Clean the metal frame with a damp cloth and mild soap. Rinse thoroughly and dry. Clean polycarbonate panels with a soft cloth and water; avoid abrasive cleaners.
- **Inspection:** Regularly inspect the frame for any signs of rust, damage, or loose connections. Tighten any loose bolts.
- **Seasonal Care:** For prolonged product life, consider disassembling and storing the gazebo in a dry, sheltered location during off-season or periods of extreme weather.

Troubleshooting

- **Gazebo feels unstable:** Ensure all bolts are tightened. Verify that the gazebo is anchored securely to the ground using all provided fixing bars and expansion bolts. Check that the ground surface is level.

- **Water pooling on roof:** Ensure roof panels are correctly installed and aligned, allowing for proper water runoff. Check for any obstructions on the roof.
- **Difficulty with assembly:** Refer to the detailed illustrated assembly guide. Ensure you have identified all parts correctly. Do not force components; if parts do not fit, re-check the instructions.

Specifications




Image: Dimensional diagram of the Outsunny Barbecue Gazebo.

Feature	Detail
Model Number	84C-220
Overall Dimensions (L x W x H)	230 x 149 x 246 cm (2.3L x 1.49W x 2.46H meters)
Item Weight	30.5 Kilograms
Material	Metal (Frame), Polycarbonate (Roof)
Color	Black
Water Resistance Level	Waterproof

UV Protection	UV Protection
Assembly Required	Yes
Included Components	Manual, 8 Fixing Bars, 8 Expansion Bolts

Warranty and Support

For warranty information, please refer to the documentation included with your purchase or visit the official Outsunny website. If you encounter any issues or require assistance with your product, please contact Outsunny customer support. Have your model number (84C-220) and purchase details ready when contacting support.

You can find more information and contact details on the [Outsunny Brand Store](#).