

Elchim 256790G01

Elchim 8th Sense Run Professional Hair Dryer User Manual

Model: 256790G01

INTRODUCTION

The Elchim 8th Sense Run Hair Dryer is a lightweight, professional-grade hair styling tool designed for efficient drying and styling. It features a brushless digital motor, ionic-ceramic technology, and offers various heat and speed settings to suit different hair types. This dryer is engineered for rapid drying, reduced frizz, and enhanced hair shine, with a long-lasting motor life of over 5,000 working hours.



Figure 1: Elchim 8th Sense Run Hair Dryer (Lily Rose Edition)

IMPORTANT SAFETY INFORMATION

Please read all instructions before using this appliance. When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

- Keep away from water. Do not use while bathing or in a shower.
- Do not place or store appliance where it can fall or be pulled into a tub or sink.
- Do not place in or drop into water or other liquid.
- If an appliance falls into water, unplug it immediately. Do not reach into the water.
- Always unplug this appliance immediately after using.
- Unplug this appliance before cleaning.
- Do not operate any appliance with a damaged cord or plug, or if the appliance malfunctions or has been dropped or damaged in any manner.
- Keep the cord away from heated surfaces. Do not wrap the cord around the appliance.
- Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and the like.
- Never use while sleeping.

- Never drop or insert any object into any opening.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Do not use an extension cord with this appliance.
- Do not direct hot air towards eyes or other heat-sensitive areas.
- Attachments may be hot during use. Allow them to cool before handling.

PRODUCT OVERVIEW

Familiarize yourself with the components of your Elchim 8th Sense Run Hair Dryer.



Figure 2: Control Switches for Heat and Speed

- **Nozzle/Concentrator:** Directs airflow for precise styling.
- **Heat Settings Switch:** Controls the temperature of the airflow (e.g., Cool, Warm, Hot).
- **Speed Settings Switch:** Controls the fan speed (e.g., Low, Medium, High).
- **Cool Shot Button:** Provides a burst of cool air to set hairstyles.
- **Air Intake Filter:** Located at the rear of the dryer, prevents hair and dust from entering the motor.



Figure 3: Air Intake Filter

SETUP

1. **Unpacking:** Carefully remove the hair dryer and all accessories from the packaging. Retain packaging for storage or future transport.
2. **Attaching Nozzles:** If desired, attach one of the concentrator nozzles to the front of the hair dryer. Ensure it clicks securely into place.
3. **Power Connection:** Plug the hair dryer into a standard electrical outlet (1875 Watts, 120V AC for US models). Ensure the outlet is suitable for the appliance's wattage.

Your browser does not support the video tag.

Video 1: Unboxing and initial setup of an Elchim hair dryer, demonstrating the contents and how to handle the product.

OPERATING INSTRUCTIONS

The Elchim 8th Sense Run Hair Dryer is designed for versatile styling with precise control.

1. **Power On/Off:** Locate the main power switch on the handle. Slide it to the "ON" position to start the

dryer.

2. **Adjusting Speed:** Use the speed setting switch to select your desired airflow intensity (Low, Medium, or High).
3. **Adjusting Heat:** Use the heat setting switch to select your desired temperature (Cool, Warm, or Hot). The ionic-ceramic technology helps to nourish hair cuticles and reduce frizz.
4. **Cool Shot Function:** Press and hold the cool shot button for a burst of cool air. This is useful for setting your hairstyle and adding shine.
5. **Drying Technique:** For best results, section your hair and dry it from roots to ends. Use the concentrator nozzle to direct airflow for smoother, more controlled styling.
6. **Power Off:** After use, slide the main power switch to the "OFF" position and unplug the appliance from the electrical outlet.

Your browser does not support the video tag.

Video 2: Demonstration of the Elchim 8th Sense Run Dryer's features and usage, highlighting its performance.

MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your hair dryer.

- **Cleaning the Air Intake Filter:** Periodically check and clean the air intake filter at the rear of the dryer. Remove any accumulated lint, dust, or hair to prevent overheating and maintain airflow.
- **Exterior Cleaning:** Wipe the exterior of the hair dryer with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the hair dryer in a cool, dry place when not in use. Do not wrap the power cord tightly around the appliance, as this can damage the cord.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Dryer does not turn on.	No power, faulty outlet, or internal issue.	Check if the dryer is properly plugged in. Test the outlet with another appliance. If the problem persists, contact customer support.
Weak airflow or overheating.	Blocked air intake filter.	Unplug the dryer and clean the air intake filter at the rear.
Unusual noise during operation.	Debris in the motor or fan.	Unplug the dryer. Carefully inspect the air intake and exhaust for any foreign objects. If unable to resolve, contact customer support.

SPECIFICATIONS

- **Model Number:** 256790G01
- **Brand:** Elchim
- **Power:** 1875 Watts
- **Motor Type:** Brushless Digital Motor
- **Technology:** Ionic-Ceramic

- **Dimensions:** 1 x 1 x 1 inches
- **Weight:** 2.34 Pounds
- **Color:** Lily Rose
- **Material:** Ceramic
- **Power Source:** Corded Electric
- **Manufacturer:** AmazonUs/ELCHX
- **UPC:** 836793004235
- **ASIN:** B08ZFM48HS

WARRANTY AND SUPPORT

Elchim products are manufactured to high-quality standards. For warranty information, service, or technical support, please refer to the warranty card included with your product or visit the official Elchim website.

Keep your proof of purchase for warranty claims.

For additional support, you may visit the [Elchim Store on Amazon](#).