

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [noot products](#) /
- › [noot products NP11 Wireless Earphones User Manual](#)

noot products NP11

noot products NP11 Wireless Earphones User Manual

Model: NP11

INTRODUCTION

Thank you for choosing noot products NP11 Wireless Earphones. These in-ear headphones are designed for comfort and performance, featuring Bluetooth connectivity, an integrated microphone, volume and remote controls, and IPX7 sweatproof rating, making them ideal for sports, workouts, running, and general exercise. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal use of your device.

WHAT'S IN THE BOX

Please verify that all items are present in your package:

- noot products NP11 Wireless Earphones
- Protective Case
- USB Charging Cable
- Multiple Sizes of Ear Tips



Image: The NP11 earphones, protective case, charging cable, and ear tips.

PRODUCT OVERVIEW

Key Features

- **Bluetooth 4.1 + EDR:** Ensures stable and universal compatibility with various devices.
- **Integrated Microphone:** For hands-free calling.
- **Volume & Remote Control:** Easily manage music playback and calls.
- **IPX7 Sweatproof:** Designed to withstand sweat and light rain, suitable for active use.
- **Ear Hook Design:** Provides a secure and comfortable fit during movement.
- **Long Battery Life:** Up to 8 hours of music play time and 250 hours of standby time.




Image: Key features including music control, microphone, and ear-hook.



IPX7 SWEATPROOF



Image: IPX7 Sweatproof feature.

SETUP

1. Initial Charge

Before first use, fully charge your NP11 earphones. Connect the USB charging cable to the charging port on the earphones and the other end to a USB power source (e.g., computer USB port, wall adapter). The indicator light will show charging status and turn off when fully charged. A full charge takes approximately 1.5 to 2 hours.



250 hours stand-by time
1.5~2 hours charging time



* charging cable included *

Image: Charging port and cable connection.

2. Power On/Off

- **Power On:** Press and hold the Multi-function Button (usually the power button) for approximately 3 seconds until you hear a power-on prompt and the indicator light flashes.
- **Power Off:** Press and hold the Multi-function Button for approximately 3-5 seconds until you hear a power-off prompt and the indicator light turns off.

3. Bluetooth Pairing

1. Ensure the earphones are powered off.
2. Press and hold the Multi-function Button for about 5-7 seconds until the indicator light flashes red and blue alternately. This indicates pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "NP11" from the list of found devices.
5. Once paired, the indicator light will flash blue slowly, and you will hear a connection confirmation.

The NP11 earphones support universal compatibility with Bluetooth 4.1 + EDR devices, offering a range of up to 30 feet in open spaces.



Image: Universal Bluetooth compatibility with various devices.

OPERATING INSTRUCTIONS

Music Control

- **Play/Pause:** Short press the Multi-function Button.
- **Next Track:** Long press the Volume + button.
- **Previous Track:** Long press the Volume - button.
- **Volume Up:** Short press the Volume + button.
- **Volume Down:** Short press the Volume - button.

Call Control

- **Answer/End Call:** Short press the Multi-function Button.
- **Reject Call:** Long press the Multi-function Button.
- **Redial Last Number:** Double-press the Multi-function Button.

CHARGING

When the battery is low, you will hear an audible warning. Connect the earphones to a USB power source using the provided charging cable. The indicator light will be red during charging and turn blue or off when fully charged. Ensure the charging port is dry before connecting the cable.

A full charge provides up to 8 hours of music playback and 250 hours of standby time.



Image: 8 hours continuous music time.

MAINTENANCE

- **Cleaning:** Wipe the earphones with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the earphones in the provided protective case to prevent damage.
- **Water Exposure:** While IPX7 sweatproof, avoid submerging the earphones in water for extended periods. Dry thoroughly if exposed to sweat or rain.
- **Temperature:** Avoid exposing the earphones to extreme temperatures (hot or cold) or high humidity.

TROUBLESHOOTING

Problem	Solution
---------	----------

Problem	Solution
Earphones do not power on.	Ensure the earphones are fully charged. Press and hold the Multi-function Button for 3 seconds.
Cannot pair with device.	Ensure earphones are in pairing mode (red and blue flashing light). Turn off Bluetooth on your device and turn it back on. Forget "NP11" from your device's Bluetooth list and try pairing again. Ensure earphones are within 30 feet of your device.
No sound or low volume.	Check the volume level on both the earphones and your connected device. Ensure the earphones are properly connected to your device. Try playing different audio sources.
Intermittent connection.	Ensure there are no obstacles between the earphones and your device. Move closer to your device. Avoid strong electromagnetic interference.

SPECIFICATIONS

Feature	Detail
Model Name	NP11
Bluetooth Version	4.1 + EDR
Bluetooth Range	Up to 30 feet (in open spaces)
Music Play Time	Up to 8 hours
Standby Time	250 hours
Charging Time	1.5 - 2 hours
Water Resistance	IPX7 Sweatproof
Weight	1.76 ounces
Included Components	Protective Case, USB Charging Cable, Ear Tips

WARRANTY & SUPPORT

noot products NP11 Wireless Earphones come with a **24-Month Hassle-Free Warranty**. For any product inquiries, technical support, or warranty claims, please contact our customer service. We are committed to providing easy to reach customer service to ensure your satisfaction.

For support, please visit the noot products store on Amazon or refer to the contact information provided with your purchase.

[Visit the noot products Store](#)

