

[Manuals.plus](#) /

> [Aer](#) /

> Aer CITY SLING 2 X-PAC Sling Bag - Instruction Manual (Model AER-91012)

Aer AER-91012

Aer CITY SLING 2 X-PAC Sling Bag

MODEL: AER-91012

Introduction

The Aer CITY SLING 2 X-PAC is a compact and versatile sling bag designed for daily essentials. It features multiple functional pockets for organized storage and an adjustable strap for comfortable wear. This manual provides instructions for its proper use and care.



Image: Front and side view of the Aer CITY SLING 2 X-PAC bag in black.

Features

- **Compact Design:** Ideal for carrying essential items without bulk.
- **X-PAC Material:** Durable and weather-resistant fabric for enhanced protection.
- **Multiple Pockets:** Features 2 exterior and 5 interior pockets for organized storage.

- **Adjustable Strap:** Allows for comfortable wear across the body or around the waist.
- **Integrated Hook:** For attaching keys or other small accessories.
- **Zipper Closure:** Securely keeps contents within the bag.



Image: Interior view highlighting the Aer and X-Pac branding and the bright orange lining.

Setup and Wearing Instructions

1. **Positioning:** Place the sling bag across your chest, over one shoulder, or around your waist, depending on your preference.
2. **Adjusting the Strap:** Locate the strap adjustment buckle. Pull the strap ends to lengthen or shorten the strap until the bag rests comfortably against your body. Ensure the bag is snug but not restrictive.
3. **Securing the Buckle:** If the strap has a quick-release buckle, ensure it is securely fastened before use.





Image: A person wearing the sling bag across their back.

Operating Instructions (Storage and Access)

The Aer CITY SLING 2 X-PAC is designed with various compartments to help you organize your belongings efficiently.

- **Main Compartment:** Use the primary zippered compartment for larger items such as a wallet, phone, or small notebook.
- **Interior Pockets:** Utilize the five interior pockets for smaller items like keys, cards, or earphones. One interior pocket includes a hook for secure attachment of keys or a carabiner.
- **Exterior Pockets:** The two exterior pockets provide quick access to frequently used items.



Image: Interior view showing a pocket with an attached hook/carabiner.



Image: Detailed view of the bag's internal organization with multiple pockets.

Maintenance

To ensure the longevity and appearance of your Aer CITY SLING 2 X-PAC bag, follow these care instructions:

- **Cleaning:** Hand wash only. Use a mild soap and cold water. Do not machine wash or tumble dry.
- **Drying:** Air dry the bag completely in a shaded area. Do not expose to direct sunlight or use artificial heat sources.
- **Stain Removal:** For stubborn stains, gently scrub with a soft brush and mild detergent. Rinse thoroughly.
- **Storage:** Store the bag in a cool, dry place away from direct sunlight when not in use.

Troubleshooting

If you encounter any issues with your sling bag, consider the following:

- **Zipper Sticking:** If a zipper becomes difficult to operate, apply a small amount of zipper lubricant or a graphite pencil lead to the teeth.
- **Strap Slipping:** Ensure the strap is correctly threaded through the adjustment buckle. If the strap continues to slip, check for any damage to the buckle or strap material.
- **General Wear and Tear:** Over time, materials may show signs of wear. Regular cleaning and proper storage can help minimize this.

Specifications

Attribute	Detail
Model Number	AER-91012
Dimensions (L x W x H)	9.06" x 3.54" x 4.72" (23 cm x 9 cm x 12 cm)
Weight	0.43 kg (15.17 oz)
Material	Nylon (X-PAC)
Color	Black
Number of Pockets	7 (2 exterior, 5 interior)
Closure Type	Zipper
Care Instructions	Hand Wash Only

Warranty and Support

This product is sold without a manufacturer's warranty as per the product specifications. For any questions or support regarding the Aer CITY SLING 2 X-PAC bag, please refer to the retailer where the product was purchased or visit the official Aer website for general product information.