

Manuals.plus /

› MASTERCANOPY /

› MASTERCANOPY 10x10 Pop-Up Outdoor Canopy with Netting Screen Walls Instruction Manual

## MASTERCANOPY 10x10

# MASTERCANOPY 10x10 Pop-Up Outdoor Canopy with Netting Screen Walls Instruction Manual

Model: 10x10 White

### IMPORTANT SAFETY INFORMATION

Always secure the canopy to the ground using the provided stakes and ropes in windy conditions. Do not leave the canopy unattended while in use. Be cautious when assembling or disassembling the canopy to avoid injury from the steel frame.

This canopy is designed for temporary use and is not intended as a permanent structure. Disassemble and store in extreme weather conditions.

### PACKAGE CONTENTS

Before assembly, please ensure all parts listed below are present:

- 1 x Canopy Frame
- 1 x Canopy Top (150D silver-coated, UV & Water-Resistant)
- 1 x Mosquito Netting
- 4 x Sand Bags (without sand)
- 4 x Ropes
- 8 x Stakes
- 1 x Wheeled Bag (600D PVC coated fabric with reinforced handles)

# PACKING LIST



Figure 1: All components included in the package.

## SETUP INSTRUCTIONS

The MASTERCANOPY 10x10 Pop-Up Outdoor Canopy is designed for quick and easy assembly. Follow these steps for a successful setup:

1. **Unpack the Frame:** Remove the canopy frame from the wheeled bag and stand it upright.
2. **Attach Canopy Top:** Place the canopy top fabric over the frame. Ensure the corners are aligned and secure them with the attached Velcro straps.
3. **Expand the Frame:** With a partner, pull the frame open from opposite sides until it is partially expanded.
4. **Lock the Center Hub:** Step inside the canopy and push the central hub upwards until it locks into place with the peak pole. This secures the roof structure.
5. **Extend the Legs:** Push the button on each leg to adjust the height. Extend all four legs to your desired height setting. There are 3 height settings available.
6. **Install Netting:** Attach the mosquito netting to the frame using the integrated Velcro straps. Ensure all sides are securely fastened to prevent insects from entering.
7. **Secure the Canopy:** Fill the provided sandbags with sand (not included) and attach them to the canopy

legs for added stability. Use the ropes and stakes to anchor the canopy firmly to the ground, especially in breezy conditions.



Figure 2: Visual guide for canopy setup.



Figure 3: Adjustable height mechanism.

## Setup Video Guide

Your browser does not support the video tag.

Video 1: Detailed instructions on how to successfully build the MASTERCANOPY gazebo.

Your browser does not support the video tag.

Video 2: Overview of the MASTERCANOPY Screen House Room Pop-up Gazebo and its features.

## OPERATING INSTRUCTIONS

Your MASTERCANOPY provides a comfortable and protected outdoor space. Here's how to make the most of its features:

- **Mosquito Netting:** The included netting attaches with Velcro straps, providing protection from insects while maintaining excellent air circulation. This is especially beneficial during warmer months.
- **UV and Water Resistance:** The 150D silver-coated top blocks 99% of harmful UV rays and is 100% water-resistant, offering reliable protection from sun and light rain.
- **Adjustable Height:** Utilize the push-button mechanism on each leg to easily adjust the canopy's height

to suit your needs or the terrain.




## CONVENIENT & PRACTICAL

The netting is effective in preventing the entry of some bugs and keeping enough air circulation.

 **UV Protection**       **Water Resistant**       **Prevent From Bugs**



**Convenient Adjustment Button**



**Reinforced Frame**



**Water-resistant Material**

Figure 4: Convenient and practical features of the canopy.



## Fine Mesh

Effectively prevent annoying little things from entering inside, giving you a safe and comfortable outdoor environment.

 **Prevent From Bugs**       **Ventilation**

Figure 5: UV and Water-Resistant Materials.




Figure 6: Fine mesh netting for bug prevention and ventilation.

## MAINTENANCE

Proper maintenance will extend the life of your MASTERCANOPY:

- **Cleaning:** Clean the canopy fabric and netting with mild soap and water. Do not use harsh chemicals or abrasive cleaners, as these can damage the material. Rinse thoroughly and allow to air dry completely before storage.
- **Frame Care:** Inspect the steel frame periodically for any signs of rust or damage. Clean any dirt or debris from the frame.
- **Storage:** When not in use, especially during off-seasons or anticipated severe weather, disassemble the canopy and store all components in the provided wheeled bag in a cool, dry place.

## TROUBLESHOOTING

Here are solutions to common issues you might encounter:

- **Canopy Instability:** Ensure all legs are fully extended and locked. Always use the provided stakes, ropes, and sandbags to anchor the canopy. In high winds, lower the canopy to its lowest setting or disassemble it.
- **Water Pooling on Top:** Ensure the canopy top is taut and the frame is fully extended and locked. Water pooling can occur if the fabric sags, which may indicate improper setup or extreme rainfall.
- **Difficulty with Assembly/Disassembly:** Ensure you have a partner for easier setup. Refer to the setup video and instructions. Check for any bent or misaligned frame parts.
- **Insects Entering:** Verify that the mosquito netting is fully zipped and all Velcro attachments are securely fastened around the frame.

## SPECIFICATIONS

Feature	Detail
Brand	MASTERCANOPY
Model	10x10
Material	Alloy Steel, Polyvinyl Chloride (PVC)
Color	White
Item Weight	37.6 pounds (17.1 Kilograms)
Product Dimensions	120"L x 120"W x 111.6"H
UV Protection	99%
Water Resistance Level	Water Resistant
Assembly Required	Yes
Recommended Uses	Camping, Outdoor Activities, Party, Picnic

## WARRANTY INFORMATION

For specific warranty details regarding your MASTERCANOPY product, please refer to the documentation included with your purchase or contact MASTERCANOPY customer support directly. Keep your proof of purchase for any warranty claims.

## CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report a missing or damaged part, please contact MASTERCANOPY customer support. You can typically find contact information on the product packaging or the official MASTERCANOPY website.