

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Xavax](#) /

› [Xavax 00110232 Adjustable Washing Machine and Dryer Base Instruction Manual](#)


Xavax 00110232

Xavax 00110232 Adjustable Washing Machine and Dryer Base

Instruction Manual

1. INTRODUCTION AND OVERVIEW

The Xavax 00110232 Adjustable Washing Machine and Dryer Base is designed to elevate your laundry appliances, providing a stable and adjustable platform. This base helps to reduce vibration, protect your floor, and make loading and unloading laundry more ergonomic. Please read this manual carefully before assembly and use to ensure safe and proper installation.



This image shows the Xavax 00110232 adjustable base, highlighting its adaptable dimensions for appliances ranging from 52 to 72 cm in width and depth, and an adjustable height from 13 to 18 cm. It also indicates a maximum load capacity of 150 kg.

2. SAFETY INSTRUCTIONS

- Always read and follow all instructions carefully.
- Ensure the base is placed on a stable, level surface before placing any appliance on it.
- Do not exceed the maximum load capacity of **150 kg**.
- Keep hands and fingers clear of moving parts during adjustment.
- Ensure all components are securely fastened before use.
- This product is intended for household appliances such as washing machines and dryers. Do not use for other purposes.
- Keep children and pets away from the base during assembly and while an appliance is in operation on it.

3. PACKAGE CONTENTS

The Xavax 00110232 Adjustable Washing Machine and Dryer Base package includes:

- 1x Adjustable Frame (consisting of connecting bars and corner pieces)
- 4x Adjustable Feet with rubber pads
- Assembly hardware (screws, nuts, etc.)

4. SETUP AND ASSEMBLY

1. Step 1: Unpack Components

Carefully remove all parts from the packaging and check against the package contents list.

2. Step 2: Assemble the Frame

Connect the metal bars to the corner pieces to form a rectangular or square frame. Ensure all connections are secure.



This image shows the assembled Xavax 00110232 base, demonstrating the connection of the metal bars to the corner pieces.

3. Step 3: Attach Adjustable Feet

Screw the four adjustable feet into the designated slots on the underside of the corner pieces. Ensure they are firmly attached.




A detailed shot of a corner section of the Xavax 00110232 base, highlighting the textured, non-slip surface where the appliance rests and the black rubber pad on the adjustable foot designed for stability and floor protection.

4. Step 4: Adjust Dimensions

Adjust the length and width of the frame to match the dimensions of your washing machine or dryer. The base is adjustable from **52 cm to 72 cm** in both length and width.

5. Step 5: Adjust Height

Adjust the height of each foot individually to ensure the base is level and stable on your floor. The height can be adjusted between **13 cm and 18 cm**. The rubber pads on the feet provide stability and protect your floor from scratches.



13 – 18 cm



A detailed view of one of the adjustable feet of the Xavax 00110232 base, illustrating how the height can be set between 13 cm and 18 cm to accommodate different needs and uneven floor surfaces.

5. OPERATING INSTRUCTIONS

Placing the Appliance

- Once the base is fully assembled, adjusted to the correct dimensions, and leveled, carefully lift your washing machine or dryer onto the base.
- Ensure the appliance is centered and its feet are securely resting within the corner sections of the base.
- Verify that the appliance is stable and does not wobble. Re-adjust the feet if necessary.
- The maximum load capacity for this base is **150 kg**. Do not exceed this weight.



This image depicts a white washing machine securely positioned on the Xavax 00110232 adjustable base. A simulated puddle of water beneath the base illustrates how the elevated design protects the appliance from floor moisture.

6. MAINTENANCE

Cleaning

- Clean the base regularly with a damp cloth. Avoid abrasive cleaners.

Stability Check

- Periodically check all connections and the stability of the feet. Re-tighten any loose screws or re-adjust feet as needed.

Inspection

- Inspect the rubber pads for wear and tear. Replace if significantly damaged to maintain stability and floor protection.

7. TROUBLESHOOTING

- **Appliance is unstable or wobbles:**

- Ensure the base is on a completely level surface. Adjust the individual feet until the base is stable.
- Verify that the appliance's feet are properly seated within the base's corner supports.
- Check that the frame connections are tight.

- **Excessive vibration:**

- Ensure the appliance itself is level and its internal components (e.g., drum) are balanced according to its own manual.
- Confirm the base is stable and level. The rubber pads are designed to help absorb some vibration.

- **Difficulty adjusting dimensions:**

- Ensure the locking mechanisms (if any) are disengaged before attempting to slide the frame sections.

8. SPECIFICATIONS

Attribute	Detail
Brand	Xavax
Model	00110232
Material	Metal
Adjustable Width/Depth	52 cm - 72 cm
Adjustable Height	13 cm - 18 cm
Maximum Load Capacity	150 kg
Product Weight	2.98 kg
Special Features	Adjustable, Rubber pads for stability
Part Number	00110232
ASIN	B08ZJGCJR3
Date of First Availability	March 12, 2021

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided at the point of purchase or contact your retailer or the Xavax customer service directly. Keep your proof of purchase for warranty claims.