

LEGO 60293

LEGO City Stunt Park 60293 Building Kit Instruction Manual

Model: 60293 | Brand: LEGO

1. INTRODUCTION

Welcome to the instruction manual for your LEGO City Stunt Park 60293 Building Kit. This playset provides an engaging building experience and exciting stunt action with a flywheel-powered motorcycle and various reconfigurable stunt modules. This manual will guide you through the assembly, operation, and care of your new LEGO set.

Safety Information

This toy contains small parts. Not suitable for children under 3 years of age due to choking hazards. Adult supervision is recommended during play.

2. WHAT'S IN THE BOX

Your LEGO City Stunt Park 60293 Building Kit includes 170 LEGO building elements, designed to construct a modular stunt park. Key components include:

- Flywheel-powered stunt motorcycle
- Two launch ramps
- Various obstacles and fire elements
- Spider cage
- LEGO City TV Tread Octane minifigure
- Additional LEGO City minifigure



Image: The complete LEGO City Stunt Park 60293 set, including the packaging box, the assembled stunt park, the flywheel motorcycle, and two minifigures.

360 Spin Video

Your browser does not support the video tag.

Video: This 7-second video provides a 360-degree view of the assembled LEGO City Stunt Park 60293, showcasing all components from various angles.

3. SETUP AND ASSEMBLY INSTRUCTIONS

Follow the step-by-step building guide included in your kit to assemble the LEGO City Stunt Park. For an enhanced building experience, utilize the digital Instructions PLUS guide available through the free LEGO Building Instructions app on smartphones and tablets. This interactive guide offers zoom and rotate viewing tools to assist with construction.

Building Tips

- Sort pieces by color and size before starting.
- Ensure all connections are firm to prevent parts from detaching during play.
- Refer to the digital instructions for 3D views of complex steps.



Image: A child's hands are shown assembling LEGO bricks for the Stunt Park, with the 'Instructions PLUS' digital guide displayed on a tablet in the background, highlighting the ease of digital building.

4. OPERATING INSTRUCTIONS

The LEGO City Stunt Park is designed for dynamic play, featuring a flywheel-powered motorcycle and reconfigurable stunt modules.

Activating the Flywheel Motorcycle

1. Place the minifigure securely on the stunt motorcycle.
2. Push the motorcycle forward on a flat surface to engage the flywheel mechanism. A few pushes will build up momentum.
3. Release the motorcycle to send it soaring through the stunt park.



Flywheel-powered bike for spectacular stunt action

Image: A child is shown engaging the flywheel mechanism of the LEGO stunt bike, preparing it for a jump over a ramp, demonstrating the interactive play feature.

Reconfiguring the Stunt Park

The modular design allows for various stunt configurations. Experiment with different arrangements of ramps, obstacles, and the spider cage to create new challenges and performances.



Kids reconfigure the modules for different stunts

Image: The LEGO City Stunt Park is displayed with its various modules, including ramps, obstacles, and a spider cage, arranged in a new configuration to illustrate the reconfigurability for diverse stunt challenges.

Official Product Video

Your browser does not support the video tag.

Video: This official product video demonstrates the LEGO City Stunt Park in action, showcasing the flywheel motorcycle performing various stunts and the modular elements being reconfigured for different play scenarios.

5. MAINTENANCE

To ensure the longevity of your LEGO City Stunt Park, follow these simple maintenance guidelines:

- **Cleaning:** Clean LEGO bricks with mild soap and water (not exceeding 104°F / 40°C). Rinse thoroughly and air dry. Do not use hot water, harsh chemicals, or abrasive materials.
- **Storage:** Store the set in a cool, dry place away from direct sunlight to prevent discoloration and material degradation.

- **Handling:** Avoid excessive force when connecting or disconnecting bricks to prevent damage.

6. TROUBLESHOOTING

If you encounter any issues with your LEGO City Stunt Park, consider the following common solutions:

- **Missing Pieces:** Double-check all packaging and the building area. If a piece is genuinely missing, contact LEGO Customer Service for assistance.
- **Motorcycle Not Launching:** Ensure the flywheel mechanism is properly engaged by pushing the bike forward firmly multiple times before releasing. Check for any obstructions on the track or wheels.
- **Stability Issues:** Verify that all bricks are securely connected according to the instructions. Loose connections can affect the stability of the stunt modules.

7. SPECIFICATIONS

Attribute	Detail
Model Number	60293
Pieces	170
Product Dimensions	11.1 x 10.32 x 2.32 inches
Item Weight	1.01 pounds
Recommended Age	5 years and up
Release Date	October 1, 2021
Manufacturer	LEGO

8. WARRANTY AND SUPPORT

LEGO products are manufactured to high-quality standards. For information regarding product warranty, missing parts, or any other support needs, please visit the official LEGO customer service website or contact their support team directly. Keep your purchase receipt as proof of purchase.

Official LEGO Website: www.lego.com