

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [LEGO](#) /
- › [LEGO City Fire Stunt Bike 60311 Instruction Manual](#)

## LEGO 60311

# LEGO City Fire Stunt Bike 60311 Instruction Manual

Model: 60311

## INTRODUCTION

---

This manual provides detailed instructions for assembling and operating your LEGO City Fire Stunt Bike (60311) building kit. Designed for children aged 5 and up, this set features a flywheel-powered stunt motorcycle and a LEGO City Adventures TV series firefighter Freya McCloud minifigure, offering an engaging building and play experience.

## SAFETY INFORMATION

---

**WARNING:** This toy contains small parts. It is not suitable for children under 3 years of age due to choking hazards. Adult supervision is recommended during assembly and play.

## WHAT'S IN THE BOX

---

Your LEGO City Fire Stunt Bike set includes the following components:

- All necessary LEGO building elements to construct the flywheel-powered stunt motorcycle.
- One LEGO City Adventures TV series firefighter Freya McCloud minifigure.
- A simple building guide.
- Access to Instructions PLUS via the free LEGO Building Instructions app for smartphones and tablets.



Image: The complete LEGO City Fire Stunt Bike set, including the box, the assembled stunt bike, and the Freya McCloud minifigure with her helmet.

## ASSEMBLY INSTRUCTIONS

---

Follow these steps to assemble your LEGO City Fire Stunt Bike:

1. **Unpack Components:** Carefully open the box and lay out all LEGO elements on a clean, flat surface. Ensure all pieces are present.
2. **Consult Building Guide:** Refer to the included paper building guide for step-by-step visual instructions. For an interactive 3D experience, download the free LEGO Building Instructions app and use the Instructions PLUS feature.
3. **Assemble Motorcycle Frame:** Begin by connecting the main frame pieces of the stunt motorcycle. Pay attention to the orientation of the flywheel mechanism.
4. **Attach Wheels:** Securely attach the front and rear wheels to the motorcycle frame. Ensure they spin freely.
5. **Add Details:** Attach handlebars, flame decals, and any other decorative elements to complete the motorcycle.

6. **Assemble Minifigure:** Put together the Freya McCloud minifigure, including her hair and helmet. The helmet can be interchanged with the hairpiece.



Image: Individual LEGO components of the Fire Stunt Bike and Freya McCloud minifigure, ready for assembly.



Image: A child's hands in the process of assembling the LEGO Fire Stunt Bike, showing various parts being connected.



Image: The fully assembled LEGO Fire Stunt Bike alongside the Freya McCloud minifigure and her helmet.

## OPERATING INSTRUCTIONS

---

The LEGO City Fire Stunt Bike features a flywheel mechanism for dynamic play:

1. **Place Minifigure:** Seat the Freya McCloud minifigure securely on the stunt bike.
2. **Activate Flywheel:** Place the bike on a flat surface. Push the stunt motorcycle forward multiple times (approximately 3 times) to activate and charge the flywheel. You will feel resistance as the flywheel spins up.
3. **Release for Action:** Release the bike to watch it perform amazing jumps, airborne maneuvers, and landings. Experiment with different surfaces and ramps for varied stunt actions.



Image: A visual guide demonstrating how to push the stunt bike forward to engage the flywheel mechanism for propulsion.



Image: Close-up of the Freya McCloud minifigure, a key character in the LEGO City Adventures TV series.



Image: The LEGO Stunt Bike with the Freya McCloud minifigure performing an aerial stunt, demonstrating the flywheel's power. For more stunt ideas and to explore the full range of LEGO City Stuntz sets, visit the official [LEGO City website](#).

## MAINTENANCE

---

To ensure the longevity and optimal performance of your LEGO set:

- **Cleaning:** Clean LEGO bricks with a mild soap solution and lukewarm water (not exceeding 40°C / 104°F). Rinse thoroughly and air dry. Do not use hot water, harsh chemicals, or abrasive materials.
- **Storage:** Store LEGO elements in a clean, dry place away from direct sunlight and extreme temperatures to prevent discoloration or warping.
- **Flywheel Care:** Keep the flywheel mechanism free from dust, hair, and other debris. If the mechanism becomes clogged, gently remove any obstructions. Avoid forcing the wheels if they are jammed.
- **Disassembly:** If disassembling the set, do so carefully to avoid damaging the bricks.

## TROUBLESHOOTING

---

Problem	Solution
Motorcycle does not move or moves slowly.	Ensure the flywheel is properly charged by pushing the bike forward firmly multiple times. Check for any obstructions (e.g., hair, dust) in the wheels or flywheel mechanism.
Pieces are missing from the set.	Double-check all packaging materials. If pieces are genuinely missing, contact LEGO Customer Service for assistance.
Minifigure does not stay on the bike.	Ensure the minifigure's legs are securely attached to the studs on the bike's seat.

## SPECIFICATIONS

---

**Brand:** LEGO

**Model:** 60311

**Item Model Number:** 6351022

**Product Dimensions:** 3.58 x 4.8 x 1.85 inches

**Item Weight:** 1.44 ounces

**Number of Pieces:** 11

**Recommended Age:** 5 years and up

**Release Date:** October 1, 2021

## WARRANTY AND SUPPORT

---

LEGO products are manufactured to high-quality standards. For information regarding product warranty, missing parts, or general support, please visit the official LEGO Customer Service website or contact their support team directly.

Official LEGO Website: [www.lego.com](http://www.lego.com)

