JVC LT-58MAW705

JVC 58-Inch Class 4K Roku Smart LED TV User Manual

Model: LT-58MAW705

Introduction

This manual provides essential information for setting up, operating, and maintaining your JVC LT-58MAW705 58-inch Class 4K Roku Smart LED TV. Please read this manual thoroughly before using your television to ensure proper operation and to maximize your viewing experience. Keep this manual for future reference.

What's in the Box

Upon unpacking, ensure all items listed below are present and in good condition:

- JVC 58-Inch 4K Roku Smart LED TV (LT-58MAW705)
- Remote Control
- TV Stand (2 pieces)
- Screws for Stand Installation
- Power Cord
- Quick Start Guide (not included in this digital manual)

If any items are missing or damaged, please contact JVC customer support immediately.

Setup

1. Attaching the TV Stand

Carefully place the TV screen-down on a soft, clean surface to prevent scratches. Align the stand pieces with the mounting holes on the bottom of the TV and secure them with the provided screws. Ensure the stand is firmly attached before placing the TV upright.



Image: Front view of the JVC LT-58MAW705 58-inch 4K Roku Smart LED TV. The screen displays a vibrant, colorful abstract image, highlighting its 4K resolution capabilities. The TV features a slim bezel and is supported by two T-shaped stands at the bottom corners.

2. Connecting Devices

The JVC LT-58MAW705 offers multiple connectivity options. Connect your external devices such as Blu-ray players, game consoles, sound systems, or USB storage drives to the appropriate ports on the back of the TV.

- **HDMI Ports (x3):** For high-definition audio and video devices like cable boxes, game consoles, or Blu-ray players.
- **USB Ports (x2):** For connecting USB storage devices to play media files (photos, music, videos).
- **Ethernet Port:** For a wired internet connection.
- **Optical Audio Output:** For connecting to an external sound system or soundbar.



Image: Rear view of the JVC LT-58MAW705 television. This image clearly shows the various input and output ports located on the back panel, including HDMI, USB, and Ethernet connections. It also highlights the VESA mounting points for wall installation.

3. Powering On and Initial Setup

Connect the power cord to the TV and then to a power outlet. Press the power button on the remote control or on the TV itself. Follow the on-screen instructions to complete the initial Roku setup, including connecting to your Wi-Fi network and logging into or creating a Roku account.

Operating the TV

Remote Control Functions

The included remote control provides full functionality for navigating the Roku interface and controlling your TV. Familiarize yourself with the buttons for power, volume, channel, home, back, directional pad, and dedicated streaming service buttons.

Navigating the Roku Smart TV Interface

The Roku Smart TV platform provides access to a vast array of streaming services and content. Use the directional pad on your remote to navigate through menus and select apps. The Home screen displays your installed streaming channels, input selections, and featured content.

- **Streaming Services:** Enjoy instant access to popular apps like Netflix, Disney+, YouTube, Amazon Prime Video, and many more directly from your TV.
- **Input Selection:** Easily switch between connected HDMI devices or the built-in tuner for over-the-air broadcasts.
- **Media Playback:** Use the USB input to play photos, music, and videos directly on the big screen.



Image: An angled front view of the JVC LT-58MAW705 television, showcasing its sleek design and thin bezels. The screen displays a dynamic, colorful image, emphasizing the visual quality of the 4K display.

Picture and Sound Settings

Access the TV's settings menu to customize picture and sound preferences. You can adjust brightness, contrast, color, and various audio modes to suit your viewing environment and content.



Image: A side-angled view of the JVC LT-58MAW705 television, illustrating its slim profile and modern aesthetic. The image highlights the minimal depth of the display, making it suitable for various living spaces.

Maintenance

Cleaning Your TV

To clean the screen, gently wipe it with a soft, lint-free cloth. For stubborn marks, dampen the cloth with a small amount of water or a screen cleaner specifically designed for electronics. Do not use harsh chemicals or abrasive materials. For the TV casing, use a soft, dry cloth.

Software Updates

Your Roku Smart TV will automatically check for and install software updates when connected to the internet. Ensure your TV is connected to a stable network to receive the latest features and performance improvements.




Image: A direct side profile view of the JVC LT-58MAW705 television, emphasizing its ultra-slim design. This perspective showcases the minimal thickness of the display panel.

Troubleshooting

If you encounter issues with your JVC LT-58MAW705 TV, refer to the common problems and solutions below. For more complex issues, consult the online support resources or contact customer service.

Problem	Possible Solution
No Power	Ensure the power cord is securely connected to both the TV and a working electrical outlet. Try a different outlet. Check if the remote control batteries need replacement.

Problem	Possible Solution
No Picture/Sound	Verify the correct input source is selected. Check all cable connections (HDMI, etc.). For sound, ensure volume is not muted and external audio systems are properly connected.
Remote Control Not Responding	Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the TV's IR sensor.
Cannot Connect to Wi-Fi	Check your Wi-Fi password. Restart your router and modem. Ensure the TV is within range of your Wi-Fi signal.
Apps Not Loading/Buffering	Check your internet connection speed. Restart the TV and your router. Some apps may require updates.

Specifications

Detailed technical specifications for the JVC LT-58MAW705 TV:

Feature	Detail
Brand	JVC
Model Number	LT-58MAW705
Screen Size	58 Inches (148 cm diagonal)
Display Technology	LED
Resolution	4K Ultra HD (3840 x 2160 pixels)
Refresh Rate	60 Hz
Aspect Ratio	16:9
HDMI Inputs	3
USB Inputs	2
Connectivity	Ethernet, HDMI, USB, Wi-Fi
Speaker Type	Built-In
Product Dimensions (D x W x H)	25" x 50" x 31" (approx. 63.5 x 127 x 78.7 cm)
Item Weight	26.5 pounds (approx. 12 kg)
Special Feature	Flat Screen, Roku Smart TV

Warranty and Support

Warranty Information

This product is sold as a "Renewed" item. Please refer to the specific warranty terms provided at the time of purchase or contact the seller for details regarding the warranty period and coverage for renewed products. Standard manufacturer warranties may not apply to renewed items.

Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact JVC customer support or the retailer from whom you purchased the product. Refer to your purchase documentation for specific contact information.

© 2023 JVC. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question