

Prtukyt V-PCEC2606

Prtukyt 6S Wireless Bluetooth Headphones User Manual

Model: V-PCEC2606

INTRODUCTION

Welcome to the user manual for your new Prtukyt 6S Wireless Bluetooth Headphones. These headphones are designed to provide a high-fidelity audio experience with versatile connectivity options, including Bluetooth 5.0, FM radio, and TF card support. They feature a comfortable, foldable design, built-in microphone for calls, and intuitive controls for seamless operation. Please read this manual carefully to ensure proper use and maintenance of your headphones.



Image: Ptukyt 6S Wireless Bluetooth Headphones in white and gold, showcasing their sleek design.

WHAT'S IN THE BOX?

Your Ptukyt 6S Wireless Bluetooth Headphones package includes the following items:

- Ptukyt 6S Wireless Bluetooth Headphones
- USB Charging Cable
- Auxiliary Audio Cable
- User Manual



Image: The contents of the headphone box, showing the folded headphones, USB charging cable, auxiliary audio cable, and user manual.

KEY PRODUCT FEATURES

- **Hi-Fi Stereo Sound:** Enjoy deep bass and crystal-clear treble with advanced Bluetooth 5.0 and high-definition stereo sound for an immersive music experience.
- **Stable Bluetooth 5.0:** Upgraded Bluetooth 5.0 ensures fast pairing, stable connection, and low latency with a built-in mic for smooth hands-free calls.
- **Comfortable & Foldable:** Soft ear cushions mimic skin texture for all-day comfort. Foldable and stretchable design fits all head sizes and ensures durability.
- **Adjustable & Portable:** Ergonomic adjustable headband and ultra-soft ear cups offer a snug fit. Foldable for easy storage—great for classes, travel, or daily use.
- **Long Battery Life:** Up to 20 hours playtime on a single charge. Switch to wired mode for nonstop music—ideal for long trips.

OUR HEADPHONES MEET YOUR DAILY NEEDS



Image: The headphones are shown in use during sports activities, at home, and outdoors, highlighting their versatility.

CONTROLS OVERVIEW

The headphones feature intuitive controls located on the ear cup for easy access to various functions:

FUNCTION INTRODUCTION




Image: A detailed diagram illustrating the function of each button and port on the headphone's ear cup.

Button/Port	Function
Power Button	Power ON/OFF
Play/Pause/Call Button	Play/Pause music, Answer/Hang up calls
Volume + / Next Song	Increase volume, Skip to next song
Volume - / Previous Song	Decrease volume, Go to previous song
Mode Button	Switch between Wireless (Bluetooth), FM, and TF card modes
Audio Cable Link Hole	Connect auxiliary audio cable for wired use
SD/TF Card Slot	Insert TF/Micro SD card for direct music playback (card not included)
USB Charge Port	Connect USB cable for charging

Video: An overview of the PRTUKYT 6S Wireless Bluetooth Headphones, demonstrating their features and controls.

SETUP GUIDE

Charging the Headphones

Before first use, fully charge your headphones. Connect the provided USB charging cable to the headphone's USB charge port and the other end to a compatible USB power source (e.g., computer USB port, wall adapter). The LED indicator will show charging status.



Image: The headphones are shown with a charging cable connected, highlighting their long playtime capability.

Bluetooth Pairing

To pair your headphones with a Bluetooth-enabled device:

1. Ensure the headphones are fully charged and powered off.
2. Press and hold the Power button until the LED indicator flashes blue and red, indicating pairing mode.
3. On your device (smartphone, tablet, PC), enable Bluetooth and search for available devices.
4. Select "6S" from the list of devices.
5. Once connected, the LED indicator will turn solid blue or flash blue slowly.



Image: The headphones are shown wirelessly connected to a smartphone, illustrating the Bluetooth pairing process.

Video: A demonstration of the 6S Wireless Headphones, including how to connect them via Bluetooth.

OPERATING INSTRUCTIONS

Wireless Mode (Bluetooth)

After successful pairing, you can control music playback and calls directly from the headphone buttons:

- **Play/Pause:** Press the Play/Pause/Call button once.
- **Next Song:** Press the Volume + / Next Song button.
- **Previous Song:** Press the Volume - / Previous Song button.
- **Answer/End Call:** Press the Play/Pause/Call button once during an incoming call.
- **Reject Call:** Press and hold the Play/Pause/Call button during an incoming call.

Wired Mode (Aux Cable)

To use the headphones in wired mode, connect the provided auxiliary audio cable to the Audio Cable Link Hole on the headphones and the 3.5mm audio jack of your device. The headphones will automatically switch to wired mode, and no battery power is required.

FM Radio Mode

Press the Mode button to switch to FM Radio mode. The headphones will automatically scan and tune into available FM stations. Use the Next/Previous Song buttons to change stations.

TF Card Mode

Insert a loaded TF/Micro SD card into the SD/TF Card Slot. The headphones will automatically switch to TF Card mode and begin playing music from the card. Use the Play/Pause and Next/Previous Song buttons to control playback.

Video: A short demonstration of the Bluetooth Headphones Over Ear, showing general usage and features.

MAINTENANCE AND CARE

To ensure the longevity and optimal performance of your headphones, follow these maintenance guidelines:

- Keep the headphones dry. Do not expose them to rain, moisture, or liquids.
- Clean the ear cushions and headband regularly with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- Store the headphones in a cool, dry place when not in use. Utilize their foldable design for compact storage.
- Avoid extreme temperatures, as this can affect battery life and overall performance.
- Do not disassemble or attempt to repair the headphones yourself. This will void the warranty and may cause damage.

TROUBLESHOOTING

If you encounter any issues with your headphones, please refer to the following common problems and solutions:

Problem	Solution
Headphones won't turn on	Ensure the headphones are fully charged. Press and hold the Power button for a few seconds.
Cannot pair with device	Make sure headphones are in pairing mode (flashing blue/red LED). Ensure Bluetooth is enabled on your device and it's within 10 meters. Forget previous pairings on your device and try again.
No sound or low volume	Check headphone and device volume levels. Ensure headphones are properly connected/paired. If in wired mode, check the aux cable connection.
Sound distortion	Move closer to your device to avoid interference. Check audio source quality.
Microphone not working	Ensure headphones are connected via Bluetooth (microphone only works in wireless mode). Check microphone settings on your device.

TECHNICAL SPECIFICATIONS

Specification	Value
Model Name	6S001
Connectivity Technology	Wireless, Bluetooth 5.0
Wireless Communication Technology	Bluetooth
Included Components	Headband
Age Range (Description)	Adult
Material	Faux Leather
Specific Uses For Product	Travel, Sports and Exercise
Charging Time	2.5 Hours
Recommended Uses For Product	Cycling, Running, Exercising
Compatible Devices	Cellphones
Control Type	Volume Control
Cable Feature	Without Cable
Frequency Range	20 Hz - 20,000 Hz

Specification	Value
Unit Count	1 Count
Style	Over Ear, White & Gold
Control Method	Touch
Number of Items	1
Controller Type	Touch Control, Bluetooth
Battery Life	30 Hours
Bluetooth Range	10 Meters
Bluetooth Version	5.0
Ear Placement	Over Ear
Form Factor	Over Ear
Noise Control	None
UPC	752771029031
Manufacturer	PRTUKYT
Item Weight	10.8 ounces
Item model number	V-PCEC2606

WARRANTY AND SUPPORT

Specific warranty information and direct support contact details were not provided in the product data. Please refer to the product packaging or the manufacturer's official website for the most up-to-date warranty terms and customer support options.