

Lorelli 10050332102

Lorelli Tricycle Neo 4-in-1 EVA User Manual

Model: 10050332102

1. INTRODUCTION

The Lorelli Neo 4-in-1 Tricycle is a versatile and comfortable ride designed for children aged 18 months and older, supporting a maximum weight of 20 kg. It features durable EVA tires for a smooth ride and a unique swivel seat that allows your child to face forward or towards you, enhancing interaction and comfort. The adjustable and removable backrest ensures your child can rest comfortably during rides. This manual provides essential information for assembly, operation, maintenance, and safety to ensure a safe and enjoyable experience for your child.

Key Features:

- Padded, comfortable, and soft seat
- Adjustable and removable backrest
- Swivel seat (parent-facing or forward-facing)
- 5-point safety harness with shoulder pads
- Removable front bar
- Foldable footrest and separate footrests for smaller children
- Free-wheel function
- Adjustable and removable sun canopy
- Comfortable push handle with foam control grip for steering
- EVA tires
- Practical pocket on the push handle
- Brakes on the rear wheels
- Lockable pedals
- Removable storage basket on the rear wheels

2. SAFETY INFORMATION

WARNING: Always supervise your child when using the tricycle. Failure to follow these instructions

could result in serious injury.

- This product is intended for children aged 18 months and older.
- Do not exceed the maximum weight capacity of 20 kg.
- Ensure all parts are correctly assembled and securely fastened before each use.
- Always use the 5-point safety harness to secure your child.
- Do not use the tricycle near stairs, hills, busy roads, swimming pools, or other hazardous areas.
- Only use on flat, level surfaces.
- Keep hands and feet away from moving parts.
- Regularly inspect the tricycle for any damaged or worn parts. Do not use if damaged.
- Keep packaging materials away from children to prevent suffocation.

3. PARTS LIST

Before assembly, ensure all components are present and undamaged. Refer to the diagrams for identification.

- Tricycle Frame
- Front Wheel with Pedals
- Rear Wheels (2)
- Padded Seat
- Backrest
- Safety Harness
- Front Bar (Bumper)
- Foldable Footrests
- Separate Footrests for smaller children
- Push Handle with Foam Grip
- Sun Canopy
- Rear Storage Basket
- Push Handle Pocket
- Assembly Hardware (screws, nuts, washers)

4. SETUP AND ASSEMBLY

Follow these steps carefully for proper assembly. It is recommended to have two adults for assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface. Check against the parts list.
2. **Attach Rear Wheels:** Slide the rear wheels onto the axle until they click into place. Ensure they are securely fastened and spin freely.
3. **Install Front Wheel:** Insert the front wheel assembly into the main frame. Secure it with the provided pins or screws as per the diagram.

4. **Attach Seat and Backrest:** Mount the padded seat onto the frame. Then, attach the backrest to the seat assembly. Ensure the swivel mechanism is functional.
5. **Install Push Handle:** Insert the push handle into the designated slot at the rear of the tricycle. Secure it firmly.
6. **Attach Sun Canopy:** Slide the canopy frame into the slots on the backrest or seat assembly. Adjust its position as needed.
7. **Attach Front Bar and Footrests:** Secure the removable front bar in front of the seat. Attach the foldable footrests and the separate footrests for smaller children as required.
8. **Final Safety Check:** Before first use, double-check all connections, screws, and moving parts to ensure they are tight and secure. Test the brakes and free-wheel function.



Figure 4.1: Fully assembled Lorelli Tricycle Neo 4-in-1 EVA.



5. OPERATING INSTRUCTIONS

5.1. Adjusting the Seat and Backrest

- **Swivel Seat:** To change the seat direction (parent-facing or forward-facing), locate the release mechanism (usually a lever or button) underneath the seat. Engage the mechanism, rotate the seat to the desired position, and ensure it locks securely in place.
- **Adjustable Backrest:** The backrest can be reclined for your child's comfort. Use the adjustment lever or button on the side or rear of the backrest to set the desired angle. Ensure it clicks into a locked position.



Figure 5.1: Illustration of adjustable backrest and canopy features.

5.2. Using Footrests and Pedals

- **Foldable Footrest:** For younger children who cannot reach the pedals, extend the foldable footrest. When not needed, it can be folded away.
- **Separate Footrests:** An additional set of footrests is provided for very small children, offering a more comfortable and secure position. Attach them as per the instructions.
- **Lockable Pedals:** To prevent the child's feet from getting caught while the tricycle is being pushed, engage the pedal lock mechanism (usually a button or switch on the front wheel hub). This disengages the pedals from the wheel. To allow the child to pedal, disengage the lock.
- **Free-Wheel Function:** This function allows the front wheel to spin independently of the pedals. Engage it when pushing the tricycle so the child's feet don't have to move with the pedals. Disengage it when the child is ready to pedal independently.



Figure 5.2: Illustration of adjustable handle and footrests.



Figure 5.3: Illustration of foldable footrest and safety harness.

5.3. Steering and Braking

- **Push Handle Control:** The comfortable push handle allows parents to steer the front wheel of the tricycle. Gently move the handle left or right to guide the tricycle's direction.
- **Rear Wheel Brakes:** To engage the brakes, push down on the brake levers located near the rear wheels. Ensure both brakes are engaged when parking the tricycle to prevent accidental movement.



Figure 5.4: Illustration of various features including the free-wheel mechanism and handlebar adjustment.

5.4. Canopy and Storage

- **Adjustable Sun Canopy:** The canopy can be adjusted to provide optimal sun protection for your child. It can also be removed if not needed.
- **Storage Basket and Pocket:** Use the removable storage basket at the rear for carrying essentials. A practical pocket is also located on the push handle for smaller items.



Figure 5.5: Different configurations of the Lorelli Tricycle.

6. MAINTENANCE

- **Cleaning:** Wipe down the frame and plastic parts with a damp cloth and mild soap. Do not use abrasive cleaners. The fabric parts (seat padding, canopy) can be spot cleaned or removed for gentle hand washing if specified by fabric care labels.

- **Lubrication:** Periodically check and lubricate moving parts like wheel axles and pedal mechanisms with a silicone-based lubricant to ensure smooth operation.
- **Inspection:** Regularly inspect all screws, bolts, and fasteners to ensure they are tight. Check for any signs of wear, cracks, or damage on the frame, wheels, and fabric components. Replace damaged parts immediately.
- **Storage:** Store the tricycle in a clean, dry place away from direct sunlight and extreme temperatures to prevent material degradation.

7. TROUBLESHOOTING

- **Wheels not turning smoothly:** Check for debris (dirt, hair) caught in the axles. Ensure the free-wheel function is engaged or disengaged as desired. Lubricate axles if necessary.
- **Tricycle difficult to steer:** Ensure the push handle is securely attached and not bent. Check if the front wheel is locked or obstructed.
- **Seat not swiveling:** Check for any obstructions underneath the seat. Ensure the swivel mechanism is fully disengaged before attempting to rotate and fully engaged to lock.
- **Pedals not moving:** Check if the pedal lock mechanism is engaged. Disengage it to allow the child to pedal.
- **Tricycle unstable:** Ensure all assembly points are securely fastened. Check that the wheels are properly attached and not wobbly. Do not exceed the maximum weight limit.

8. SPECIFICATIONS





Feature	Detail
Model Number	10050332102
Recommended Age	18 months and up
Maximum Weight Capacity	20 kg (Product), 25 kg (Specification) - <i>Note: Adhere to the lower limit for safety.</i>
Main Material	Metal
Tire Type	EVA
Product Dimensions (L x W x H)	87 x 54.5 x 100 cm
Item Weight	7.8 kg
Package Dimensions	68 x 41 x 30 cm
Package Weight	12.35 kg
Batteries Required	No



9. WARRANTY AND SUPPORT

Lorelli products are manufactured to high-quality standards. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official Lorelli website. If you encounter any issues or require assistance with your Lorelli Tricycle Neo 4-in-1 EVA, please contact Lorelli customer service through their official channels. Have your model number (10050332102) and purchase details ready when contacting support.

© 2024 Lorelli. All rights reserved.

Related Documents - 10050332102

	<p>Lorelli DALLAS Children Tricycle - Manual Instruction and Safety Guide</p> <p>Official manual instructions and safety guidelines for the Lorelli DALLAS children's tricycle. Learn about assembly, usage, and safety requirements for children aged 24-72 months.</p>
	<p>Lorelli Navigator Car Seat Manual</p> <p>Instruction manual for the Lorelli Navigator car seat, covering installation and usage for Groups 1, 2, and 3 (9-36 kg).</p>
	<p>Lorelli LYNX Isofix Car Seat: User Manual & Installation Guide</p> <p>Comprehensive instruction manual for the Lorelli LYNX Isofix child car seat. Learn about installation, safety features, and usage guidelines for children from birth up to 12 years. Ensure safe travel with Lorelli.</p>
	<p>Lorelli EXPEDITION Car Seat: i-Size Safety Manual & Installation Guide</p> <p>Comprehensive user manual for the Lorelli EXPEDITION i-Size car seat. Find detailed instructions for installation, safe usage, and maintenance for children 100-150 cm. Visit www.lorelli.eu for more information.</p>

	<p>Lorelli VIOLA 3 in 1 Stroller: Manual Instruction, Safety, and Assembly Guide</p> <p>Comprehensive user manual for the Lorelli VIOLA 3 in 1 stroller. Includes safety guidelines, assembly instructions, parts list, operation details, and maintenance tips for safe and optimal use.</p>
	<p>Lorelli RIO Car Seat Manual: Installation, Safety, and Usage Guide</p> <p>Comprehensive manual for the Lorelli RIO car seat (76-150 cm). Find detailed instructions on installation, safety guidelines, washing, and usage for optimal child protection.</p>