

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Hot Wheels](#) /
- › [Hot Wheels Massive Loop Mayhem Track Set User Manual](#)

Hot Wheels GTV14

Hot Wheels Massive Loop Mayhem Track Set Instruction Manual

Model: GTV14

PRODUCT OVERVIEW

The Hot Wheels Massive Loop Mayhem track set offers thrilling excitement with its huge 28-inch tall loop, designed for multi-car play. Vehicles race around the loop, aiming to avoid near-misses. Users launch the first car with a slam launcher, then introduce more cars to create dynamic action. The challenge involves managing multiple cars simultaneously, requiring precise timing and skill. The set includes one 1:64 scale Hot Wheels vehicle to begin play.



Image: The complete Hot Wheels Massive Loop Mayhem Track Set, featuring the large orange loop and blue track sections, with a single yellow Hot Wheels car at the base.

WHAT'S IN THE BOX

- 1 Hot Wheels Massive Loop Mayhem track set
- Slam launcher
- Battery box
- 1 Hot Wheels 1:64 scale vehicle



Image: The retail packaging for the Hot Wheels Massive Loop Mayhem Track Set, showing the assembled track and included car.

SETUP INSTRUCTIONS

1. **Unpack Components:** Carefully remove all track pieces, the slam launcher, battery box, and the included vehicle from the packaging.
2. **Assembly:** Connect the track pieces according to the visual diagrams provided in the original product instructions. While assembly is generally straightforward, some users have noted that printed instructions can be small or unclear. Referring to product images or online visual guides may assist in the assembly process. Allow approximately 45 minutes for complete and correct assembly.
3. **Battery Installation:** The track's booster requires **four (4) D batteries** (not included). Locate the battery compartment on the battery box component. Use a small screwdriver to open the compartment, insert the batteries with correct polarity, and secure the cover. The track will not function without these batteries.
4. **Placement:** Ensure the assembled track is placed on a flat, stable surface to prevent tipping during play.



Image: A visual representation of the track's impressive 28-inch (70cm+) height, highlighting the scale of the main loop.

OPERATING INSTRUCTIONS

1. **Power On:** Locate the on/off switch on the battery box and slide it to the "On" position. This will activate the motorized booster.
2. **Place Car:** Position a Hot Wheels 1:64 scale vehicle into the slam launcher at the start of the track.
3. **Launch:** Firmly press down on the slam launcher to propel the car into the loop. The motorized booster will then keep the car in continuous motion through the epic loop.
4. **Multi-Car Play:** For enhanced excitement, introduce additional cars (sold separately) onto the track after the first car has entered the loop. The objective is to see how many cars can race simultaneously before an inevitable crash occurs. This requires a trick of timing and skill.



BOOST TO KEEP GOING!

Image: A close-up view of the track's booster mechanism, showing a yellow Hot Wheels car being propelled forward.



Image: Two children enthusiastically playing with a Hot Wheels track set, demonstrating multi-car play and interaction.

MAINTENANCE

- **Cleaning:** Wipe down track pieces and the battery box with a dry or slightly damp cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Battery Replacement:** Replace all four D batteries when the booster's performance diminishes or stops. Ensure proper polarity during installation.
- **Storage:** For long-term storage, disassemble the track and store components in their original packaging or a suitable container to prevent damage and loss of pieces.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Cars not completing the loop or moving slowly.	Low or dead batteries in the booster. Insufficient force on the slam launcher.	Replace all four D batteries. Ensure a firm and consistent press on the slam launcher.
Track is excessively noisy during operation.	Normal operation of the motorized booster and car movement.	Some noise is inherent to the product's design due to the motorized booster and high-speed car action. This is not typically a defect.
Cars frequently crash or derail.	Too many cars on the track simultaneously. Incorrect car type for the track.	Reduce the number of cars on the track. Ensure only 1:64 scale Hot Wheels vehicles are used. Experiment with different car weights and designs for optimal performance.
Track pieces do not connect securely.	Improper alignment during assembly.	Review the assembly instructions carefully. Ensure all connectors are fully engaged.

SPECIFICATIONS

- **Product Dimensions:** 33.86 x 32.28 x 29.13 inches
- **Item Weight:** 2.2 pounds
- **Model Number:** GTV14
- **Manufacturer Recommended Age:** 5 - 9 years
- **Batteries Required:** 4 D batteries (not included)
- **Release Date:** June 1, 2021
- **Manufacturer:** Mattel

WARRANTY AND SUPPORT

For detailed warranty information or further assistance, please refer to the official user manual available as a PDF document. You can typically find this document on the product's support page on the manufacturer's website or through the retailer where the product was purchased.

A digital version of the user manual can be accessed via this link:[Hot Wheels Massive Loop Mayhem User Manual \(PDF\)](#)