

QDRAGON B08ZYB9NPR

QDRAGON 3-in-1 Baby Walker and Activity Center Instruction Manual

Model: B08ZYB9NPR

[Instructions](#) [Product Overview](#) [Safety Information](#) [Setup](#) [Operating](#)
[Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. PRODUCT OVERVIEW

The QDRAGON 3-in-1 Baby Walker and Activity Center is designed to support infants and toddlers aged 12+ months through various developmental stages. It functions as a push walker, an entertainment table, and a hangable activity center. This product aims to enhance coordination, leg strength, and cognitive development.

Key Features:

- **3-in-1 Design:** Functions as a baby push walker, baby entertainment table, and hangable activity center.
- **Detachable Entertainment Table:** Features a turning cube, shape recognition block, colorful turnable gear, small beads, basketball frame, and an elephant-shaped electronic piano.
- **Stable Triangle Structure:** Designed with a stable triangle support structure and a four-point rectangular base to prevent rollover.
- **Water Tank Structure:** Allows for adding water or sand to increase chassis weight for enhanced stability during walking.
- **Adjustable Speed Wheels:** Rear wheels have anti-slip rings and can be adjusted to standard or low speed to accommodate different walking stages and help prevent bow legs.
- **Safe Materials:** Constructed from non-toxic ABS material with smooth, burr-free edges.

Product Dimensions and Weight:

- **Product Dimensions:** 15.7"L x 14.2"W x 18.1"H (as walker)
- **Item Weight:** 4.49 pounds
- **Material:** Plastic
- **Recommended Age:** 12 - 18 months

Product Dimensions



Image: The QDRAGON 3-in-1 Baby Walker and Activity Center in its walker configuration, showcasing its pink and white design with various activity features.

2. SAFETY INFORMATION

- Always supervise your child when using the walker or activity center.
- Ensure all parts are securely assembled before each use.
- Do not use on uneven surfaces, stairs, or near heat sources.
- Regularly inspect the product for any damage or loose parts. Discontinue use if any damage is found.
- The small balls included with the basketball hoop may pose a choking hazard for infants. Always supervise children during play with these items.
- Ensure the water tank is properly sealed if filled, to prevent spills.
- This product is intended for children aged 12-18 months. Adjust speed settings according to your child's developmental stage and walking ability.


3. SETUP INSTRUCTIONS

Follow these steps to assemble your QDRAGON 3-in-1 Baby Walker and Activity Center. A screwdriver is required for battery installation.


3.1. Baby Walker Assembly:

1. **Install Batteries:** Use a screwdriver to open the battery compartment in the main function part (activity panel). Insert 3x 1.5V AAA batteries.
2. **Remove Activity Panel:** Press the white button to detach the main activity panel from the walker frame.
3. **Attach Handlebar:** Insert the handlebar into the baby walker frame and secure it with the plastic screw.
4. **Fill Water Tank (Optional):** Open the cover of the box and fill with water or sand to increase the weight of the walker chassis for added stability. Close the cover securely.
5. **Attach Rear Support:** Place the heavy box (water tank compartment) at the back of the baby walker and lock it with 3 plastic screws.
6. **Install Walker Holders:** Install the two baby walker holders (side supports).
7. **Install Wheels:** Attach the wheels to the baby walker frame.
8. **Final Check:** Ensure all parts are securely fastened.


Baby Walker Instruction:




Use 3X1.5V AAA batteries in the main function part




Press the white button to take out the main function part




Put the handlebar into the baby walker and then lock the plastic screw




Open the cover of the box and fill in water or sand to gain the weight of the baby walker




Put the heavy box at the back side of the baby walker and lock 3 plastic screws



Install two baby walker holders




Install wheels on the baby walker




Final product show


Play table Instruction:



Take out the basket net and insert it into the side of the product.



Press the white button to take out the main function part



Install 4 holders into the table



Final product show

Image: Visual guide for assembling the baby walker, including battery installation, handlebar attachment, water tank filling, and wheel installation.

3.2. Play Table Conversion:

1. **Remove Activity Panel:** Press the white button to detach the main activity panel from the walker frame.
2. **Attach Table Legs:** Install 4 holders (legs) into the designated slots on the activity panel to convert it into a play table.



Image: Visual guide for converting the activity panel into a standalone play table by attaching four legs.

3.3. Hangable Activity Center:

The detachable activity panel can also be hung on a crib or other suitable surface using straps (not explicitly mentioned in box contents, but implied by images). Ensure it is securely fastened to prevent falling.



Image: A baby interacting with the detachable activity panel, which is shown hung on the side of a crib.

4. OPERATING INSTRUCTIONS

4.1. Using as a Push Walker:

- Ensure the water tank is filled for optimal stability, especially for new walkers.
- Adjust the rear wheel speed: Unlock for standard speed, lock for low speed. This helps control the pace and supports early walking development.
- The adjustable handle can be set to a comfortable height for your child.

2 Speeds Can Be Adjusted



Image: A detailed view of the rear wheels, highlighting the anti-slip rubber ring and the lock/unlock mechanism for speed adjustment.



Image: Illustration of the adjustable handle and the water tank compartment, which can be filled to add weight for stability.

4.2. Interactive Activity Panel:

The activity panel offers various engaging features:

- **Electronic Piano:** Press the keys on the elephant-shaped piano to play melodies and sounds.
- **Basketball Frame:** Practice hand-eye coordination by tossing the included small balls into the hoop.
- **Turning Cube & Shape Recognition:** Manipulate the turning cube and fit shapes into their corresponding slots.
- **Turnable Gears:** Spin the colorful gears to develop fine motor skills.
- **Lightful Trunk & Rattle:** Engage with the light-up elephant trunk and attached rattle.

Activity Center For Baby



Image: A detailed view of the activity panel, highlighting features such as the basketball frame, turning cube, shape sorter, gears, and electronic piano.

4.3. Official Product Videos:

Your browser does not support the video tag.

Video: This video demonstrates the QDRAGON 3-in-1 Baby Walker and Activity Center in use, showcasing its various modes and interactive features for infant and toddler development.

Your browser does not support the video tag.

Video: A short video highlighting the "Cutest baby push walker" feature, demonstrating a baby interacting with the walker and its activity panel.

Your browser does not support the video tag.

Video: This video provides a review of the 3-in-1 activity table and walker, showing its functionality and how a child interacts with it.

Your browser does not support the video tag.

Video: A review showcasing the QDRAGON Baby Walker and Activity Center, highlighting its features and benefits for toddlers.

Your browser does not support the video tag.

Video: This video demonstrates the QDRAGON Baby Walker and Activity Center, focusing on its use as a walker and activity table.

Your browser does not support the video tag.

Video: A demonstration of the Sit-to-Stand Walker Toy, showing its functionality and how a child can use it for support.

Your browser does not support the video tag.

Video: A brief video showcasing the QDRAGON Baby Walker, with a user expressing mixed feelings but demonstrating its use.

Your browser does not support the video tag.

Video: This video highlights the QDRAGON 3-in-1 Baby Walker as a favorite, demonstrating its versatility as a walker and activity center.

Your browser does not support the video tag.

Video: A video demonstrating the QDRAGON 3-in-1 Baby Walker and Activity Center, emphasizing its easy setup and multiple functions.

5. MAINTENANCE

- **Cleaning:** Wipe down all plastic surfaces with a damp cloth and mild soap. Avoid abrasive cleaners.
- **Drying:** Ensure all parts are completely dry before storing or allowing your child to play with the product again.
- **Storage:** Store in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Replacement:** Replace batteries in the electronic piano when sounds become faint or stop working. Ensure correct polarity.

6. TROUBLESHOOTING

- **Wheels not moving smoothly:**
 - Check if the speed adjustment mechanism on the rear wheels is in the "unlocked" position.
 - Ensure no debris is caught in the wheels.
 - Note: The walker may not move well on thick or high-pile carpets. It performs best on hard, flat surfaces.
- **Activity panel not producing sound/lights:**
 - Check if the batteries are correctly installed and not depleted. Replace if necessary.
 - Ensure the power switch on the electronic piano is turned "on".
- **Walker feels unstable:**
 - Verify that the water tank is filled with water or sand to increase stability.
 - Ensure all assembly screws and connections are tight.

7. SPECIFICATIONS

Product Name	QDRAGON 3-in-1 Baby Walker and Activity Center
Model Number	B08ZYB9NPR
Brand	QDRAGON
Material	Plastic (ABS)
Color	Pink

Product Dimensions (Walker)	15.7"L x 14.2"W x 18.1"H
Item Weight	4.49 pounds
Recommended Age	12 - 18 months
Power Source (Piano)	3x 1.5V AAA Batteries (not included)
What's in the Box	Baby walker (components for 3-in-1 modes)

8. WARRANTY AND SUPPORT

For warranty information or product support, please contact QDRAGON customer service directly. Refer to the product packaging or the manufacturer's official website for contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question