

[Manuals.plus](#) /

› [Inpods](#) /

› Inpods Little Fun Mini Portable Bluetooth Speaker User Manual

Inpods Inpods Little Fun

Inpods Little Fun Mini Portable Bluetooth Speaker User Manual

1. INTRODUCTION

This manual provides comprehensive instructions for the safe and efficient operation of your Inpods Little Fun Mini Portable Bluetooth Speaker. Please read this manual thoroughly before using the product and retain it for future reference.

2. PRODUCT OVERVIEW

The Inpods Little Fun is a compact and portable Bluetooth speaker designed for wireless audio playback. It features Bluetooth 5.0 connectivity, True Wireless Stereo (TWS) pairing, and a 360-degree sound experience.



Figure 2.1: Inpods Little Fun Mini Portable Bluetooth Speaker (Blue)

This image displays the Inpods Little Fun Mini Portable Bluetooth Speaker in a blue color. It has a compact, cylindrical design with a perforated grille on the top surface for sound output. The speaker is shown from a slightly elevated angle, highlighting its minimalist aesthetic.

3. FEATURES

- **Bluetooth 5.0 Connectivity:** Ensures stable and efficient wireless connection.
- **True Wireless Stereo (TWS):** Allows two Inpods Little Fun speakers to connect for enhanced stereo sound.
- **360-degree Sound:** Designed for balanced sound diffusion in all directions.
- **Compact and Portable Design:** Small size for easy carrying.
- **Integrated Control:** Simple one-button operation.
- **Phone Function:** Supports hands-free calling.
- **Multiple Playback Functions:** Supports MP3 playback.

4. PACKAGE CONTENTS

Please check the package contents upon unboxing:

- Inpods Little Fun Mini Portable Bluetooth Speaker
- Micro USB Charging Cable
- User Manual



Figure 4.1: Speaker and Accessories in Box

This image shows the Inpods Little Fun speaker (a grey variant) nestled within its compact white retail packaging. A charging cable is visible alongside the speaker, illustrating the typical contents of the product box.

5. SETUP

5.1. Charging the Speaker

1. Locate the Micro USB charging port at the bottom of the speaker.
2. Connect the provided Micro USB cable to the speaker's charging port.
3. Connect the other end of the USB cable to a DC 5V power source (e.g., USB wall adapter, computer USB port).
4. The charging indicator light will illuminate (color may vary) to show that the speaker is charging.
5. Once fully charged (approximately 3-4 hours), the indicator light will change or turn off.

5.2. Power On/Off

- **To Power On:** Press and hold the power button (often the main control button) for a few seconds until you hear an audible prompt or see an indicator light.
- **To Power Off:** Press and hold the power button again for a few seconds until you hear an audible prompt or the indicator light turns off.

5.3. Bluetooth Pairing (Single Speaker)

1. Ensure the speaker is fully charged and powered on. It will automatically enter Bluetooth pairing mode, indicated by a flashing LED light.
2. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
3. Select "Inpods Little Fun" from the list of found devices.
4. Once connected, you will hear a confirmation sound, and the LED indicator will stop flashing and remain solid.

5.4. True Wireless Stereo (TWS) Pairing (Two Speakers)

To achieve a stereo sound experience, you can pair two Inpods Little Fun speakers together:

1. Ensure both Inpods Little Fun speakers are powered on and not connected to any other Bluetooth device.
2. On **one** of the speakers, double-click the main control button. This speaker will initiate TWS pairing.
3. The two speakers will automatically search for and connect to each other. You will hear a confirmation tone once TWS pairing is successful.
4. Once TWS paired, connect your device to **one** of the speakers via Bluetooth as described in Section 5.3. Both speakers will then play audio in stereo.

inPODS LITTLEFUN

TWS Bluetooth speaker

inpods littleFun TWS Two speakers can be connected to each other,
a mobile phone can connect two speakers, giving you a different experience



Connection method: when the speaker is turned on. Double-click any side to power the key

Figure 5.1: TWS Pairing Illustration

This illustration depicts two Inpods Little Fun speakers, one light blue and one light green, wirelessly connected to each other. An arrow indicates the wireless connection between them, symbolizing the True Wireless Stereo (TWS) pairing functionality where two speakers work together to deliver stereo sound from a single source.

6. OPERATING INSTRUCTIONS

6.1. Basic Controls

The Inpods Little Fun speaker features a single integrated control button for various functions:

- **Power On/Off:** Press and hold the button.
- **Play/Pause:** Short press the button during music playback.
- **Answer/End Call:** Short press the button during an incoming call or active call.
- **Reject Call:** Press and hold the button during an incoming call.
- **TWS Pairing:** Double-click the button when two speakers are on and not connected to a device (refer to Section

5.4).

- *Note: Volume and track skipping are typically controlled via the connected Bluetooth device.*

6.2. Call Functions

When connected to a smartphone, the speaker can be used for hands-free calling:

- **Answering a Call:** A short press of the control button will answer an incoming call.
- **Ending a Call:** A short press of the control button during a call will end it.
- **Rejecting a Call:** Press and hold the control button for approximately 2 seconds to reject an incoming call.

7. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the speaker. Do not use abrasive cleaners or solvents.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, charge the speaker regularly, even if not in frequent use. Avoid fully discharging the battery for extended periods.
- **Water Resistance:** The product is listed as "Is Waterproof: True". While it may withstand splashes, avoid submerging it in water. Ensure the charging port cover is securely closed if present.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker fully.
Cannot pair via Bluetooth.	Speaker is not in pairing mode; Bluetooth is off on device; device too far.	Ensure speaker is in pairing mode (flashing LED). Enable Bluetooth on your device. Move device closer to speaker (within 10 meters).
No sound.	Volume too low; speaker not connected; audio source issue.	Increase volume on both speaker and connected device. Re-pair the speaker. Check audio playback on your device.
TWS pairing fails.	Speakers already connected to another device; incorrect pairing procedure.	Ensure both speakers are disconnected from other devices. Follow TWS pairing steps carefully (Section 5.4).

9. SPECIFICATIONS

- **Model Name:** Inpods Little Fun
- **Bluetooth Version:** 5.0
- **Output Power:** 5W
- **Signal-to-Noise Ratio:** ≥90dB
- **Frequency Range:** 120Hz-20KHz
- **Battery Capacity:** 400mAh
- **Working Voltage:** DC 5V, 3.7V
- **Work Time:** 3-4 Hours (approx.)

- **Speaker Type:** Portable, Surround Sound
- **Material:** Plastic
- **Item Weight:** 100 g
- **Dimensions:** 7.2 x 7.2 x 5.6 cm (Package Dimensions)
- **Waterproof:** Yes
- **Control Method:** Touch (Integrated Button)
- **Connectivity Technology:** Bluetooth, AUX, USB
- **Memory Card Support:** Yes

10. WARRANTY AND SUPPORT

The Inpods Little Fun Mini Portable Bluetooth Speaker comes with a standard manufacturer's warranty. For specific warranty details, please refer to the warranty card included in your product packaging or contact your retailer. For technical support, troubleshooting assistance, or warranty claims, please contact the customer support provided by your point of purchase or the official Inpods support channels.

Online Support: Visit the official Inpods website for FAQs and support resources.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B0911ZM86G>

More documents and user manuals: <https://manuals.plus/>