

Manuals.plus /

> VISWIN /

> VISWIN Extended Large H-Frame Easel Instruction Manual

VISWIN ELHF_W02DW_V

VISWIN Extended Large H-Frame Easel Instruction Manual

Model: ELHF_W02DW_V | Brand: VISWIN

INTRODUCTION

Thank you for choosing the VISWIN Extended Large H-Frame Easel. This easel is designed for artists requiring a stable, adjustable, and versatile platform for various canvas sizes. Crafted from high-quality beech wood, it features a robust H-frame design, adjustable height and angle, a double-layer storage tray, and lockable swivel casters for mobility. Please read this manual thoroughly before assembly and use to ensure proper function and longevity of your easel.

KEY FEATURES

- Adjustable Height & Angle:** Easily raise or lower the canvas tray with a metal ratchet system. The mast allows for angle adjustments from a slight forward tilt to a fully folded position for storage.
- Premium Beech Wood Construction:** Made from solid beech wood with durable metal fittings, ensuring stability and long-term use.
- Double-Extension Mast:** Accommodates canvases up to 93 inches (2362 mm) in height.
- Movable with Lockable Casters:** Equipped with four 360° swivel casters, each with a lock, for easy movement and secure positioning.
- Double-Layer Storage Tray:** Features a 70mm deep tray to keep art supplies organized and within reach.
- Foldable Design:** Folds to a compact 2.5 inches (65 mm) thickness for convenient storage.

SETUP INSTRUCTIONS

The easel comes with clear step-by-step instructions and labeled parts for straightforward assembly. An assembly video is also available for visual guidance.

Unpacking and Component Check

- Carefully remove all components from the packaging.
- Verify that all parts listed in the included parts list are present and undamaged.

3. Identify wooden parts by their easy-peel number stickers and hardware by individual packaging.

Assembly Steps

Follow the detailed instructions provided in the physical manual. Key steps typically include:

- Attaching the base supports to the main H-frame.
- Securing the four swivel casters to the base.
- Mounting the double-layer storage tray to the main mast.
- Assembling the double-extension mast and canvas holders.




Figure 1: Easel Dimensions and Canvas Capacity.

The image shows a dark brown H-frame easel. It has a central vertical mast with a sliding mechanism near the top. The base consists of two horizontal legs connected by a crossbar. The background is a textured, light brown surface.

VISWIN

Higher Stronger More Professional

Figure 2: Fully assembled H-Frame Easel.

OPERATION

Adjusting Height and Angle

The easel features a metal ratchet system for easy height adjustment of the canvas tray. Simply lift the tray to engage the ratchet at your desired height. To lower, disengage the ratchet and carefully guide the tray down. The flexible slider on the mast allows for angle adjustments, from a slight forward tilt (approximately 5°) to a fully vertical position.



Figure 3: Adjustable Height and Angle Mechanism.



Figure 4: Detail of the metal ratchet for height adjustment.

Securing Canvases

The double-extension mast and adjustable canvas holders securely hold canvases up to 93 inches. Use the flexible slider to position the top canvas holder to firmly grip your canvas.

Double-mast

Max height: 93"(2360 mm)

Accommodate more sizes of canvas





Figure 5: Accommodating various canvas sizes with the double-mast.



Figure 6: Double mast adjustment detail.

Mobility and Stability

The easel is equipped with four 360° swivel casters. To move the easel, unlock the casters. To secure the easel in place, engage the locks on all four casters. The sturdy H-frame base provides superior stability during use.



Square base

More stable structure than A-frame easel



Easy to move with 4 lockable casters

Figure 7: Square base and lockable casters for mobility and stability.



Figure 8: Detail of locking a caster wheel.

Using the Storage Tray

The double-layer tray provides convenient storage for brushes, paints, and other art supplies, keeping them organized and within easy reach while you work.

Double-layer tray

Raised edge

Adjustable height

Keep organized



Figure 9: Double-layer storage tray with art supplies.



Figure 10: Storage tray detail with supplies.

Folding for Storage

To fold the easel for compact storage, adjust the mast to its lowest position and then tilt the easel forward until it lies flat. This reduces its thickness to approximately 2.5 inches (65 mm).



- Easy for storage
- Not take up much space
- Folded: 2 ¹/₂" (65 mm) thick

Figure 11: Easel in folded position for storage.

Your browser does not support the video tag.

Video 1: Demonstrates the assembly, adjustment, and folding of the VISWIN H-Frame Easel, highlighting its features like the sturdy base, metal ratchet, double-layer tray, double mast, and flexible slider. It also shows how to lock/unlock wheels and store the easel.

- **Cleaning:** Wipe down the wooden surfaces with a soft, dry cloth. For stubborn marks, use a slightly damp cloth and dry immediately. Avoid harsh chemicals that may damage the wood finish.
- **Hardware:** Periodically check all screws and knobs to ensure they are tight. Tighten any loose fittings to maintain stability.
- **Storage:** When not in use, store the easel in a dry environment away from extreme temperature changes or direct sunlight to prevent wood warping or cracking.

TROUBLESHOOTING

- **Easel is unstable:** Ensure all assembly screws are tightened. Check that the casters are locked when the easel is stationary. Verify the canvas is properly seated and secured by the holders.
- **Difficulty adjusting height/angle:** Loosen the adjustment knobs sufficiently before attempting to move the canvas tray or mast. Ensure the metal ratchet is properly engaged or disengaged.
- **Casters not rolling smoothly:** Check for debris caught in the wheels. Clean the casters if necessary. Ensure the locks are fully disengaged.

SPECIFICATIONS

Feature	Detail
Brand	VISWIN
Model Name	ELHF_W02DW_V
Color	Walnut
Material	Beech Wood
Product Dimensions (D x W x H)	24"D x 24"W x 146"H (61cm x 61cm x 370.8cm)
Item Weight	28.7 Pounds (13 kg)
Max Canvas Height	93 inches (2362 mm)
Max Loading Capacity	66 lbs (30 kg)
Easel Type	H-Frame Easel
Mobility	4 Lockable Swivel Casters
Storage	Double-layer tray (70mm deep)
Foldable	Yes, folds to 2.5" (65 mm) thick

WARRANTY INFORMATION

VISWIN is dedicated to providing high-quality products. This easel comes with a lifetime guarantee. If the product is found to be defective upon receipt or during normal use due to non-external reasons, please contact us for assistance. We are committed to ensuring your satisfaction.

CUSTOMER SUPPORT

For any questions, concerns, or assistance with your VISWIN H-Frame Easel, please refer to the contact information provided with your purchase or visit the official VISWIN store on Amazon:

[Visit the VISWIN Store](#)

© 2026 VISWIN. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0912M3CX4>

More documents and user manuals: <https://manuals.plus/>